Canarm IPL707A01BN

Canarm Arden IPL707A01BN 1-Light Cord Pendant User Manual

Model: IPL707A01BN | Brand: Canarm

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Canarm Arden IPL707A01BN 1-Light Cord Pendant. Please read all instructions carefully before beginning installation and retain this manual for future reference. This pendant light is designed for indoor use and features a brushed nickel finish with a watermark glass shade.

Image 1.1: Main view of the Canarm Arden 1-Light Cord Pendant.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, follow these instructions:

- Always disconnect power at the main circuit breaker or fuse box before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. If you are unsure about wiring, consult a qualified electrician.
- Do not exceed the maximum wattage specified for this fixture (100W Type A bulb).
- Ensure the fixture is securely mounted to a structural part of the building.
- Do not connect this fixture to an ungrounded electrical system.
- Avoid touching the bulb directly with bare hands when replacing, as oils from your skin can shorten bulb life.
- Do not operate the fixture with a damaged cord or if it has been dropped or damaged in any way.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, contact Canarm customer support before proceeding with installation.

- Pendant Light Fixture (with cord and shade)
- Mounting Hardware (Canopy, Mounting Plate, Screws, Wire Nuts)
- Instruction Manual

Image 3.1: View of the pendant light fixture and associated components.

4. SETUP AND INSTALLATION

Before installation, ensure the power is turned off at the circuit breaker. This fixture requires assembly and ceiling mounting.

4.1 Tools Required (Not Included)

- Phillips Head Screwdriver
- Wire Strippers
- Electrical Tape
- Ladder

4.2 Installation Steps

1. **Turn off Power:** Locate the circuit breaker controlling the light fixture and turn it off.
2. **Prepare Mounting Plate:** Attach the mounting plate to the junction box in the ceiling using the provided screws. Ensure it is securely fastened.
3. **Adjust Cord Length:** The pendant cord length is adjustable from 10 to 58 inches. Determine the desired hanging height and adjust the cord accordingly. Secure any excess cord within the canopy or junction box.
4. **Wire Connections:**

   - Connect the fixture's black wire to the house's black (live) wire.
   - Connect the fixture's white wire to the house's white (neutral) wire.
   - Connect the fixture's ground wire to the house's ground wire (bare copper or green).
   - Secure all connections with wire nuts and electrical tape.

5. **Mount Canopy:** Carefully push the canopy up to the ceiling, aligning the mounting holes with the screws on the mounting plate. Secure the canopy with the decorative nuts or screws.
6. **Install Bulb:** Screw in one 100W Type A (E26 base) incandescent bulb into the socket. Do not exceed the maximum wattage.
7. **Restore Power:** Turn the power back on at the circuit breaker.

Image 4.1: Example of the pendant light installed in a kitchen setting.

5. OPERATING INSTRUCTIONS

The Canarm Arden pendant light operates via a standard wall switch (not included). Once installed and powered, simply use the wall switch to turn the light on or off. The fixture is designed for incandescent bulbs and features a touch control method, which typically refers to the type of switch it's compatible with, rather than an integrated touch sensor on the fixture itself.

5.1 Bulb Replacement

1. **Turn off Power:** Always turn off the power at the circuit breaker before replacing the bulb.
2. **Allow to Cool:** Allow the old bulb to cool completely before touching it.
3. **Remove Old Bulb:** Unscrew the old bulb counter-clockwise.
4. **Install New Bulb:** Screw in a new 100W Type A (E26 base) incandescent bulb clockwise until snug. Do not overtighten.
5. **Restore Power:** Turn the power back on at the circuit breaker.

Image 5.1: Top-down view illustrating the bulb within the watermark glass shade.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your pendant light.

- **Cleaning:** To clean the fixture, turn off the power and wipe with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or glass.
- **Glass Shade:** The watermark glass shade can be carefully removed for more thorough cleaning if necessary. Ensure it is completely dry before reattaching.
- **Bulb Check:** Periodically check the bulb for signs of wear or dimming and replace as needed.

7. TROUBLESHOOTING

If you experience issues with your pendant light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Defective bulb.	Check circuit breaker and wall switch. Verify all wire connections are secure (ensure power is off first). Replace bulb with a new one.
Light flickers.	Loose bulb. Loose wire connection. Incorrect bulb type/wattage.	Tighten bulb. Check wire connections (ensure power is off first). Ensure bulb is 100W Type A (E26 base).
Fixture hums.	Loose components. Incompatible dimmer switch (if applicable).	Ensure all parts are securely fastened. If using a dimmer, ensure it is compatible with incandescent bulbs.

8. SPECIFICATIONS

Feature	Detail
Brand	Canarm
Model Number	IPL707A01BN
Material	Metal, Glass
Finish Type	Brushed Nickel
Shade Material	Glass (Watermark)
Light Source Type	Incandescent
Number of Light Sources	1
Wattage	100 watts (Max)
Bulb Base	E26
Voltage	120 Volts (AC)
Product Dimensions	5.5"L x 4.38"W x 7.6"H (Fixture only)
Adjustable Height	10 to 58 inches
Indoor/Outdoor Usage	Indoor
Mounting Type	Ceiling Mount
Control Method	Wall Switch (Touch compatible)
Certification	CSA

9. WARRANTY AND SUPPORT

This Canarm Arden IPL707A01BN 1-Light Cord Pendant is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or to inquire about replacement parts, please contact Canarm customer service. Keep your proof of purchase for warranty validation.

You can find contact information for Canarm by visiting their official website or the retailer where the product was purchased.

Related Documents - IPL707A01BN

	GSF Series Galvanized Shutter Fans Operation Instructions and Parts Manual Operation instructions, parts manual, warranty, and installation guide for Canarm's GSF Series Galvanized Shutter Fans, designed for light commercial exhaust ventilation applications.
	CANARM XFS Light Commercial Wall Exhaust Fans Instruction Manual Comprehensive instruction manual for CANARM XFS series light commercial wall exhaust fans, covering installation, operation, maintenance, specifications, and warranty information.
	CANARM XFS Light Commercial Wall Exhaust Fan Instruction Manual Official instruction manual for CANARM XFS series light commercial wall exhaust fans. Includes product overview, specifications, installation, operation, maintenance, warranty, and contact information.
	Canarm LED Surface Mount Light Installation Instructions Comprehensive installation guide for Canarm LED Surface Mount Lights, including models DL-11C-15FC, DL-11C-22FC, DL-15A-30FC, and DL-15C-30FC. Covers safety precautions, maintenance, preparation, and step-by-step assembly.
	CANARM XFS Series Light Commercial Wall Exhaust Fans - Instruction Manual Comprehensive instruction manual for CANARM XFS series light commercial wall exhaust fans. Includes details on warranty, installation, operation, maintenance, and technical specifications for models XFS12 through XFS36.

Comprehensive installation instructions and safety precautions for the Canarm Ceiling Fan Wall-Mounted Control, covering wiring diagrams and model compatibility for the CP48D, CP56D, CP60D series.