

Smeg CJF01RDUS



SMEG CJF01RDUS Electric Citrus Juicer Instruction Manual

Model: CJF01RDUS

[Information](#) [Setup](#) [Operation](#) [Maintenance](#) [Introduction](#) [Safety](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the SMEG CJF01RDUS Electric Citrus Juicer. This manual provides essential information for the safe and efficient use, maintenance, and care of your appliance. Please read it thoroughly before first use and keep it for future reference.

The SMEG Electric Citrus Juicer is designed for extracting juice from citrus fruits such as oranges, lemons, limes, and grapefruits. Its powerful motor and durable components ensure efficient juicing.



Figure 1: SMEG CJF01RDUS Electric Citrus Juicer, Red.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Do not immerse the motor base in water or any other liquid. Do not operate with a damaged cord or plug.
- **General Use:** This appliance is for household use only. Do not use outdoors. Keep hands and utensils away from moving parts during operation. Always ensure the juicer is properly assembled before use.
- **Children:** This appliance is not intended for use by children or persons with reduced physical, sensory,

or mental capabilities unless supervised by a responsible adult.

- **Cleaning:** Always unplug the appliance before cleaning. Refer to the 'Maintenance and Cleaning' section for detailed instructions.
- **Proposition 65 Warning:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. SETUP AND ASSEMBLY

Before first use, unpack all components and remove any packaging materials. Wash all removable parts (reamer, strainer, juice collector, dust cover) in warm soapy water, rinse thoroughly, and dry completely.

3.1 Component Identification



Figure 2: Key components of the SMEG Citrus Juicer.

1. **Dust Cover:** Transparent cover to protect the reamer and strainer when not in use.
2. **Reamer:** Stainless steel cone for extracting juice from citrus halves.
3. **Strainer:** Stainless steel mesh to separate pulp and seeds from the juice.

4. **Juice Collector:** BPA-free Tritan bowl that collects the extracted juice.
5. **Anti-Drip Spout:** Stainless steel spout for dispensing juice directly into a glass. Can be lifted to stop flow.
6. **Motor Base:** Houses the 80W motor and features a built-in cord wrap.

3.2 Assembling the Juicer

1. Place the motor base on a stable, flat surface.
2. Position the juice collector onto the motor base, ensuring it is seated correctly.
3. Place the stainless steel strainer into the juice collector.
4. Mount the stainless steel reamer onto the central shaft of the motor base, ensuring it is firmly in place.
5. The dust cover can be placed on top when the juicer is not in use.

3.3 Cord Management

The power cord is approximately 3 feet long and features a built-in cord wrap located underneath the motor base for tidy storage when not in use.

4. OPERATING INSTRUCTIONS

The SMEG Electric Citrus Juicer is designed for simple, automatic operation.

1. Ensure the juicer is properly assembled and plugged into a suitable power outlet.
2. Cut your citrus fruit (e.g., orange, lemon, lime, grapefruit) in half.
3. Place a glass or container under the anti-drip spout. Ensure the spout is in the down position to allow juice to flow.
4. Place a fruit half onto the reamer and apply gentle downward pressure. The motor will automatically start.
5. Continue pressing and rotating the fruit until all juice is extracted. The universal reamer is designed to efficiently extract juice from various citrus sizes.
6. Release pressure to stop the motor. Lift the anti-drip spout to prevent any remaining drips.
7. **Important:** Do not operate the juicer continuously for more than 3 minutes to prevent motor overheating. Allow a cooling period if multiple batches are needed.

Your browser does not support the video tag.

Video 1: Official SMEG CjF01 Citrus Juicer demonstration, showing assembly and juicing process.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your juicer. Always unplug the appliance from the power outlet before cleaning.

5.1 Disassembly for Cleaning

1. Remove the dust cover.
2. Lift off the reamer.
3. Remove the stainless steel strainer.
4. Carefully lift the Tritan juice collector from the motor base.



Figure 3: Disassembled components of the SMEG Citrus Juicer for cleaning.

5.2 Cleaning Instructions

- **Removable Parts:** The dust cover, reamer, strainer, and juice collector should be washed by hand in warm soapy water. Rinse thoroughly and dry immediately. These parts are **not dishwasher safe**.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or spray it with liquids.
- **Storage:** Once all parts are clean and dry, reassemble the juicer and place the dust cover on top to protect it from dust.

6. TROUBLESHOOTING

If you encounter any issues with your SMEG Citrus Juicer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not start when fruit is pressed.	Not plugged in; components not correctly assembled; insufficient pressure on fruit.	Check power connection. Ensure reamer and juice collector are securely in place. Apply firm, even pressure to the fruit.
Low juice yield.	Fruit not fully reamed; fruit too small/large for efficient juicing.	Ensure fruit is pressed firmly and rotated on the reamer until all pulp is extracted. The universal reamer is designed for various sizes, but some fruits may require more attention.
Juice leaks from the spout.	Spout not fully closed (lifted position).	Ensure the anti-drip spout is pushed down to the closed position after dispensing juice.
Motor stops during operation.	Overheating due to prolonged use.	Allow the juicer to cool down for several minutes before resuming operation. Avoid continuous use for more than 3 minutes.
General malfunction.	Loose parts or minor misalignment.	Disassemble and reassemble the juicer components carefully, ensuring each part is correctly seated. This often resolves minor operational issues.

If the problem persists after attempting these solutions, please contact SMEG Customer Support.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	CJF01RDUS
Brand	Smeg
Color	Red
Power	80 Watts
Voltage	120 Volts
Material	Die-cast aluminum (body), Stainless Steel (reamer, strainer, spout), Tritan (juice collector, dust cover)
Product Dimensions (D x W x H)	6.54"D x 7"W x 11.06"H
Item Weight	6 Pounds
Capacity	0.6 Liters
Controller Type	Manual (pressure activated)
Care Instructions	Hand Wash Only (removable parts)
Special Features	Cord Storage, Anti-drip Spout, Automatic On/Off
UPC	812895020809

8. WARRANTY AND SUPPORT

8.1 Manufacturer's Warranty

This SMEG CJF01RDUS Electric Citrus Juicer comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal household use. It does not cover damage resulting from misuse, accident, alteration, neglect, unauthorized repair, or commercial use.

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, warranty claims, or to order replacement parts, please contact SMEG Customer Support:

- **Website:** Visit the official SMEG website for support resources and contact information.
- **Phone:** Refer to your product packaging or the SMEG website for regional customer service numbers.

When contacting support, please have your product model number (CJF01RDUS) and date of purchase readily available.

