



[Manuals.plus](#) /

› [Koblenz](#) /

› Koblenz LKM-9510 RVI Professional Blender Instruction Manual

## Koblenz LKM-9510 RVI

# Koblenz LKM-9510 RVI Professional Blender Instruction Manual

Model: LKM-9510 RVI

## INTRODUCTION

---

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Koblenz LKM-9510 RVI Professional Blender. Please read all instructions carefully before first use and retain this manual for future reference.



Image: The Koblenz LKM-9510 RVI Professional Blender filled with various fruits and vegetables, ready for blending.

## IMPORTANT SAFETY INFORMATION

---

**WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

- Always ensure the blender is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the container while blending to reduce the risk of severe personal injury and/or damage to the blender.
- Never blend hot liquids in a sealed container. Allow hot liquids to cool before blending.
- Ensure the lid is securely in place before operating the blender.
- Do not operate the blender with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

## PRODUCT COMPONENTS

Your Koblenz LKM-9510 RVI Professional Blender consists of several key components designed for optimal performance and durability.



Image: An exploded diagram showing the blender's components: lid, borosilicate glass jar, stainless steel blades, motor base, and multi-function control panel.

- **Lid:** Secures the contents during blending.
- **1.75-Liter Borosilicate Glass Jar:** A durable, high-impact glass container with clear measurement indicators for precise ingredient quantities.
- **Stainless Steel Blades:** Bi-directional, ultra-reversible blades with two layers for efficient blending and easy cleaning.
- **Motor Base:** Houses the powerful 1000-watt motor and electronic controls. Features stainless steel construction.
- **Multi-function Electronic Control Panel:** Provides various blending options including pulse and multiple speed settings.



# Stainless steel, bi-directional, ultra-reversible **blades**



Image: Detailed view of the stainless steel bi-directional, ultra-reversible blades, showing their two-layer design.

## SETUP

---

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or shipping if needed.
2. **Clean:** Before first use, wash the glass jar, lid, and blades with warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
3. **Assemble:** Place the blade assembly securely onto the motor base. Then, place the glass jar onto the motor base, ensuring it is properly seated and locked into position.
4. **Position:** Place the blender on a clean, dry, and stable surface. Ensure the power cord is not obstructed and is within reach of a suitable electrical outlet.
5. **Connect Power:** Plug the blender into a standard 120V AC electrical outlet.

## OPERATING INSTRUCTIONS

---

The Koblenz LKM-9510 RVI blender features multi-function electronic controls for versatile blending.



## Multi-function electronic control and pulse



Image: A hand interacting with the multi-function electronic control panel, showing the 'Smoothie', 'Pulse', 'LO', 'MED', and 'HI' buttons.

1. **Add Ingredients:** Place your desired ingredients into the glass jar. Do not exceed the maximum fill line indicated on the jar. For best results, add liquids first, then soft ingredients, followed by harder ingredients and ice.
2. **Secure Lid:** Place the lid firmly onto the glass jar.
3. **Select Function/Speed:**
  - **Pulse:** Press and hold the 'PULSE' button for short bursts of power. Release to stop. This is ideal for chopping or controlling consistency.
  - **Low (LO):** Press the 'LO' button for continuous low-speed blending.
  - **Medium (MED):** Press the 'MED' button for continuous medium-speed blending.
  - **High (HI):** Press the 'HI' button for continuous high-speed blending.
  - **Smoothie:** Press the 'SMOOTHIE' button for a pre-programmed blending cycle optimized for smoothies.
4. **Blend:** Allow the blender to operate until desired consistency is achieved. The low revolutions feature helps retain nutrients and natural fibers.
5. **Stop:** Press the selected speed button again or the 'OFF' button (if available) to stop the blender. Unplug the unit from the power outlet after use.



Image: A woman operating the Koblenz blender in a kitchen, illustrating the benefit of nutrient retention through low-revolution blending.

## CLEANING AND MAINTENANCE

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Disassemble:** Remove the glass jar and blade assembly from the motor base.
3. **Wash Jar and Blades:** Wash the glass jar, lid, and blade assembly with warm, soapy water. The stainless steel bi-directional blades are designed for easy cleaning. Use a brush to clean around the blades carefully. Rinse thoroughly and dry completely.
4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
5. **Storage:** Store the blender in a clean, dry place. Ensure all parts are dry before storing to prevent mold or mildew.

## TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet not working; jar not properly seated.	Ensure the power cord is securely plugged into a working outlet. Check if the glass jar is correctly placed and locked onto the motor base.

Problem	Possible Cause	Solution
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients are too large.	Add more liquid. Reduce the amount of ingredients. Cut larger ingredients into smaller pieces. Use the 'PULSE' function to break down larger chunks.
Blender stops during operation.	Overheating due to prolonged use or overloading.	Unplug the blender and allow it to cool down for at least 15-20 minutes. Reduce the load or blending time.
Leakage from the bottom of the jar.	Blade assembly not tightened; seal damaged or missing.	Ensure the blade assembly is securely tightened to the jar. Check the rubber seal for proper placement and any damage. Replace if necessary.

## SPECIFICATIONS

Detailed technical specifications for the Koblenz LKM-9510 RVI Professional Blender.



Image: A diagram illustrating the height of the blender, measuring 18 inches (45 cm).

- **Model Number:** LKM-9510 RVI
- **Brand:** Koblenz
- **Color:** Silver
- **Capacity:** 1.75 Liters (Borosilicate Glass Jar)
- **Power Source:** Corded Electric
- **Voltage:** 120V
- **Motor:** Professional Grade (implied by product title, often 1000W+ for 'professional')
- **Number of Speeds:** 3 (Low, Medium, High) plus Pulse function
- **Blade Material:** Stainless Steel (Bi-directional, Ultra-reversible)
- **Construction:** Stainless Steel

- **Product Dimensions:** Approximately 14.6 x 11.4 x 9.6 inches
- **Item Weight:** Approximately 10.12 pounds
- **UPC:** 099053005063

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact Koblenz customer service. Refer to the product packaging or the official Koblenz website for the most current contact details and warranty terms.

It is recommended to keep your purchase receipt as proof of purchase for any warranty claims.