

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sennheiser](#) /

› [Sennheiser SK 100 G4-A Bodypack Transmitter Instruction Manual](#)

Sennheiser SK 100 G4-A

Sennheiser SK 100 G4-A Bodypack Transmitter

INSTRUCTION MANUAL

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Sennheiser SK 100 G4-A Bodypack Transmitter. The SK 100 G4-A is a robust bodypack transmitter designed for professional audio applications, featuring an 1/8" audio input socket (ew connector) and operating within the A frequency range (516 - 558 MHz).

Key features include:

- Bodypack transmitter with 1/8" audio input socket (ew connector).
- Frequency range: A (516 - 558 MHz).
- Durable metal construction for reliable performance.

Setup

Follow these steps to prepare your bodypack transmitter for use:

1. **Battery Installation:** Open the battery compartment on the bodypack. Insert two AAA batteries, ensuring correct polarity. Close the compartment securely.
2. **Microphone Connection:** Connect your microphone (e.g., lavalier microphone) to the 1/8" audio input socket (ew connector) on the bodypack. Ensure the connection is secure, often by twisting the connector to lock it in place.
3. **Power On:** Press and hold the power button until the display illuminates. The display will show battery status, frequency, and other operational information.



Figure 1: Front view of the Sennheiser SK 100 G4-A Bodypack Transmitter.



Figure 2: Top view showing the microphone input on the bodypack transmitter.

Operating Instructions

To ensure optimal performance, familiarize yourself with the following operating procedures:

- **Menu Navigation:** Use the navigation buttons (up/down arrows) to scroll through menu options on the display. The 'SET' button is typically used to confirm selections, and 'ESC' to exit.
- **Frequency Synchronization:** For seamless operation, synchronize the bodypack transmitter with its corresponding receiver. This usually involves placing the transmitter near the receiver and initiating a sync function on both devices. Refer to your receiver's manual for specific synchronization steps.
- **Mute Function:** The bodypack transmitter includes a mute switch (often labeled 'MUTE') to temporarily disable audio transmission. Ensure the switch is in the desired position during use.
- **Monitoring:** The display provides real-time information on battery life and signal strength. Monitor these indicators to prevent unexpected interruptions during operation.



Figure 3: Side view of the bodypack transmitter, showing controls and input.

Proper care extends the life of your device:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the bodypack. Avoid abrasive cleaners or solvents.
- **Battery Care:** Remove batteries if the device will not be used for an extended period to prevent leakage. Always use high-quality alkaline batteries.
- **Storage:** Store the transmitter in a cool, dry place away from direct sunlight and extreme temperatures.
- **General Safety:** This device emits radio frequency energy. Ensure it is used in accordance with local regulations and does not interfere with other wireless devices.

Troubleshooting

If you encounter issues, try these common solutions:

- **No Audio:** Check battery levels, ensure the microphone is securely connected, and verify the mute function is disengaged. Confirm the transmitter and receiver are synchronized to the same frequency.
- **Interference/Poor Signal:** Ensure the transmitter and receiver are within range and have a clear line of sight. Check for other wireless devices operating on similar frequencies and adjust channels if necessary.
- **Device Not Powering On:** Verify batteries are correctly installed and fully charged.

Specifications

Feature	Specification
Model Number	509501
Item Weight	8.8 ounces
Product Dimensions	13.8 x 3.2 x 2.9 inches
Batteries	2 AAA batteries required (Alkaline)
Compatible Devices	Headphones, Speakers, Audio Equipment
Connector Type	ew connector (1/8" audio input)
Hardware Interface	Radio Frequency
Material Type	Metal
Power Source	Battery Powered
Special Feature	Bodypack Transmitter
Connectivity Technology	Wireless

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the official Sennheiser website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

