

Bytech BYTECH Wireless Optical Mouse

BYTECH Wireless Optical Mouse User Manual

Model: BYTECH Wireless Optical Mouse

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your BYTECH Wireless Optical Mouse. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The BYTECH Wireless Optical Mouse is designed for comfortable and efficient navigation. It features a precise optical sensor, a scroll wheel, and a DPI adjustment button for customizable sensitivity. Its ergonomic design and wireless connectivity provide a clutter-free workspace.



Figure 1: Top-down view of the BYTECH Wireless Optical Mouse. The mouse is black with a silver stripe along its sides. A scroll wheel and a DPI button are visible on the top surface.



Figure 2: Side view of the BYTECH Wireless Optical Mouse. This angle highlights the ergonomic curve and the silver accent line that runs along the side of the mouse.

SETUP

1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert one AA battery (not included) into the compartment, ensuring the correct polarity (+/-) as indicated inside.
4. Close the battery compartment cover securely.

2. USB Receiver Connection

1. Remove the USB receiver from its storage slot, usually located inside the battery compartment or near it.
2. Plug the USB receiver into an available USB port on your computer or laptop.
3. Your operating system should automatically detect and install the necessary drivers. This may take a few moments.

3. Powering On

- Locate the On/Off switch on the underside of the mouse.
- Slide the switch to the "On" position. The mouse should now be ready for use.

OPERATING INSTRUCTIONS

Basic Functions

- **Left Click:** Press the left button to select items, open links, or activate functions.
- **Right Click:** Press the right button to open context menus or access additional options.
- **Scroll Wheel:** Roll the wheel up or down to scroll through documents or web pages. Press the scroll wheel for middle-click functionality (e.g., opening links in new tabs).

DPI Adjustment

The mouse features a DPI (Dots Per Inch) button, typically located behind the scroll wheel. Press this

button to cycle through different sensitivity settings. Each press will change the cursor speed, allowing you to find the optimal setting for your task.

- Press the **DPI button** once to switch to the next sensitivity level.
- Repeat until you find your preferred cursor speed.

Power Saving Mode

To conserve battery life, the BYTECH Wireless Optical Mouse is designed to automatically enter a sleep mode after a period of inactivity. To wake the mouse, simply move it or click any button.

MAINTENANCE

Cleaning

- Ensure the mouse is turned off before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Wipe the surface of the mouse gently. Avoid excessive moisture.
- For the optical sensor, use a dry cotton swab to carefully remove any dust or debris.
- Do not use abrasive cleaners, alcohol, or solvents, as these may damage the surface.

Battery Replacement

When the mouse performance degrades or the cursor becomes erratic, it may be time to replace the battery. Follow the battery installation steps outlined in the "Setup" section.

Storage

When not in use for an extended period, it is recommended to turn off the mouse to conserve battery life. The USB receiver can be stored in its dedicated slot on the mouse's underside to prevent loss.

TROUBLESHOOTING

- **Mouse not responding:**
 - Ensure the mouse is turned on.
 - Check the battery level and replace if necessary.
 - Verify the USB receiver is securely plugged into a working USB port. Try a different USB port.
 - Restart your computer.
- **Cursor erratic or jumping:**
 - Clean the optical sensor on the underside of the mouse.
 - Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent). A mouse pad is recommended.
 - Check for strong electromagnetic interference from other devices.
- **Connectivity issues:**
 - Reduce the distance between the mouse and the USB receiver.
 - Remove any large metal objects or electronic devices that might be obstructing the wireless signal.
 - If using a USB hub, try connecting the receiver directly to the computer.

SPECIFICATIONS

Feature	Detail
Brand	Bytech
Model	BYTECH Wireless Optical Mouse
Connectivity Technology	Wireless (USB Receiver)
Movement Detection Technology	Optical
Color	Black
Power Source	Battery Powered (1x AA, not included)
Operating System Compatibility	macOS, Android (and generally Windows)
Item Weight	3.56 ounces
Product Dimensions (LxWxH)	1 x 1 x 1 inches (Approximate)

Note: Specifications are subject to change without notice.

WARRANTY AND SUPPORT

Bytech products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your product or visit the official Bytech website. Keep your purchase receipt as proof of purchase for warranty claims. For further assistance, please contact Bytech customer support through their official channels.