

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Philips LED](#) /

› [Philips LED A19 Dimmable Warm Glow Light Bulb Instruction Manual \(Model 479444\)](#)

Philips LED 479444

Philips LED A19 Dimmable Warm Glow Light Bulb Instruction Manual

Model: 479444

INTRODUCTION

This manual provides essential information for the safe and effective use of your Philips LED A19 Dimmable Warm Glow Light Bulbs. These bulbs are designed to provide soft white light with a warm glow dimming effect, offering energy efficiency and a long lifespan. Please read this manual thoroughly before installation and retain it for future reference.



Image: A pack of six Philips LED A19 light bulbs, showcasing their frosted design and standard E26 base.

SAFETY INFORMATION

- **Risk of Electric Shock:** Always turn off power to the fixture before installing, removing, or inspecting the bulb.
- **Indoor Use Only:** These bulbs are designed for indoor use in dry locations. Do not use where directly exposed to water.
- **Operating Temperature:** Suitable for use in operating environments between -20°C (-4°F) and +45°C (+113°F).
- **Dimmer Compatibility:** These bulbs are dimmable. Ensure your dimmer switch is compatible with LED technology for optimal performance and to prevent flickering.
- **Not for Enclosed Fixtures:** Not recommended for use in fully enclosed fixtures as this may shorten bulb life.
- **Not for Emergency Exits:** Not intended for use with emergency exit fixtures or emergency lights.
- **Weight:** The added weight of the device may cause instability of a free-standing portable luminaire.

SETUP AND INSTALLATION

Follow these steps to properly install your Philips LED A19 light bulb:

1. **Turn Off Power:** Before replacing any light bulb, ensure the power to the light fixture is turned off at the switch and, if necessary, at the circuit breaker.
2. **Remove Old Bulb:** Carefully unscrew the existing light bulb from the fixture. Allow it to cool if it was recently in use.
3. **Inspect Fixture:** Check the fixture's socket for any damage or debris.
4. **Install New Bulb:** Gently screw the Philips LED A19 bulb into the E26 medium base socket until it is finger-tight. Do not overtighten.
5. **Restore Power:** Turn the power back on at the switch and circuit breaker.
6. **Test:** Turn on the light to ensure proper operation.



Image: A Philips LED A19 bulb with its dimensions (4.7 inches height, 2.5 inches width) and E26 medium base clearly labeled.

OPERATING INSTRUCTIONS

Your Philips LED A19 bulb features a Warm Glow dimming effect, which mimics the behavior of traditional incandescent bulbs by shifting to a warmer color temperature as it dims.

- **Standard Operation:** Simply turn the light switch on to illuminate the bulb at full brightness (2700K).
- **Dimming Function:** If connected to a compatible dimmer switch, adjust the dimmer control to achieve your desired light level. As you dim the bulb, the color temperature will gradually shift from 2700 Kelvin (soft white) to 2200 Kelvin (warm amber glow).
- **Flicker-Free Dimming:** These bulbs are designed for flicker-free and silent dimming with a wide range of dimmer switches.



Image: A living room scene demonstrating the warm, inviting glow provided by Philips LED bulbs when dimmed.

MAINTENANCE

Philips LED A19 bulbs require minimal maintenance.

- **Cleaning:** Ensure the power is off and the bulb is cool before cleaning. Wipe the bulb with a soft, dry cloth. Do not use liquid or abrasive cleaners.
- **Replacement:** These LED bulbs have a long lifespan (up to 15,000 hours). Replace the bulb when its light output significantly diminishes or it ceases to function.


TROUBLESHOOTING

Problem	Possible Cause	Solution
Bulb does not light up.	No power to the fixture, loose bulb, faulty bulb.	Check power switch and circuit breaker. Ensure bulb is screwed in tightly. Test bulb in another working fixture.
Bulb flickers or buzzes.	Incompatible dimmer switch, loose connection, electrical interference.	Ensure dimmer is LED-compatible. Tighten bulb. Consult an electrician if problem persists.
Dimming range is limited or inconsistent.	Incompatible dimmer switch.	Verify dimmer switch is designed for LED bulbs and supports the full dimming range.

SPECIFICATIONS

Feature	Detail
Brand	Philips LED
Model Name	479444
Bulb Shape Size	A19
Bulb Base	E26 Medium Base
Light Type	LED
Wattage	8.8 Watts (60W Incandescent Equivalent)

Feature	Detail
Brightness	800 Lumens
Color Temperature	2700K (Soft White) to 2200K (Warm Glow)
Voltage	120 Volts
Special Feature	Dimmable, Frosted, Warm Glow Effect
Average Life	15,000 Hours (approx. 13.7 years at 3 hrs/day)
Dimensions	2.48" W x 4.69" H
Material	Glass
Color Rendering Index (CRI)	80



You'll save \$83.33
in energy costs over the life of the lamp
without sacrificing light quality or brightness.

* LED Lifetime means the length of time (in hours) until half of the LED light sources maintain at least 70% of their initial lumen output (B50, L70).
** Rated Average Life means the average length of operation (in hours) at which point 50% of the lamps will be operational and 50% will not (B50).

Image: An infographic comparing Philips LED (9.5 Watts, 800 Lumens, 15,000 Hours Lifetime) with Standard Incandescent (60 Watts, 800 Lumens, 1,500 Hours Lifetime), highlighting energy savings.

WARRANTY INFORMATION

These Philips LED A19 bulbs come with a **5-year limited warranty**. This warranty covers defects in materials and workmanship under normal use. For warranty claims or further details, please refer to the packaging or contact Philips customer support.

CUSTOMER SUPPORT

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact Philips customer support:

- **Website:** Visit the official Philips Lighting website for support resources and contact information.
- **Phone:** Refer to your product packaging for regional customer service phone numbers.