

[manuals.plus](#) /

- › [Amazon Basics](#) /
- › [Amazon Basics 1800W Ceramic Heater with Adjustable Thermostat - Silver \(Model DQ075SILVER-EU4\) Instruction Manual](#)

Amazon Basics DQ075SILVER-EU4

Amazon Basics 1800W Ceramic Heater with Adjustable Thermostat - Silver (Model DQ075SILVER-EU4) Instruction Manual

Model: DQ075SILVER-EU4 | Brand: Amazon Basics

INTRODUCTION

This instruction manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your Amazon Basics 1800W Ceramic Heater. Please read this manual thoroughly before using the product and retain it for future reference.



Figure 1: Amazon Basics 1800W Ceramic Heater (Silver)

IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, always follow these basic precautions:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.

- Always use the handle when moving this heater.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors. This heater is intended for indoor use only.
- This heater is not intended for use in bathrooms, laundry areas, or similar indoor locations with high humidity. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has an automatic shut-off safety switch and overheat protection. If the heater tips over or overheats, it will automatically turn off. Unplug the unit and allow it to cool down before restarting.
- The heater is ETL certified, ensuring compliance with safety standards.

Uso sicuro e affidabile



Termostato regolabile
con 3 impostazioni: bassa, alta
e solo ventilatore per la circolazione
dell'aria



Certificato TUV con protezione
antiribaltamento e spegnimento
automatico



Indicatore luminoso di alimentazione

Figure 2: Safety and Reliable Features - Adjustable thermostat, automatic shut-off for tip-over and overheating, and power indicator.

Stabile e sicuro

Include un interruttore di protezione in caso di ribaltamento nella sua base per una maggiore sicurezza dell'utente



Figure 3: Stable and Secure Design - Includes a tip-over protection switch on its base for enhanced user safety.

SETUP

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for storage or return if necessary.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 m) of clear space around the heater from any combustible materials.
3. **Power Connection:** Plug the heater directly into a 120V wall outlet. Do not use extension cords or power strips.



Ideale per ambienti fino a 10-15m²

Figure 4: Optimal Room Size - Ideal for heating areas up to 10-15 square meters.

OPERATING INSTRUCTIONS

The heater features two control knobs on the top for power settings and thermostat adjustment.

Modo d'uso

1

Per iniziare, impostare il termostato su HIGH (Alto)

2

Il riscaldatore manterrà un calore costante in base all'impostazione del termostato (Fan, Low, High Heat)

3

Certificato ETL con spegnimento automatico in caso di surriscaldamento; scollegare e riavviare una volta raffreddato



Figure 5: Control Panel - Power and Thermostat Knobs

Power Settings:

- **OFF:** Turns the heater off.
- **FAN ONLY:** Activates the fan without heat, useful for air circulation.
- **LOW HEAT:** Provides a lower heat output (e.g., 750W).
- **HIGH HEAT:** Provides the maximum heat output (1800W).

Thermostat Adjustment:

1. Turn the thermostat knob clockwise to increase the desired temperature.
2. Turn the thermostat knob counter-clockwise to decrease the desired temperature.
3. The heater will cycle on and off to maintain the set temperature.

A power indicator light will illuminate when the heater is connected to power and operating.



Figure 6: Heater in Operation - Compact and portable for various indoor settings.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:**

- Always unplug the heater from the wall outlet before cleaning.
- Allow the heater to cool down completely.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater.
- Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to clean dust from the air intake and exhaust grilles.
- Ensure no water or other liquids enter the interior of the heater.

- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in. Power outlet not functioning. Tip-over switch activated. Overheat protection activated.	Ensure the power cord is securely plugged into a 120V outlet. Check the circuit breaker or try a different outlet. Ensure the heater is on a flat, stable surface. If it tipped, stand it upright and wait a few minutes before restarting. Unplug the heater, allow it to cool for 10-15 minutes, then plug it back in.
Heater produces no heat.	Set to "FAN ONLY" mode. Thermostat set too low.	Turn the power setting knob to "LOW HEAT" or "HIGH HEAT". Increase the thermostat setting by turning the knob clockwise.
Heater cycles on and off frequently.	Thermostat set too close to room temperature. Air intake/exhaust blocked.	Adjust the thermostat to a higher setting if more heat is desired. Ensure there are no obstructions blocking the air vents.

SPECIFICATIONS

Brand	Amazon Basics
Model	DQ075SILVER-EU4
Color	Silver
Dimensions (L x W x H)	19.02 x 15.01 x 24 cm (7.5 x 5.9 x 9.4 inches)
Weight	1.3 kg (2.87 lbs)
Wattage	1800 Watts
Voltage	120 Volts
Material	Ceramic
Speed Settings	3 (Fan Only, Low Heat, High Heat)
Safety Features	Overheat Protection, Tip-Over Safety Switch, ETL Certified
Intended Use	Indoor only

WARRANTY INFORMATION

Amazon Basics products are covered by a limited warranty. For detailed warranty terms and conditions, please refer to the official Amazon Basics website or contact customer support. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT





For any questions, assistance, or troubleshooting not covered in this manual, please contact Amazon Basics customer



support through the Amazon website where you purchased the product. You can typically find support contact information in your order details or on the Amazon Basics brand page.

Online Support: Visit [Amazon Customer Service](#)



Related Documents - DQ075SILVER-EU4

<div><div>amazon basics</div><div></div><div><div>Ceramic Space Heater with Adjustable Thermostat</div><div>Chauffage d'espace à thermostat réglable</div><div>Keramische Raumheizung mit einstellbarem Thermostat</div><div>Stufa elettrica in Ceramica con Termostato Regolabile</div><div>Grzejnik ceramiczny Cu Termostatem Regulacyjnym</div><div>Keramiische raumhoerverwarming met instelbare thermostat</div><div>Grzejnik ceramiczny z regulowanym termostatem</div><div>Keramični ogrevalni aparat s nastavljivo termostatom</div></div><div><div>B073V6M4MSN, B073V6M3PDX</div><div><div>EN</div><div>Page 2</div><div>15</div><div>Page 39</div></div><div><div>FR</div><div>Page 12</div><div>46</div><div>Page 47</div></div><div><div>DE</div><div>Seite 21</div><div>46</div><div>Seite 55</div></div><div><div>IT</div><div>Page 31</div><div>46</div><div>Indice 64</div></div></div></div>	<div><div>Amazon Basics Ceramic Space Heater with Adjustable Thermostat - User Manual & Safety Guide</div><div>User manual for the Amazon Basics Ceramic Space Heater with Adjustable Thermostat (1800W). Contains safety instructions, operating guidelines, specifications, and troubleshooting for household use in dry indoor areas.</div></div>
<div><div>amazon basics</div><div></div><div><div>1500-Watt Ceramic Personal Heater with Adjustable Thermostat</div><div>Radiateur personnel en céramique de 1500 W avec thermostat réglable</div><div>Grzejnik osobisty ceramiczny o 1500 W z termostatem regulacyjnym</div><div>B07V6M4MSN, B07V6M3PDX</div></div><div><div>EN</div><div>Page 2</div><div>15</div><div>Page 18</div></div></div>	<div><div>Amazon Basics 1500W Ceramic Personal Heater User Manual Safety, Operation, Troubleshooting</div><div>Comprehensive user manual for the Amazon Basics 1500W Ceramic Personal Heater with Adjustable Thermostat. Includes detailed safety instructions, operating guide, cleaning, storage, maintenance, troubleshooting, and specifications for models B07V6M4MSN and B07V6M3PDX.</div></div>
<div><div>amazon basics</div><div></div><div><div>500-Watt Personal Ceramic Heater</div><div>Chauffe-personnel en céramique de 500 Watts</div><div>Appareil De Chauffage Céramique Mobile 500 W</div><div>B074MW25S5, B074MXC3PN, B074MR2C61, B074MX8VN5</div></div><div><div>EN</div><div>Page 2</div><div>15</div><div>Page 11</div></div><div><div>FR</div><div>Page 6</div><div></div><div></div></div></div>	<div><div>Amazon Basics 500-Watt Personal Ceramic Heater User Manual</div><div>User manual for the Amazon Basics 500-Watt Personal Ceramic Heater, including intended use, operation, safety instructions, specifications, and troubleshooting. Model numbers: B074MW25S5, B074MXC3PN, B074MR2C61, B074MX8VN5.</div></div>
<div><div>amazon basics</div><div></div><div><div>1500-Watt Ceramic Space Heater with Adjustable Thermostat</div><div>Chauffage d'espace en céramique de 1500 Watts avec thermostat réglable</div><div>Grzejnik ceramiczny o 1500 W z termostatem regulacyjnym</div><div>B073V6M4MSN, B073V6M3PDX</div></div><div><div>EN</div><div>Page 2</div><div>15</div><div>Page 18</div></div></div>	<div><div>AmazonBasics 1500-Watt Ceramic Space Heater with Adjustable Thermostat - User Manual</div><div>User manual and safety instructions for the AmazonBasics 1500-Watt Ceramic Space Heater with Adjustable Thermostat. Learn about operation, maintenance, troubleshooting, and specifications.</div></div>

<div data-bbox="129 100 189 116" data-label="Page-Header"><p>amazon basics</p></div> <div data-bbox="185 132 236 273" data-label="Image"></div> <div data-bbox="129 286 242 324" data-label="Caption"><p>Digital Tower Heater, 28" Colonne de Chauffage Numérique, 28 po Chauffeur de Pile Digital, 28 po/piedes B08PQK8P75, B08PQK8P75</p></div> <div data-bbox="129 331 300 349" data-label="Page-Footer"><p>Page 2 Page 21</p></div>	<div data-bbox="341 174 957 208" data-label="Section-Header"><p>Amazon Basics Digital Tower Heater 28" User Manual</p></div> <div data-bbox="341 217 1377 288" data-label="Text"><p>User manual for the Amazon Basics 28-inch Digital Tower Heater, providing instructions on operation, safety, cleaning, and troubleshooting. Includes specifications and FAQs.</p></div>
<div data-bbox="129 416 189 432" data-label="Page-Header"><p>amazon basics</p></div> <div data-bbox="185 448 236 589" data-label="Image"></div> <div data-bbox="129 602 242 640" data-label="Caption"><p>Digital Tower Heater, 23" Colonne de Chauffage Numérique, 23 po Chauffeur de Pile Digital, 23 po/piedes B08PQK8P75, B08PQK8P75</p></div> <div data-bbox="129 647 300 665" data-label="Page-Footer"><p>Page 2 Page 21</p></div>	<div data-bbox="341 470 957 504" data-label="Section-Header"><p>Amazon Basics 23" Digital Tower Heater User Manual</p></div> <div data-bbox="341 512 1425 624" data-label="Text"><p>Comprehensive user manual for the Amazon Basics 23" Digital Tower Heater (Model DQ1535). Includes safety instructions, operation guide, specifications, cleaning, maintenance, and troubleshooting tips.</p></div>