

[Manuals.plus](#) /

› [Aigostar](#) /

› Aigostar Electric Kettle User Manual

## Aigostar Aigostar 1.7L

# Aigostar Electric Kettle User Manual

Model: Aigostar 1.7L

Brand: Aigostar

## INTRODUCTION

---

Thank you for choosing the Aigostar Electric Kettle. This 1.7L electric kettle is designed for fast and efficient water boiling, featuring LED illumination, automatic shut-off, and boil-dry protection for safe and convenient use. Its stainless steel construction ensures durability and a healthy brewing experience. Please read this manual carefully before use to ensure proper operation and maintenance.



Image: The Aigostar 1.7L Electric Kettle, showcasing its sleek stainless steel design and illuminated water level indicator.

## IMPORTANT SAFETY INFORMATION

**Please read and understand all safety instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.**

- Do not immerse the kettle, power base, cord, or plug in water or any other liquid.
- Ensure the kettle is placed on a firm, flat, heat-resistant surface away from the edge of the countertop.

- Do not operate the kettle if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.
- Keep the appliance out of reach of children and pets.
- Always ensure the lid is securely closed before operating the kettle.
- Do not open the lid while water is boiling or immediately after, as hot steam can cause burns.
- The kettle features an automatic shut-off function when water boils and boil-dry protection. Do not attempt to override these safety features.
- The handle is designed to stay cool to the touch, but caution should still be exercised when handling the hot kettle.
- Only use the kettle with its supplied power base.

## PRODUCT OVERVIEW

Familiarize yourself with the components of your Aigostar Electric Kettle:



Image: An illustrative diagram highlighting the various parts of the Aigostar Electric Kettle, including the lid, spout, filter, lid release button, power switch, stay-cool handle, LED lights, water level gauge, 360° swivel base, and cord storage.

- **Kettle Body:** Made of premium 304 stainless steel.
- **Lid:** Securely covers the kettle opening.
- **Lid Release Button:** Located on the handle for easy opening.
- **Spout:** Designed for drip-free pouring.
- **Detachable Filter:** Located behind the spout, helps filter out scale.
- **Water Level Gauge:** Clear window with MIN (0.5L) and MAX (1.7L) markings.
- **LED Illumination:** Lights up when the kettle is heating.
- **Power Switch:** Located on the handle to turn the kettle on/off.
- **Stay-Cool Handle:** Ergonomically designed for comfortable and safe grip.
- **360° Swivel Base:** Allows the kettle to be placed on the base from any angle.
- **Cord Storage:** Located under the power base for neat storage.

## Detachable Mesh Filter

Filtrates calcium and lime out of water, easy to clean



## Heat Resistant Handle

Offers a comfortable and secure grip



## Clear Water Level Gauge

Gives you an idea of how full the jug is



Image: Detailed view of the kettle's features, including the detachable mesh filter for water purity, the heat-resistant handle for safe handling, and the clear water level gauge for accurate filling.

## 360-Degree Cordless Base



## Convenient Cord Storage Power Cable Length Approx 30 inch

Image: The 360-degree cordless base, illustrating its rotational capability and the integrated cord storage for convenience and tidiness.

## SETUP

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain the packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe the exterior of the kettle with a damp cloth.
3. **First Boil:** Fill the kettle with water to the MAX line (1.7L). Boil the water and then discard it. Repeat this process 2-3 times to remove any manufacturing residues and ensure optimal taste.
4. **Placement:** Place the power base on a stable, flat, and dry surface. Ensure the power cord is not dangling where it could be tripped over.

## OPERATING INSTRUCTIONS

1. **Fill the Kettle:** Press the lid release button to open the lid. Fill the kettle with the desired amount of water, ensuring it is between the MIN (0.5L) and MAX (1.7L) marks on the water level gauge. Do not overfill or

underfill.

2. **Close the Lid:** Close the lid firmly until it clicks into place.
3. **Place on Base:** Place the kettle securely onto the 360° swivel power base.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.
5. **Start Boiling:** Press the power switch down to the 'ON' position. The LED illumination will light up, indicating that the kettle is heating.
6. **Automatic Shut-off:** The kettle will automatically switch off once the water has reached a rolling boil. The LED illumination will turn off.
7. **Pouring:** Carefully lift the kettle from its base and pour the hot water. The handle is designed to remain cool.
8. **Re-boiling:** If you need to re-boil water, wait a few moments for the internal thermostat to reset before pressing the power switch again.




Free of BPA



Boil water  
quicker



Boil dry  
protection



Overheating  
protection



Image: Visual representation of key safety and performance features: BPA-free materials, rapid boiling capability, boil-dry protection, and overheating protection.

## MAINTENANCE

---

Regular cleaning and descaling will prolong the life of your kettle and ensure optimal performance.

### Cleaning the Exterior

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the stainless steel finish.
- Ensure the power base and cord remain dry.

### Cleaning the Interior and Filter

- The interior of the kettle can be cleaned with a soft brush or sponge and mild dish soap. Rinse thoroughly with clean water.
- The detachable filter can be removed for cleaning. Rinse it under running water and use a soft brush if necessary to remove any deposits. Reinsert the filter securely after cleaning.

### Descaling

Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. This can affect performance and taste. Descale your kettle regularly.

# How to remove scale?



1. Have deposits or "rust" on your kettle



2. Pour Citric acid or vinegar and water



3. Boil water



4. Now you can see your kettle becomes clean

Image: A four-step guide demonstrating how to remove limescale from the kettle: 1. Identify deposits, 2. Pour citric acid or vinegar and water, 3. Boil the solution, 4. Observe the clean kettle interior.

1. Fill the kettle with 1 part white vinegar and 2 parts water (or use a commercial descaling solution according to its instructions).
2. Bring the mixture to a boil.
3. Allow the solution to soak in the kettle for at least 30 minutes, or longer for heavy deposits.
4. Pour out the solution and rinse the kettle thoroughly several times with fresh water to remove any vinegar smell or residue.
5. For stubborn deposits, you may need to repeat the process.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power switch not engaged; kettle not properly seated on base.	Ensure plug is securely in outlet; press power switch down firmly; ensure kettle is correctly placed on the power base.

Problem	Possible Cause	Solution
Water is not boiling.	Kettle not turned on; insufficient water.	Check power switch; ensure water level is above MIN mark.
Kettle does not shut off automatically.	Limescale buildup; faulty thermostat.	Descale the kettle as per maintenance instructions. If the problem persists after descaling, discontinue use and contact customer support.
Metallic taste or smell in water.	New kettle residue; limescale buildup.	Perform initial cleaning and boil-and-discard steps multiple times. Regularly descale the kettle.
Kettle leaks.	Lid not closed properly; overfilling.	Ensure lid is securely closed; do not fill above the MAX line. If leaking persists, discontinue use.

## SPECIFICATIONS

Feature	Detail
Brand	Aigostar
Model Number	Aigostar 1.7L
Capacity	1.7 Liters
Power	1100W
Material	304 Food-Grade Stainless Steel, BPA Free
Color	Silver
Product Dimensions	8.8"L x 6"W x 9.62"H
Item Weight	2.38 Pounds
Special Features	Automatic Shut-Off, Boil Dry Protection, LED Illumination, 360° Swivel Base, Cord Storage
UPC	718356204903



Image: A visual representation of the kettle's dimensions, indicating its length, width, and height for reference.

## WARRANTY AND SUPPORT

Aigostar products are manufactured to high-quality standards. For any issues or inquiries regarding your electric kettle, please contact Aigostar customer support. Please refer to your purchase documentation for specific warranty terms and conditions.

For more information or to explore other Aigostar products, visit the official Aigostar store [Aigostar Store on Amazon](#).

