

Uten EHA701

Uten Digital Kitchen Scale EHA701 User Manual

Model: EHA701

1. INTRODUCTION

The Uten Digital Kitchen Scale EHA701 is a high-precision, multi-functional weighing instrument designed for various kitchen tasks, including cooking, baking, and portion control. Equipped with advanced sensor technology, it provides accurate measurements for both solid ingredients and liquids. Its sleek design and user-friendly features make it an essential tool for any modern kitchen.

Key Features:

- **High Precision:** Measures with an accuracy of 1g, ideal for spices and diet control.
- **Multi-Unit Conversion:** Easily switch between g, kg, ml, fl'oz, lb, oz.
- **Liquid Volume Measurement:** Dedicated functions for water and milk volume.
- **Tare Function:** Zero out the weight of containers for accurate ingredient measurement.
- **Easy-to-Read LCD:** Backlit display ensures clear visibility in various lighting conditions.
- **Durable and Easy to Clean:** Tempered glass panel for longevity and simple maintenance.
- **Automatic Shut-off:** Conserves battery life by turning off after 2 minutes of inactivity.
- **Overload and Low Battery Indicators:** Alerts for optimal performance and safety.

Easy to clean

Smooth glass surface is easy to clean



Image 1: The Uten Digital Kitchen Scale highlighting its precision with a digital display showing weight and unit options.

2. SETUP

2.1 Unpacking and Initial Inspection

Carefully remove the scale from its packaging. Inspect the scale for any signs of damage. Ensure all components are present.

2.2 Battery Installation

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert one CR2032 battery, ensuring the correct polarity (+/-).
4. Close the battery compartment cover securely.

2.3 Placement

Place the scale on a hard, flat, and stable surface to ensure accurate readings. Avoid placing it on soft or uneven surfaces, which can affect precision.

Minimalist Design

Three buttons bring more functions



Image 2: The underside of the scale, illustrating the battery compartment and unit conversion button.

3. OPERATING INSTRUCTIONS

3.1 Power On/Off

- To power on, press the **ZERO** button. The LCD will light up and display "0g".
- The scale features an automatic shut-off function after approximately 2 minutes of inactivity to conserve battery life.

3.2 Unit Conversion

Press the **MODE** button to cycle through the available units: grams (g), kilograms (kg), milliliters (ml), fluid ounces (fl'oz), pounds (lb), and ounces (oz).

3.3 Tare Function

The tare function allows you to weigh ingredients in a container by subtracting the container's weight.

1. Place an empty container on the scale.
2. Press the **ZERO/TARE** button. The display will reset to "0".
3. Add your ingredients to the container. The display will show only the weight of the ingredients.




Image 3: Visual guide on how to use the tare function, showing an empty plate being zeroed out before adding ingredients.

3.4 Liquid Volume Measurement

The scale includes specific modes for measuring water and milk volume.

- After selecting 'ml' or 'fl'oz' using the **MODE** button, the scale can differentiate between water and milk for more accurate volume readings.
- Use the **MODE** button to toggle between water volume mode and milk volume mode if available.



Image 4: The scale's multifunction display, illustrating the different modes for weight, water volume, and milk volume.

3.5 Maximum Weight Capacity

The maximum weight capacity of this scale is 8000 grams (8 kg or 17.6 lb). Do not exceed this limit to prevent damage to the scale.

4. MAINTENANCE

4.1 Cleaning

The tempered glass surface of the Uten Digital Kitchen Scale is designed for easy cleaning.

- Wipe the scale surface with a damp cloth immediately after use, especially if spills occur.
- For stubborn stains, use a mild detergent on the damp cloth.
- Do not immerse the scale in water or use abrasive cleaners, as this can damage the electronic components.
- Ensure the scale is completely dry before storage or next use.



Multifunction



Image 5: Demonstrating the ease of cleaning the scale's smooth glass surface.

4.2 Storage

Store the scale in a cool, dry place away from extreme temperatures and humidity. Avoid placing heavy objects on the scale when not in use.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
"Lo" or Low Battery Indicator	Battery is low.	Replace the CR2032 battery.
"O-Ld" or Overload Indicator	Weight on the scale exceeds the maximum capacity (8kg).	Remove some weight immediately to prevent damage.

Problem	Possible Cause	Solution
Inaccurate Readings	<ul style="list-style-type: none"> Scale is on an uneven surface. Scale is dirty or has debris underneath. External vibrations or air currents. 	<ul style="list-style-type: none"> Place the scale on a hard, flat, and stable surface. Clean the scale and ensure no debris is affecting the sensors. Ensure the environment is stable during weighing.
Scale Does Not Turn On	<ul style="list-style-type: none"> Battery is dead or incorrectly installed. Scale is damaged. 	<ul style="list-style-type: none"> Check battery polarity or replace the battery. If still not working, contact customer support.

6. SPECIFICATIONS

Feature	Detail
Model Number	EHA701
Brand	Uten
Maximum Weight Capacity	8000 Grams (8 kg / 17.6 lb)
Minimum Measurement	1 gram
Units of Measurement	g, kg, ml, fl'oz, lb, oz
Display Type	Backlit LCD
Power Source	1 x CR2032 battery
Material	Tempered Glass
Dimensions (L x W x H)	23 x 17 x 1.5 cm (9.1 x 6.7 x 0.6 inches)
Item Weight	525 Grams
Special Features	Automatic Shut-off, Tare Function, Low Battery Indicator, Overload Indicator
Recommended Uses	Kitchen, Baking, Liquid Measurement

More Precise

Accurate to 1g/0.1oz

Weigh up to 8kg/17.6lb



Digital display



Image 6: Overview of the Uten Digital Kitchen Scale highlighting its main features and specifications.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's return policy or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Uten

For further assistance, please visit the official Uten website or contact their customer service department.