

Intex Quick Fill Rechargeable Electric Pump Model 66642 Instruction Manual

Brand: Intex | Model: 66642

1. SAFETY INFORMATION

Please read all instructions carefully before using this electric pump. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Warning:** Not suitable for children under 36 months. Small parts and/or detachable small parts included may be swallowed. Choking hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not operate the pump in wet conditions or immerse it in water.
- Never point the inflation/deflation port towards your face or body when operating.
- Do not block the air intake or outlet during operation.
- Use only the provided charging cable and nozzles.
- Disconnect the pump from the power source before cleaning or servicing.
- Do not attempt to disassemble or repair the pump yourself. Contact qualified service personnel.

2. PRODUCT OVERVIEW

The Intex Quick Fill Rechargeable Electric Pump is designed for efficient inflation and deflation of various inflatable items. It features a robust design, multiple nozzle attachments, and a rechargeable battery for convenient use both indoors and outdoors.

Key Features:

- Equipped with 3 different nozzles for versatile use.
- Capable of both inflation and deflation.
- Suitable for both indoor and outdoor applications.
- Features a 12V connection, for example, for a car cigarette lighter adapter (check packaging for inclusion).

- AC power adapter allows for home charging.
- Automatic charge stop for enhanced safety.



Image 1: Intex Quick Fill Rechargeable Electric Pump with various nozzle attachments and charging cable.

3. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- Intex Quick Fill Rechargeable Electric Pump (Model 66642)
- 3 Interconnecting Nozzles
- 220V AC Power Adapter (for charging)
- 12V DC Car Charger Adapter (if included with your specific model, check packaging)



Image 2: The electric pump, three nozzle attachments, and the charging cable.

4. SETUP

4.1. Charging the Pump

Before first use, fully charge the pump's internal battery. The pump is designed with an automatic charge stop feature for safety.

1. Locate the charging port on the pump.
2. Connect the 220V AC power adapter to the pump's charging port.
3. Plug the AC power adapter into a standard 220V wall outlet.
4. Allow the pump to charge until the charging indicator light (if present) indicates a full charge, or for the recommended duration specified in the packaging.
5. Alternatively, if your model includes a 12V DC car charger, you can charge the pump using a vehicle's cigarette lighter socket.



Image 3: Detail of the charging port on the pump.

4.2. Attaching Nozzles

Select the appropriate nozzle for the valve of the item you wish to inflate or deflate. The pump comes with three interconnecting nozzles to fit most common valve sizes.

- Identify the valve size on your inflatable item.
- Choose the nozzle that best fits the valve opening.
- Firmly insert the chosen nozzle into the inflation or deflation port of the pump.

5. OPERATING INSTRUCTIONS

5.1. Inflation

1. Ensure the pump is charged.
2. Select the correct nozzle and attach it to the **inflation port** (usually marked with an arrow pointing outwards) of the pump.
3. Insert the nozzle firmly into the valve of the item to be inflated.
4. Turn on the pump using the power switch.

5. Inflate the item to the desired firmness. **Do not overinflate.**
6. Turn off the pump and remove the nozzle from the valve.



Image 4: Demonstrating the inflation process of an air mattress using the electric pump.

5.2. Deflation

The pump can also be used to quickly deflate items, making packing and storage easier.

1. Select the correct nozzle and attach it to the **deflation port** (usually marked with an arrow pointing inwards) of the pump.
2. Insert the nozzle firmly into the valve of the item to be deflated.
3. Turn on the pump using the power switch.
4. Allow the pump to extract air until the item is fully deflated.
5. Turn off the pump and remove the nozzle from the valve.



Image 5: Illustrating the deflation process of an air mattress using the electric pump.

6. MAINTENANCE

- Cleaning:** Wipe the pump's exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the pump is completely dry before storage or next use.
- Storage:** Store the pump and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Keep out of reach of children.
- Battery Care:** For optimal battery life, charge the pump fully before storing for extended periods and recharge every few months if not in use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Pump does not turn on.	Battery is depleted.	Charge the pump fully using the provided AC adapter.
Pump has low airflow.	Incorrect nozzle size or blocked air intake/outlet.	Ensure the correct nozzle is used and firmly attached. Check for any obstructions in the air intake or outlet.

Problem	Possible Cause	Solution
Item inflates slowly.	Nozzle not properly sealed to the valve.	Ensure a tight seal between the nozzle and the item's valve.
Pump overheats.	Continuous operation for too long.	Turn off the pump and allow it to cool down for at least 15-20 minutes before resuming use.

8. SPECIFICATIONS

Brand	Intex
Model Number	66642
Power Source	Rechargeable Electric (220V AC adapter)
Voltage	220 Volts
Air Flow Capacity	650 Liters per minute
Material	Plastic (PVC)
Item Weight	800 Grams
Product Dimensions (L x W x H)	12.4 cm x 14.3 cm x 19.4 cm
Nozzles Included	3

9. WARRANTY AND SUPPORT

For warranty information, technical support, or replacement parts, please refer to the warranty card included with your product or contact Intex customer service directly. Keep your purchase receipt as proof of purchase.

Contact Information: Please visit the official Intex website for the most up-to-date contact details for your region.

Related Documents - 66642

	<p>INTEX Quick-Fill Electric Air Pump AP639 Owner's Manual and Instructions</p> <p>Official owner's manual for the INTEX Quick-Fill Electric Air Pump, Model AP639. Provides safety warnings, operating instructions for inflation and deflation, maintenance, and storage guidelines.</p>
	<p>INTEX Owner's Manual: Built-in Fast-Fill™ Electric Pump Model AP619A</p> <p>Comprehensive owner's manual for the INTEX Built-in Fast-Fill™ Electric Pump Model AP619A, providing essential safety instructions, operating procedures for inflation and deflation, important notes on airbed care, and storage guidelines. Learn how to properly use and maintain your INTEX airbed pump.</p>

 <p>OWNER'S MANUAL</p>	<p>Intex Auto Pool Cleaner Owner's Manual and Setup Guide</p> <p>Comprehensive owner's manual for the Intex Auto Pool Cleaner. Includes setup instructions, parts reference, cleaning guides, troubleshooting tips, and safety information for maintaining your pool cleaner.</p>
 <p>INTEX</p>	<p>Intex Frame Pool Set Family User Manual - Models 260x160x65cm and Others</p> <p>Comprehensive user manual for Intex Frame Pool Set Family models, including setup instructions, maintenance guidelines, troubleshooting tips, and warranty information for safe and enjoyable pool use.</p>
 <p>OWNER'S MANUAL</p>	<p>Intex Electric Pool Heater HT30221-2 Owner's Manual</p> <p>This owner's manual provides essential safety rules, setup instructions, operating procedures, troubleshooting guide, and warranty information for the Intex HT30221-2 Electric Pool Heater. Learn how to safely install, operate, and maintain your pool heater for optimal performance.</p>
	<p>INTEX AP619A Fast-Fill Electric Air Pump Owner's Manual & Safety Guide</p> <p>Comprehensive owner's manual for the INTEX AP619A Fast-Fill Electric Air Pump, detailing important safety instructions, operating procedures for inflation and deflation, maintenance, and storage.</p>