

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JUKSTG](#) /

> [JUKSTG UKT20301 Wireless Mouse User Manual](#)

## JUKSTG UKT20301

# JUKSTG UKT20301 Wireless Mouse User Manual

Model: UKT20301

## INTRODUCTION

---

Thank you for choosing the JUKSTG Wireless Mouse. This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly before use.

### Key Features:

- **Ergonomic Design:** Slim and comfortable design with a frosted surface for an improved user experience.
- **Plug-and-Play Wireless:** Reliable 2.4GHz wireless connection via a nano receiver. Features smart sleep mode for battery conservation.
- **Durability:** Built for longevity with a 5,000,000 click lifespan. Offers a working distance of up to 10 meters. The USB Nano Receiver can be stored within the mouse.
- **Portability:** Compact dimensions (11.5 x 6.4 x 3.4 cm) make it ideal for travel and easy storage in a backpack or pocket.
- **Wide Compatibility:** Compatible with Windows 98/Me/2000/XP/Vista/Win 7/Win8/10 and Mac OS.

## PACKAGE CONTENTS

---

Please verify that all items are present in your package:

- 1 x JUKSTG Wireless Mouse
- 1 x USB Nano Receiver
- *Note: 1 AA battery is required and not included in the package.*

## PRODUCT OVERVIEW

---

Familiarize yourself with the components of your JUKSTG Wireless Mouse:

- **Left Click Button:** Standard primary function.
- **Right Click Button:** Standard secondary function.
- **Scroll Wheel:** For vertical scrolling and middle-click function.

- **DPI Adjustment Button:** Located below the scroll wheel, used to change cursor sensitivity.
- **Forward/Backward Buttons:** Located on the side for navigation (e.g., web browsing).
- **USB Nano Receiver Storage:** Compartment on the underside of the mouse for secure storage.
- **Battery Compartment:** Located on the underside for inserting the AA battery.
- **Power ON/OFF Switch:** Located on the underside to conserve battery life.



Wireless range can be up to 10 meters without interference




Figure 1: JUKSTG Wireless Mouse showcasing its ergonomic and symmetric design for comfortable use.

# STRONG DURABILITY

Tested over 5 million keystrokes



Figure 2: Illustration of the mouse's strong durability, tested for over 5 million keystrokes.

## SETUP

---

Follow these steps to set up your JUKSTG Wireless Mouse:

1. **Insert Battery:** Open the battery compartment on the underside of the mouse. Insert one AA battery, ensuring correct polarity (+/-).
2. **Retrieve USB Receiver:** Locate and remove the USB Nano Receiver from its storage slot next to the battery compartment.
3. **Connect Receiver:** Plug the USB Nano Receiver into an available USB port on your computer (PC or laptop). Your operating system should automatically detect and install the necessary drivers.
4. **Power On:** Slide the ON/OFF switch on the underside of the mouse to the 'ON' position.
5. **Test Functionality:** Move the mouse to confirm cursor movement on your screen.

# LOW POWER CONSUMPTION

Be in sleep mode in 10 mins of inactivity



Figure 3: Underside of the JUKSTG Wireless Mouse, showing the battery compartment, ON/OFF switch, and USB Nano Receiver storage.



Figure 4: Demonstrates the 2.4G wireless transmission technology, providing a stable connection up to 10 meters.

## OPERATING INSTRUCTIONS

---

### Basic Operation:

Use the left and right click buttons for primary and secondary functions, and the scroll wheel for navigation. The side buttons can be used for forward and backward actions in web browsers or file explorers.

### DPI Adjustment:

The mouse features 3 adjustable DPI (Dots Per Inch) levels to control cursor sensitivity and speed. To change the DPI, press the DPI button located just below the scroll wheel. Each press cycles through the available DPI settings:

- **800 DPI:** Slower cursor movement, suitable for precise tasks.
- **1200 DPI:** Standard cursor movement, balanced for general use.
- **1600 DPI:** Faster cursor movement, ideal for quick navigation or larger screens.

# 3 Adjustable DPI Levels

*Click the DPI-Control Button to change the moving speed freely*




Figure 5: Visual representation of the 3 adjustable DPI levels (800, 1200, 1600) and the DPI control button.

## Power Saving Mode:

To conserve battery life, the mouse will automatically enter sleep mode after 10 minutes of inactivity. To wake the mouse, simply click any button.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device. Do not use harsh chemicals or abrasive cleaners.
- **Battery Replacement:** When the mouse performance degrades or stops responding, replace the AA battery. Ensure the mouse is switched off before replacing the battery. Dispose of used batteries responsibly.
- **Storage:** When not in use for extended periods, switch off the mouse and store the USB Nano Receiver in its dedicated slot to prevent loss.

## TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Mouse not responding or cursor not moving.	<ol style="list-style-type: none"> <li>1. Ensure the mouse is switched ON.</li> <li>2. Check if the AA battery is inserted correctly and has sufficient charge. Replace if necessary.</li> <li>3. Ensure the USB Nano Receiver is securely plugged into a working USB port on your computer. Try a different USB port.</li> <li>4. Restart your computer.</li> </ol>
Cursor movement is erratic or lagging.	<ol style="list-style-type: none"> <li>1. Ensure the mouse is within the 10-meter wireless range of the receiver.</li> <li>2. Remove any objects that might be causing interference between the mouse and the receiver (e.g., large metal objects).</li> <li>3. Try using the mouse on a different surface.</li> <li>4. Replace the battery.</li> </ol>
DPI button does not change sensitivity.	<ol style="list-style-type: none"> <li>1. Ensure the mouse is powered on and connected.</li> <li>2. Press the DPI button firmly.</li> </ol>

## SPECIFICATIONS

Feature	Detail
Brand	JUKSTG
Model Number	UKT20301
Connectivity Technology	2.4G Wireless, USB Nano Receiver
Number of Buttons	6
Adjustable DPI Levels	800, 1200, 1600
Dimensions (LxWxH)	11.5 x 6.4 x 3.4 cm
Item Weight	59 g
Power Source	1 x AA Battery (not included)
Battery Average Life	Up to 12 Months
Wireless Range	Up to 10 meters
Durability	5,000,000 Clicks Lifespan
Compatible Operating Systems	Windows 98/Me/2000/XP/Vista/Win 7/Win8/10, Mac OS
Hardware Platform	Laptop, Personal Computer

