

Manuals.plus /

- › ALEKO /
- › ALEKO Inflatable Hot Tub Spa User Manual

## ALEKO HTIR4GRW

# ALEKO Inflatable Hot Tub Spa User Manual

Model: HTIR4GRW | Brand: ALEKO

## 1. INTRODUCTION

---

Thank you for choosing the ALEKO Inflatable Hot Tub Spa. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new hot tub. Please read this manual thoroughly before setup and use to ensure proper installation and to maximize your enjoyment and the longevity of the product.



Image: The ALEKO 210 Gallon Round Inflatable Hot Tub Spa, shown from an elevated perspective, highlighting its light blue and

white design and compact form factor.

## 2. SAFETY INFORMATION

---

### Important Safety Instructions

When installing and using this electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions before using the hot tub.
- Do not connect the hot tub to the power supply until it is filled with water.
- Ensure the electrical supply meets the specifications outlined in this manual.
- Always supervise children around the hot tub.
- Do not use the hot tub if the temperature exceeds 104°F (40°C).
- Consult a physician before use if you have health conditions, are pregnant, or are elderly.
- Avoid using electrical appliances near the hot tub.
- Regularly inspect the hot tub for damage and do not operate if damaged.



Image: A close-up view of the warning label located on the side of the ALEKO hot tub, detailing important safety precautions and electrical specifications.

### 3. PACKAGE CONTENTS

Please check to ensure all components are present and in good condition:

- Inflatable Hot Tub Unit
- Control Unit / Pump
- Fitted Cover with Safety Locking Clips
- Filter Cartridges (Quantity: 3)
- Inflation Hose
- Repair Kit
- Instruction Manual

**Easy-touch control panel**  
allows you to adjust temperature,  
bubbles, and filter



Image: The matching fitted cover for the ALEKO hot tub, designed to help retain heat and provide safety when the tub is not in use. The underside features an aluminum foil coating for insulation.

## 4. SETUP GUIDE

### 4.1 Site Selection

Choose a flat, stable surface capable of supporting the weight of the hot tub when filled with water (approximately 210 gallons + weight of occupants). Ensure adequate drainage and access to a power outlet.

### 4.2 Unpacking and Inflation

Carefully remove all components from the packaging. Unfold the hot tub liner and connect the inflation hose to the hot tub's air valve and the control unit's inflation port. Inflate the hot tub until it is firm to the touch but not overinflated. Do not use an air compressor not designed for this product.

### 4.3 Filling the Hot Tub

Once inflated, ensure the drain valve is closed. Fill the hot tub with fresh water using a garden hose, up to the maximum fill line indicated on the interior wall. Do not overfill.



Image: A person demonstrating the quick and easy assembly and installation process of the ALEKO inflatable hot tub, showing the initial setup phase.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Control Panel Overview

The easy-touch control panel allows you to manage all functions of your hot tub. It features buttons for temperature adjustment, bubble jet activation, and filter operation.

### 5.2 Temperature Adjustment

Press the 'Temperature' button and use the up/down arrows to set your desired water temperature. The hot tub can heat water up to 104°F (40°C). The 1200-watt heater provides efficient heating.

### 5.3 Bubble Jet Operation

Press the 'Bubble' button to activate the high-powered bubble jets. The hot tub features 100-130 bubble jets for a relaxing massage experience. Press again to turn off.

### 5.4 Filtration System

Press the 'Filter' button to activate the filtration system. The filter motor is designed to keep the water clean. Ensure a filter cartridge is installed before operating the filter.



Image: A close-up of the ALEKO hot tub's easy-touch control panel, showing the digital display and buttons for temperature, filter, and bubble jet controls.

## 6. MAINTENANCE

---

### 6.1 Water Quality and Treatment

Maintaining proper water chemistry is crucial for hygiene and longevity. Regularly test water pH and sanitizer levels (e.g., bromine or chlorine). Add appropriate chemicals as needed to keep the water balanced and clean.

### 6.2 Filter Cartridge Replacement

The filter cartridge should be cleaned regularly and replaced every 1-2 weeks, or more frequently depending on usage. A clean filter ensures efficient water circulation and filtration.

### 6.3 Cleaning the Hot Tub

Periodically drain and clean the hot tub liner. Use a soft cloth and mild, non-abrasive cleaner. Rinse thoroughly before refilling.



Image: A cylindrical filter cartridge, essential for maintaining water clarity and cleanliness in the hot tub. This component requires regular cleaning or replacement.

## 7. TROUBLESHOOTING

---

This section addresses common issues you might encounter. For problems not listed here, please contact customer support.

Problem	Possible Cause	Solution
Hot tub not heating or heating slowly	Low water level, dirty filter, heater error code, cold ambient temperature.	Ensure water is at proper level. Clean or replace filter. Check control panel for error codes and consult manual. Consider indoor or warmer weather use.
Water is cloudy or dirty	Dirty filter, improper water chemistry, heavy usage.	Clean or replace filter cartridge. Test and adjust water chemistry (pH, sanitizer). Shock treat the water if necessary.
Hot tub losing air pressure / Leaks	Valve not sealed, small puncture, seam leak.	Ensure all valves are tightly closed. Locate puncture using soapy water and repair with provided kit. For seam leaks, contact customer support.
Control panel displaying error codes	System malfunction, sensor issue.	Refer to the specific error code in the full product manual (if available) or contact customer support for diagnosis. Try unplugging and re-plugging the unit.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	ALEKO
Model	HTIR4GRW
Voltage	120 Volts
Shape	Round
Capacity	210 Gallons
Seating Capacity	4 Persons
Product Dimensions	29 x 20 x 16 inches
Item Weight	59.8 pounds
Heater Power	1200 Watts (Newly upgraded)
Max Heat Capability	104°F (40°C)
Bubble Jets	100-130 high powered bubble jets

## 9. WARRANTY AND SUPPORT

---

For warranty information, technical assistance, or customer support, please refer to the contact details provided with your purchase documentation or visit the official ALEKO website. You can also find customer support information on the product's retail page.

It is recommended to register your product upon purchase to facilitate any future warranty claims or support requests.