

## HP 3FV67AA#ABB

# HP 250 Wireless Mouse User Manual

Model: 3FV67AA#ABB

## INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your HP 250 Wireless Mouse. The HP 250 Wireless Mouse is designed to enhance connectivity and productivity, offering a reliable 2.4 GHz wireless connection and an ambidextrous, contoured design for comfortable use. It features a Blue LED optical sensor with adjustable sensitivity settings.

## PACKAGE CONTENTS

- HP 250 Wireless Mouse
- USB Nano Receiver
- 1 AA Battery (Lithium Metal)

## SETUP

1. **Insert Battery:** Locate the battery compartment on the underside of the mouse. Open the compartment cover and insert the provided AA battery, ensuring correct polarity (+/-). Close the cover securely.
2. **Locate USB Nano Receiver:** The USB nano receiver is typically stored inside the battery compartment or packaged alongside the mouse. Remove the receiver.
3. **Connect Receiver:** Plug the USB nano receiver into an available USB port on your computer.
4. **Power On:** The mouse should automatically power on and establish a connection with the receiver. If there is an on/off switch, ensure it is in the "On" position.
5. **Driver Installation:** Your operating system (Windows) should automatically detect and install the necessary drivers. No manual driver installation is typically required.



Image: Top view of the HP 250 Wireless Mouse, showing its contoured design and scroll wheel.

## OPERATING INSTRUCTIONS

The HP 250 Wireless Mouse features a standard 3-button layout with a scroll wheel for intuitive navigation.

- **Left Button:** Primary click function for selecting items, opening links, etc.
- **Right Button:** Secondary click function, typically opening context menus.
- **Scroll Wheel:** Used for vertical scrolling through documents and web pages. It can also function as a middle click button.

The ambidextrous design ensures comfortable use for both left-handed and right-handed users.

## DPI SENSITIVITY

The HP 250 Wireless Mouse utilizes a Blue LED optical sensor offering multiple sensitivity options: 1000 DPI,

1200 DPI, and 1600 DPI. These settings allow for fluid control and can be selected to match your preferred cursor speed and precision requirements. The mouse is designed to adapt its sensitivity for optimal performance.

## BATTERY INFORMATION

The mouse is powered by one AA Lithium Metal battery, which is included in the package. The average battery life is approximately 12 months, depending on usage.

### Battery Replacement:

1. Turn off the mouse if it has an on/off switch.
2. Locate and open the battery compartment cover on the underside of the mouse.
3. Remove the old battery.
4. Insert a new AA battery, ensuring correct polarity (+/-).
5. Close the battery compartment cover securely.
6. Dispose of used batteries according to local regulations.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Sensor Care:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris to ensure accurate tracking.
- **Storage:** When not in use for extended periods, consider removing the battery to prevent leakage. Store the mouse and receiver in a dry, cool place. The nano receiver can be stored inside the mouse for convenience.

## TROUBLESHOOTING

Problem	Solution
Mouse not responding or erratic movement.	<p><b>Check Battery:</b> Ensure the battery is correctly inserted and has sufficient charge. Replace if necessary.</p> <p><b>Check Receiver:</b> Ensure the USB nano receiver is securely plugged into a working USB port. Try a different USB port.</p> <p><b>Interference:</b> Move the mouse closer to the receiver. Avoid using the mouse near other wireless devices that might cause interference.</p> <p><b>Surface:</b> Ensure the mouse is used on a suitable, non-reflective surface.</p>
Connection issues.	<p><b>Re-pair:</b> If the mouse has a pairing button, press it and follow any on-screen instructions. (Note: This model typically auto-pairs).</p> <p><b>Restart Computer:</b> Sometimes a simple computer restart can resolve connectivity issues.</p>

## SPECIFICATIONS

Model Name	HP Wireless Mouse
------------	-------------------

<b>Model Number</b>	3FV67AA#ABB
<b>Connectivity Technology</b>	2.4 GHz Wireless (Wi-Fi)
<b>Movement Detection</b>	Optical (Blue LED)
<b>DPI Sensitivity</b>	Up to 1600 DPI (1000, 1200, 1600 selectable/adaptive)
<b>Number of Buttons</b>	3 (Left, Right, Scroll Wheel)
<b>Hand Orientation</b>	Ambidextrous
<b>Power Source</b>	1 x AA Lithium Metal Battery (included)
<b>Average Battery Life</b>	12 months
<b>Compatible Operating Systems</b>	Windows
<b>Compatible Devices</b>	PC with available USB port
<b>Dimensions (L x W)</b>	11.5 cm x 6.9 cm

## WARRANTY AND SUPPORT

---

HP products are covered by a limited warranty. For detailed warranty information, please refer to the warranty card included with your product or visit the official HP support website. For technical assistance, driver downloads, or further support, please visit [support.hp.com](https://support.hp.com).