

Brim 50013

Brim Electric Handheld Burr Coffee Grinder Model 50013 User Manual

Model: 50013

1. INTRODUCTION

Thank you for choosing the Brim Electric Handheld Burr Coffee Grinder. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new coffee grinder. Please read all instructions carefully before first use and retain this manual for future reference.

This compact and versatile grinder is designed to provide precise and consistent coffee grounds for various brewing methods, from fine espresso to coarse French press. It features durable stainless steel burrs and a simple one-touch operation.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not immerse the motor unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Check the bean hopper for the presence of foreign objects before using.
- This appliance is for household use only.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Brim Electric Handheld Burr Coffee Grinder.





Figure 1: Assembled Brim Electric Handheld Burr Coffee Grinder. This image displays the complete grinder unit, showcasing its sleek stainless steel and black design, with the transparent bean hopper visible in the middle section.

Components:

- 1. Motor Unit / Top Cover:** Contains the motor and power button.
- 2. Bean Hopper:** Transparent section for whole coffee beans.
- 3. Burr Grinding Assembly:** Internal stainless steel burrs for grinding.
- 4. Ground Coffee Container:** Bottom section for collecting ground coffee.
- 5. Grind Adjustment Ring:** Located at the base of the burr assembly for selecting grind size.

4. SETUP AND FIRST USE

Before using your grinder for the first time, follow these steps:

- 1. Unpack:** Carefully remove all packaging materials and inspect the grinder for any damage.
- 2. Clean:** Wash the bean hopper and ground coffee container with warm, soapy water. Rinse thoroughly and dry completely. The motor unit should be wiped with a damp cloth only; never immerse it in water.
- 3. Assemble:** Ensure the burr grinding assembly is securely in place. Attach the bean hopper and then the motor unit, twisting to lock them into position. Finally, attach the ground coffee container to the bottom.



Figure 2: Disassembling the grinder for cleaning or assembly. This image illustrates the grinder being separated into its main components: the top motor unit, the bean hopper with burr assembly, and the bottom ground coffee container.

5. OPERATING INSTRUCTIONS

Follow these steps to grind your coffee beans:

- 1. Add Beans:** Remove the top motor unit and add up to 30 grams of whole coffee beans into the bean hopper. Do not overfill.



Figure 3: A hand adding whole coffee beans into the transparent bean hopper of the grinder, which is placed on a kitchen counter next to other coffee brewing equipment.

2. **Select Grind Setting:** Reattach the motor unit. Adjust the grind adjustment ring, typically located at the base of the burr assembly, to your desired fineness. The grinder offers 9 precise settings, ranging from fine for espresso to coarse for French press. Turn the ring clockwise for finer grinds and counter-clockwise for coarser grinds.
3. **Start Grinding:** Plug the grinder into a suitable electrical outlet. Press and hold the power button on the top of the motor unit to begin grinding. Release the button to stop.



Figure 4: A person holding the Brim Electric Handheld Burr Coffee Grinder during operation, demonstrating its compact and ergonomic design. The grinder is actively processing coffee beans.

4. **Empty Grounds:** Once grinding is complete, unplug the unit. Carefully remove the ground coffee container from the bottom and pour the fresh grounds into your brewing device.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your grinder.

1. **Unplug:** Always ensure the grinder is unplugged from the power outlet before cleaning.
2. **Disassemble:** Separate the motor unit, bean hopper, burr grinding assembly, and ground coffee container. Refer to Figure 2 for visual guidance.
3. **Clean Components:**
 - **Motor Unit:** Wipe the exterior with a soft, damp cloth. Do not immerse in water.
 - **Bean Hopper, Ground Coffee Container, and Burr Assembly:** These parts can be washed with warm, soapy water. Use a small brush (not included) to remove any stubborn coffee residue from the burrs.
4. **Dry Thoroughly:** Ensure all washed parts are completely dry before reassembling and storing or using again. Moisture can damage the burrs and affect performance.
5. **Reassemble:** Put the grinder back together, ensuring all parts are securely locked.

7. TROUBLESHOOTING

If you encounter issues with your grinder, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Grinder does not start	Not plugged in; parts not assembled correctly; no beans in hopper.	Ensure power cord is securely plugged in. Check that all components (motor unit, hopper, container) are properly assembled and locked. Add coffee beans.
Inconsistent grind size	Grind setting incorrect; burrs clogged; foreign object.	Adjust grind setting. Disassemble and clean burrs thoroughly. Check for any foreign objects.
Grinder stops during operation	Overheating; motor overload; obstruction.	Unplug and allow to cool for 30 minutes. Reduce amount of beans. Disassemble and check for obstructions in the burr assembly.
Excessive noise	Normal operation; loose parts; foreign object.	Some noise is normal for burr grinders. Ensure all parts are securely fastened. Check for foreign objects.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	50013
Brand	Brim
Dimensions (L x W x H)	3.46" x 3.46" x 9.48"
Item Weight	1.49 pounds
Capacity	30 grams (approx. 0.03 Kilograms)
Grind Settings	9 precise settings
Burr Material	Stainless Steel
Voltage	2.3E+2 Volts (AC)
UPC	829486500138
Manufacturer	Sensio Inc.

9. WARRANTY INFORMATION

This Brim Electric Handheld Burr Coffee Grinder is covered by a limited manufacturer's warranty. Please

refer to the warranty card included with your purchase for specific terms and conditions, including the duration of coverage and how to make a claim. Typically, this warranty covers defects in materials and workmanship under normal household use.

Keep your purchase receipt as proof of purchase for warranty validation.

10. CUSTOMER SUPPORT

For further assistance, product inquiries, or to report an issue not covered in this manual, please contact Brim customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.

Manufacturer: Sensio Inc.

Please have your model number (50013) and purchase date available when contacting support.