

## **Pyle EUPPHP1049KT**

# **Pyle Wireless Portable PA Speaker System**

MODEL: EUPPHP1049KT - USER MANUAL

## **1. Introduction**

Thank you for purchasing the Pyle Wireless Portable PA Speaker System. This high-powered active and passive speaker pair is designed to deliver exceptional sound quality for various applications, from personal use to outdoor DJ events. This manual provides essential information for the safe and efficient operation of your new PA system. Please read it thoroughly before use and retain it for future reference.

### **Package Contents:**

- Active PA Speaker (1)
- Passive PA Speaker (1)
- Speaker Stands (2)
- Wired Microphone (1)
- Remote Control (1)
- Power Cable (1)
- Speaker Connection Cable (1)

# QUE CONTIENT LA BOÎTE



Image: All components included in the Pyle Wireless Portable PA Speaker System package.

## 2. Safety Instructions

To reduce the risk of electric shock, do not remove the cover. No user-serviceable parts inside. Refer servicing to qualified service personnel. Always follow basic safety precautions when using electrical products.

- Do not expose this appliance to rain or moisture.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

### 3. Product Features

- **1000 Watt Peak Power:** Delivers powerful audio output for clear and dynamic sound.
- **10" Subwoofer & 1" Tweeter:** Equipped with high-performance drivers for impressive bass response and clear highs.
- **Bluetooth Compatible:** Seamless wireless audio streaming from smartphones, tablets, and other Bluetooth-enabled devices.
- **Multiple Inputs:** Features USB, SD card reader, 3.5mm AUX input, 1/4" SpeakOn, and XLR microphone input for versatile connectivity.
- **Digital LCD Display & EQ Control:** Rear panel controls for master volume, mic volume, treble, and bass adjustments.
- **35mm Speaker Stand Mount:** Allows for elevated speaker placement for optimal sound dispersion.



Image: Illustration of the speaker's internal components, emphasizing the 1000 Watt peak output capability.

### 4. Setup

#### 4.1 Speaker Placement

For optimal sound projection, it is recommended to mount the speakers on the included stands. Ensure the stands are placed on a stable, level surface to prevent tipping.

1. Extend the legs of the speaker stands fully for maximum stability.
2. Carefully lift each speaker and place it onto the 35mm pole mount on top of the stand. Ensure it is securely seated.



Image: The Pyle PA Speaker System with both active and passive speakers correctly mounted on their stands.

## 4.2 Connecting the Speakers

The system includes one active speaker (with the control panel) and one passive speaker. They must be connected for the passive speaker to function.

1. Locate the SpeakOn output on the active speaker's rear panel.
2. Connect one end of the included speaker connection cable to the SpeakOn output on the active speaker.
3. Connect the other end of the cable to the SpeakOn input on the passive speaker.

## 4.3 Power Connection

Ensure the power switch on the active speaker is in the OFF position before connecting to power.

1. Connect the power cable to the AC input on the active speaker's rear panel.
2. Plug the other end of the power cable into a standard wall outlet (AC 120V/240V, 50/60Hz).



# OPTIONS DE LECTURE POLYVALENTES

USB, SD, AUX et Plus Encore!



Panneau Arrière



Facile À Installer

Image: Details of the speaker's rear panel connections and the stand mounting point, illustrating ease of setup.

## 5. Operating Instructions

### 5.1 Control Panel Overview

The active speaker features a comprehensive control panel on its rear. Familiarize yourself with the following controls:

- **MP3 Control Digital Display:** Shows current mode (USB/SD/Bluetooth/AUX) and track information.
- **Mode Button:** Switches between input modes (Bluetooth, USB, SD, AUX).
- **Play/Pause, Previous/Next Buttons:** For media playback control.
- **Scan Button:** For radio tuning (if applicable).
- **MIC VOL:** Adjusts the volume of the microphone input.
- **BASS:** Adjusts the low-frequency output.
- **TREBLE:** Adjusts the high-frequency output.
- **MASTER VOL:** Controls the overall output volume of the system.
- **MIC Input (XLR):** For connecting a wired microphone.

- **LINE IN (AUX 3.5mm):** For connecting external audio devices via a 3.5mm cable.
- **USB Port:** For connecting USB flash drives.
- **SD Card Slot:** For inserting SD memory cards.
- **SPEAKER OUT (SpeakOn):** For connecting the passive speaker.
- **Power Switch:** Turns the unit ON/OFF.



Image: Detailed view of the speaker's control panel, illustrating how to customize your sound.

## 5.2 Bluetooth Connectivity

To stream audio wirelessly from your Bluetooth-enabled device:

1. Turn on the PA system.
2. Press the 'Mode' button on the control panel until 'BLUE' appears on the digital display, indicating Bluetooth mode.
3. On your smartphone, tablet, or computer, enable Bluetooth and search for available devices.
4. Select 'PYLEUSA' or a similar name from the list of devices.
5. Once paired, you can play audio from your device, and it will stream through the PA system.

Image: Demonstrating the wireless Bluetooth functionality and various input options of the speaker system.

### 5.3 USB/SD Playback

The system supports MP3 audio playback from USB flash drives and SD memory cards.

1. Insert your USB flash drive into the USB port or your SD card into the SD card slot.
2. The system should automatically switch to USB or SD mode. If not, press the 'Mode' button until the correct mode is displayed.
3. Use the Play/Pause, Previous, and Next buttons to control playback.

### 5.4 AUX Input

For connecting external audio devices without Bluetooth (e.g., CD players, laptops):

1. Connect a 3.5mm audio cable from your device's headphone output or line out to the 'LINE IN' (AUX) port on the speaker.
2. Press the 'Mode' button until 'AUX' is displayed.
3. Control playback and volume from your connected device.

### 5.5 Microphone Input

The system includes an XLR microphone input for vocal performances or announcements.

1. Connect the wired microphone to the 'MIC' (XLR) input.
2. Adjust the 'MIC VOL' knob to control the microphone's volume level.

### 5.6 EQ Adjustment

Use the 'BASS' and 'TREBLE' knobs to fine-tune the audio output to your preference or the acoustics of the environment.

- Turn the 'BASS' knob clockwise to increase low frequencies (more bass) or counter-clockwise to decrease.
- Turn the 'TREBLE' knob clockwise to increase high frequencies (more clarity) or counter-clockwise to decrease.

## 6. Maintenance

---

### 6.1 Cleaning

To maintain the appearance and longevity of your PA system:

- Always unplug the unit from the power outlet before cleaning.
- Use a soft, dry cloth to wipe down the exterior surfaces.
- Do not use liquid cleaners, aerosol cleaners, or harsh chemicals, as they may damage the finish or internal components.
- Keep the ventilation openings free of dust and debris.

### 6.2 Storage

When not in use for extended periods, store the PA system in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to store it in its original packaging or a protective case to prevent damage.

## 7. Troubleshooting

If you encounter issues with your Pyle PA Speaker System, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; Power switch off; Outlet not working.	Ensure power cable is securely connected; Turn power switch ON; Test outlet with another device.
No sound from speakers	Master volume too low; Incorrect input mode selected; Passive speaker not connected; Audio source issue.	Increase MASTER VOL; Press MODE button to select correct input; Ensure passive speaker is connected via SpeakOn cable; Check audio source device.
Bluetooth not connecting	Speaker not in Bluetooth mode; Device too far; Bluetooth on device is off.	Ensure speaker is in 'BLUE' mode; Move device closer to speaker; Enable Bluetooth on your device and re-scan.
Distorted sound	Volume too high (clipping); EQ settings incorrect; Poor audio source quality.	Reduce MASTER VOL or source volume; Adjust BASS/TREBLE knobs; Use a higher quality audio source.
Microphone not working	MIC VOL too low; Microphone not connected properly; Microphone faulty.	Increase MIC VOL; Ensure microphone is securely plugged into XLR input; Test with another microphone if available.

## 8. Specifications

Feature	Specification
Output Power	1000 Watts (Peak) / 500 Watts (RMS)
Number of Channels	2
Subwoofer Size	10 inches
Tweeter Size	1 inch
Audio Input	AUX, SpeakOn, USB, SD, XLR (Microphone)
Recommended Uses	Concerts, Conferences, Outdoor Events, Personal Use
Sound Level	92 dB
UPC	842893113036
Special Features	High-resolution audio, Integrated microphone, USB port, Display
Connectivity Technology	AUX, Bluetooth



Feature	Specification
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	18.08 Pounds
Dimensions (L x W x H)	57.5 x 35.5 x 67.4 centimeters
Power Source	Corded Electric

## 9. Warranty and Support

This Pyle Wireless Portable PA Speaker System comes with a**2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please visit the official Pyle website or contact their customer service department. Contact information can typically be found on the product packaging or the Pyle brand's official online presence.

For additional information and product registration, please visit:[www.pyleusa.com](http://www.pyleusa.com)

© 2024 Pyle. All rights reserved.

Documents - Pyle – EUPPHP1049KT



[pdf]

EUPPHP1049KT Pyle USA PyleUSA 3 1 11 2 7 4 8 10 6 5 9 REMOTE CONTROL MODE USB SD BT FM CONVERTER In Previous Song Press and hold for fast rewind swich to backward manuals pyleusa  
**EUPPHP1049KT** Active Passive PA Speaker System Kit Dual Loudspeaker Sound Package, 10 Subwoofers, Bluetooth Wireless Streaming, Includes 2 Speaker Stands, Wired Microphone, Remote Control, 1000 Watt **EUPPHP1049KT** 1. LCD screen 2. Mp3 control MODE: USB/SD/BT/FM convertor : Play / Pause SCAN: Pr...  
lang:en score:38 filesize: 930.77 K page\_count: 6 document date: 2018-09-18

