

Logitech G933-SNOW-RB

Logitech G933 Artemis Spectrum Snow Wireless 7.1 Gaming Headset User Manual

Model: G933-SNOW-RB

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Logitech G933 Artemis Spectrum Snow Wireless 7.1 Gaming Headset. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image 1.1: The Logitech G933 Artemis Spectrum Snow Wireless Gaming Headset, showcasing its white and black design.

2. PACKAGE CONTENTS

Verify that all items are present in your product packaging:

- Logitech G933 Artemis Spectrum Snow Wireless 7.1 Gaming Headset
- Wireless USB Mix Adapter
- 3.5mm Analog Cable
- USB Charging/Data Cable
- User Documentation (this manual)

3. HEADSET FEATURES AND COMPONENTS

Familiarize yourself with the key components of your G933 headset.



Image 3.1: Side view of the Logitech G933 headset, highlighting the ear cup design and control buttons for power, volume, and G-keys.

- **Adjustable Headband:** For comfortable fit during extended use.
- **Padded Earcups:** Over-ear design with sound isolation for immersive audio.
- **Retractable Microphone:** Flexible boom microphone that can be stowed away when not in use.
- **On-Headset Controls:** Power switch, volume wheel, programmable G-keys, and microphone mute button.

- **USB Charging Port:** For connecting the USB charging/data cable.
- **3.5mm Audio Jack:** For wired connection to various devices.
- **Wireless USB Mix Adapter Storage:** Conveniently located under the left earcup plate.



Image 3.2: Logitech G933 headset with the retractable microphone extended, showing its optimal position for voice communication.

4. SETUP

4.1. Charging the Headset

Before initial use, fully charge the headset. Connect the USB charging/data cable to the headset's USB port and to a powered USB port on your computer or a USB wall adapter. The LED indicator on the headset will show charging status.

4.2. Wireless Setup (PC/Mac)

1. Remove the Wireless USB Mix Adapter from the left earcup.
2. Plug the Wireless USB Mix Adapter into a USB port on your computer.
3. Slide the power switch on the headset to the "ON" position.
4. The headset should automatically connect to the adapter. If not, press the G-key on the headset for 3 seconds to initiate pairing mode.

5. For full functionality, download and install the Logitech G HUB software from the official Logitech website. This software enables 7.1 surround sound, LIGHTSYNC RGB customization, and G-key programming.

4.3. Wired Setup (PC/Mac/Console/Mobile)

The G933 can be used in wired mode with the included 3.5mm analog cable.

1. Connect one end of the 3.5mm analog cable to the headset's 3.5mm audio jack.
2. Connect the other end to the 3.5mm audio output on your device (PC, console controller, mobile phone).
3. In wired mode, the headset operates passively. Some features like LIGHTSYNC RGB and G-key functionality may be limited or unavailable without power.

5. OPERATING THE HEADSET

5.1. Power On/Off

Slide the power switch located on the left earcup to turn the headset ON or OFF.

5.2. Volume Control

Adjust the volume using the scroll wheel located on the left earcup.

5.3. Microphone Usage

- **Extend/Retract:** Pull the microphone boom out from the left earcup to use it. Push it back in to stow.
- **Mute/Unmute:** Press the microphone mute button on the left earcup. A red LED on the microphone tip indicates it is muted.
- **Microphone Monitoring:** Enable or disable microphone monitoring (sidetone) via the Logitech G HUB software to hear your own voice in the headset.

5.4. Programmable G-Keys

The G933 features three programmable G-keys on the left earcup. These can be customized using the Logitech G HUB software to perform various functions, such as media controls, macros, or chat commands.

5.5. LIGHTSYNC RGB Lighting

The headset features customizable RGB lighting. Use the Logitech G HUB software to select from a spectrum of 16.8 million colors, synchronize lighting effects with other Logitech G devices, or set custom animations.

5.6. 7.1 Surround Sound

Experience immersive 7.1 surround sound (DTS Headphone:X 2.0 or Dolby Headphone) by installing and configuring the Logitech G HUB software on your PC. This feature provides precise audio positioning for an enhanced gaming experience.

6. MAINTENANCE

6.1. Cleaning

- Wipe the headset with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- The ear pads are removable for cleaning or replacement. Gently pull them off to remove and push them

back on to reattach.

6.2. Battery Care

- To maximize battery life, avoid fully discharging the battery frequently.
- Store the headset in a cool, dry place when not in use for extended periods.
- If the headset will not be used for a long time, charge it to about 50% before storing.

7. TROUBLESHOOTING

7.1. No Audio / Disconnection

- Ensure the headset is powered ON and fully charged.
- Verify the Wireless USB Mix Adapter is securely plugged into a working USB port.
- Check that the headset is selected as the default audio output device in your operating system's sound settings.
- If using Logitech G HUB, ensure the headset is recognized and not muted.
- Try re-pairing the headset by pressing the G-key for 3 seconds.
- Test with the 3.5mm analog cable to determine if the issue is wireless-specific.

7.2. Microphone Not Working




- Ensure the microphone is extended and not muted (red LED off).
- Check that the headset microphone is selected as the default input device in your operating system's sound settings and in any communication applications.
- Verify microphone settings within Logitech G HUB.

7.3. Software Issues (Logitech G HUB)

- Ensure Logitech G HUB is updated to the latest version.
- Try restarting the G HUB software or your computer.
- If issues persist, consider reinstalling Logitech G HUB.

8. SPECIFICATIONS

Model Name	G933 Artemis Spectrum Snow
Item Model Number	G933-SNOW-RB
Connectivity Technology	Wireless (2.4 GHz), Wired (3.5mm analog)
Audio Driver Type	Dynamic Driver
Frequency Range	20Hz-20KHz
Surround Sound	7.1 DTS Headphone:X 2.0 / Dolby Headphone (via G HUB)
Microphone	Retractable, Noise-cancelling
Battery Life	Up to 12 hours (without lighting), Up to 8 hours (with default lighting)
Charging Port	USB

	<p>Logitech H800 Wireless Headset Quick Start Guide</p> <p>Learn how to set up and use your Logitech H800 Wireless Headset for music, calls, and Bluetooth connectivity. This guide covers features, connection steps, troubleshooting, and battery information.</p>
	<p>Logitech USB Headset H390: Comfortable, Clear Audio for Calls and Entertainment</p> <p>Explore the Logitech USB Headset H390, featuring plush comfort, pure digital stereo sound, and an adjustable noise-cancelling microphone. Ideal for clear voice/video calls, music, and gaming, with easy USB plug-and-play setup and broad OS compatibility.</p>
	<p>Logitech G522 LIGHTSPEED Headset Setup Guide</p> <p>A comprehensive setup guide for the Logitech G522 LIGHTSPEED Headset, covering connection to PC and Bluetooth devices, wired USB audio, resetting and pairing, switching modes, adjusting volume, and muting the microphone.</p>