

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Yantop](#) /

› [Yantop Wireless Mouse User Manual - Model USAA1-YPGEPC157AB](#)

Yantop USAA1-YPGEPC157AB

Yantop Wireless Mouse User Manual

Model: USAA1-YPGEPC157AB

1. INTRODUCTION

Thank you for choosing the Yantop Wireless Mouse. This device offers reliable 2.4G wireless connectivity, an ergonomic design for comfortable use, and adjustable DPI settings to enhance your productivity and gaming experience. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting.



Figure 1: Yantop Wireless Mouse and USB Nano Receiver. A top-down view of the black Yantop wireless mouse, showcasing its ergonomic design, scroll wheel, and DPI button. The compact USB nano receiver is shown next to it.

2. PACKAGE CONTENTS

- 1 x Yantop Wireless Mouse
- 1 x USB Nano Receiver (stored in the battery compartment)
- 1 x User Manual

Note: 2 AAA batteries are required and are not included in the package.

3. PRODUCT OVERVIEW

Six-button Design



Figure 2: Six-Button Design. A detailed diagram labeling the six buttons of the Yantop wireless mouse: Left Button, Right Button, Non-slip Rubber Scroll Wheel, DPI Button, Forward Button, and Backward Button.

1. **Left Button:** Standard left-click function.
2. **Right Button:** Standard right-click function.
3. **Scroll Wheel:** For scrolling up and down, and can also function as a middle-click button.
4. **DPI Button:** Adjusts cursor sensitivity (DPI).
5. **Forward Button:** Navigates forward in web browsers or file explorers.
6. **Backward Button:** Navigates backward in web browsers or file explorers.

4. SETUP

4.1 Installing Batteries

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover.

4.2 Connecting the Receiver

1. The USB Nano Receiver is stored inside the battery compartment of the mouse. Carefully remove it.
2. Plug the USB Nano Receiver into an available USB port on your computer (desktop, laptop, MacBook, etc.).
3. Your computer should automatically detect and install the necessary drivers. No additional software installation is required.

4.3 Powering On/Off

Locate the ON/OFF switch on the bottom of the mouse. Slide the switch to the "ON" position to power on the mouse. Slide it to the "OFF" position when not in use to conserve battery life.

Energy Saving Mode

Auto enter power-saving mode after 10 minutes of inactivity



- 01** Up to 12 months of battery life
- 02** Powered by 2 x AAA batteries (Not included)
- 03** Take out USB nano receiver
- 04** On/Off switch button



Working Stand by Auto Shut Off 10 Mins

Figure 3: Battery and Receiver Location. An image of the mouse's underside, illustrating the battery compartment where two AAA batteries are inserted, the storage slot for the USB nano receiver, and the ON/OFF power switch.

5. OPERATION

5.1 Adjusting DPI (Cursor Sensitivity)

The Yantop Wireless Mouse features three adjustable DPI settings: 800, 1200 (default), and 1600. To change the DPI, press the DPI button located below the scroll wheel. Each press will cycle through the available settings, allowing you to select the cursor speed that best suits your needs.



Figure 4: Adjustable DPI Settings. A close-up of the mouse's top, showing the DPI button and visual indicators for the three adjustable DPI settings: 800, 1200 (default), and 1600.

5.2 Power Saving Features

To conserve battery life, the mouse is equipped with a smart power-saving mode. If the mouse is inactive for 10 minutes, it will automatically enter sleep mode. To wake it up, simply click any button on the mouse.

Smart Power Saving Mode

Automatically enter sleep mode after ten minutes of stopping work

 **10min**



Figure 5: Smart Power Saving Mode. An image depicting the mouse's smart power-saving feature, showing it automatically entering sleep mode after 10 minutes of inactivity.

6. COMPATIBILITY

The Yantop Wireless Mouse is compatible with a wide range of operating systems, including:

- Windows XP / 7 / 8 / 10
- Mac OS (Note: Side buttons are not supported on Mac OS)
- Linux



Note: Side buttons are not supported in Mac OS

Figure 6: Operating System Compatibility. The Yantop wireless mouse displayed alongside logos of compatible operating systems.

7. MAINTENANCE

7.1 Cleaning

To clean your mouse, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the finish. Ensure no liquid enters the mouse's internal components.

7.2 Battery Replacement

When the mouse performance degrades or it stops responding, it's likely time to replace the batteries. Follow the steps in Section 4.1 to replace the two AAA batteries. Dispose of old batteries responsibly according to local regulations.

8. TROUBLESHOOTING

- **Mouse not responding:**
 - Ensure the mouse is powered on (ON/OFF switch on the bottom).

- Check if the batteries are correctly inserted and have sufficient charge. Replace if necessary.
 - Ensure the USB Nano Receiver is securely plugged into a working USB port on your computer. Try a different USB port.
 - Move the mouse closer to the receiver to rule out range issues (maximum 15m/32ft).
- **Cursor movement is erratic or slow:**
 - Clean the optical sensor on the bottom of the mouse.
 - Try using the mouse on a different surface.
 - Adjust the DPI setting using the DPI button (see Section 5.1).
- **Side buttons not working:**
 - If you are using a Mac OS system, the side buttons are not supported. This is a known compatibility limitation.
 - For Windows/Linux, ensure no software conflicts are present.

9. SPECIFICATIONS

Feature	Detail
Model Number	USAA1-YPGEPC157AB
Connection Type	2.4G Wireless (USB Nano Receiver)
DPI Settings	800 / 1200 (default) / 1600
Number of Buttons	6 (Left, Right, Scroll Wheel, DPI, Forward, Backward)
Working Distance	Up to 15 meters (32 feet)
Power Source	2 x AAA Batteries (not included)
Battery Life	Up to 12 months (with power-saving mode)
Automatic Sleep Mode	After 10 minutes of inactivity
Keystroke Durability	Over 5,000,000 clicks
Product Dimensions	12.5 x 7.01 x 3.99 cm (4.92 x 2.76 x 1.57 inches)
Product Weight	90.72 g (0.2 lbs)
Compatibility	Windows XP/7/8/10, Mac OS (side buttons not supported), Linux

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact Yantop customer service through the retailer where the product was purchased. Keep your proof of purchase for warranty claims.

