



Manuals.plus /

› AGLUCKY /

› AGLUCKY Countertop Ice Maker User Manual

AGLUCKY Z5879-GREY

AGLUCKY Countertop Ice Maker Instruction Manual

MODEL: Z5879-GREY

Brand: AGLUCKY

1. Introduction and Overview

Thank you for choosing the AGLUCKY Countertop Ice Maker. This portable and compact ice machine is designed to provide fresh ice quickly and conveniently for various settings, including your home, kitchen, office, bar, or parties. It features efficient ice production, user-friendly controls, and a self-cleaning function to ensure optimal performance and hygiene.



Figure 1: AGLUCKY Countertop Ice Maker (Model Z5879-GREY)

This ice maker can produce 9 bullet-shaped ice cubes in approximately 6-8 minutes and has a daily ice production capacity of up to 26.5 pounds. It offers two ice cube sizes (small and large) to suit your preferences. The intuitive control panel includes indicators for 'Add Water' and 'Ice Full', ensuring you are always aware of the machine's status.

Compact Countertop Ice Maker



26LBS/24H



2L Water Tank



9Ice Cubes /6Mins



Figure 2: Key Features of the AGLUCKY Ice Maker

2. Safety Information

Please read all instructions carefully before operating the ice maker to ensure safe and efficient use. Keep this manual for future reference.

- **Electrical Safety:** Ensure the power outlet matches the voltage requirements (115 Volts). Do not operate with a damaged cord or plug.
- **Placement:** Place the ice maker on a stable, level surface away from direct sunlight, heat sources, and corrosive gases. Ensure adequate ventilation around the unit, especially near the air vents.
- **Water Quality:** Use potable water only. Distilled or filtered water is recommended to minimize mineral buildup and maintain ice quality.
- **Children and Pets:** Keep the appliance out of reach of children and pets. Supervise children if they are near the appliance.
- **Maintenance:** Unplug the ice maker before cleaning or performing any maintenance. Do not use abrasive cleaners or sharp objects.
- **Refrigerant:** This appliance uses R600a refrigerant. Do not puncture the refrigerant tubing. Refer to

qualified service personnel for repairs.

3. Setup

Follow these steps for initial setup:

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective film.
2. **Included Components:** Verify that all accessories are present: the ice maker unit, ice scoop, and ice basket.
3. **Placement:** Position the ice maker on a flat, stable countertop. Ensure there is at least 5 inches of clearance around the unit for proper ventilation. Avoid placing it near heat-generating appliances.
4. **Resting Period:** After transportation, allow the ice maker to stand upright for at least 2-4 hours before plugging it in. This allows the refrigerant to settle.
5. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Remove the ice basket and wash it with warm water and mild detergent. Wipe the interior with a soft cloth. Rinse thoroughly and dry.
6. **Add Water:** Open the top lid and pour potable water into the water reservoir. Do not exceed the 'MAX' water level line indicated inside the reservoir.

4. Operating Instructions


Operating your AGLUCKY Ice Maker is simple:

1. **Power On:** Plug the ice maker into a grounded electrical outlet. Press the 'ON/OFF' button on the control panel to turn on the appliance. The 'POWER' indicator light will illuminate.
2. **Select Ice Size:** Press the 'SELECT' button to choose your desired ice cube size: 'S' for small or 'L' for large. The corresponding indicator light will illuminate.
3. **Ice Production:** The ice maker will automatically begin the ice-making cycle. The first batch of ice typically takes 6-8 minutes. Subsequent cycles may be faster.
4. **'ADD WATER' Indicator:** If the 'ADD WATER' indicator light turns red, it means the water reservoir is low. Add more water to the reservoir up to the 'MAX' line. The ice maker will resume operation automatically.
5. **'ICE FULL' Indicator:** When the ice basket is full, the 'ICE FULL' indicator light will turn red, and the ice maker will pause operation. Remove ice from the basket to resume production.
6. **Power Off:** To turn off the ice maker, press the 'ON/OFF' button again.

Simple Operation Panel




Add Water
Indicator


Ice Full
Indicator


Optional
Ice Cube Size


Self-cleaning
Function

Figure 3: Control Panel and Indicators

Selectable Ice Cube Size

Large Size



Small Size



Figure 4: Ice Cube Sizes

The ice maker operates with a quick and quiet cooling system, designed to be energy-efficient while maintaining a low noise level during operation.



Figure 5: Low Noise Operation

5. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your ice maker and ensure fresh-tasting ice.

1. **Daily Cleaning:** After each use, unplug the unit. Remove the ice basket and drain any remaining water from the reservoir by opening the drain plug at the bottom. Wipe the interior with a soft cloth.
2. **Self-Cleaning Function:** The ice maker is equipped with a self-cleaning function. To activate, ensure the unit is plugged in and has water in the reservoir. Press and hold the 'ON/OFF' button for 5 seconds. The self-cleaning cycle will begin, circulating water through the system. Once complete, drain the water and wipe dry.
3. **Monthly Cleaning:** For thorough cleaning or to remove mineral buildup, mix a solution of water and vinegar (or a mild descaling agent) and run the self-cleaning cycle. After the cycle, drain the solution and run 2-3 cycles with clean water to rinse thoroughly.
4. **Exterior Cleaning:** Wipe the exterior of the ice maker with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.

Self-Cleaning Function

Press ON/OFF button for 5 secs to get the cleaning mode



Figure 6: Self-Cleaning Process

6. Troubleshooting

If you encounter issues with your ice maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ice maker not working / No ice production	Not plugged in; No water; Air vent blocked; Refrigerant issue.	Check power connection; Add water; Ensure proper ventilation; Contact customer support.
'ADD WATER' light on, but water is present	Water level sensor dirty or obstructed.	Clean the water level sensor (small black sensor inside reservoir).
'ICE FULL' light on, but basket is not full	Ice cubes are blocking the sensor; Sensor dirty.	Rearrange ice cubes; Clean the ice full sensor.
Ice cubes are too small or not solid	Water temperature too high; Ambient temperature too high.	Use colder water; Place unit in a cooler environment.
Unusual noise during operation	Unit not level; Internal component issue.	Ensure unit is on a flat surface; Contact customer support if noise persists.

If the problem persists after attempting these solutions, please contact AGLUCKY Customer Support for assistance.

7. Specifications

Detailed technical specifications for your AGLUCKY Ice Maker:


Feature	Specification
Brand	AGLUCKY
Model Name	Z5879-GREY
Product Dimensions (D x W x H)	12.3" x 8.7" x 12.6"
Capacity	26.5 Pounds (ice production per 24 hours)
Wattage	750 watts
Voltage	115 Volts
Refrigerant	R600a
Material	Stainless Steel
Item Weight	17.01 pounds
Installation Type	Countertop
Included Components	Ice maker, Ice scoop, Ice basket

Product Specification


- Ice shape : Bullet
- Refrigerant : R600a
- Power : 115 Volts/60 Hz
- Item Weight : 16.5 pounds



Figure 7: Product Dimensions and Key Components



High Speed Exhaust Fan



Plug Drain



Pure Copper Columns



Large Air Vent

Figure 8: Internal and External Components

8. Warranty and Support

AGLUCKY products are designed for reliability and performance. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official AGLUCKY website. Please have your model number (Z5879-GREY) and purchase date available when contacting support.

Note: No official product videos from the seller were available for embedding in this manual.