

Hella 358.128-321

Hella Cool Maker 358.128-321 10W-40 Fully Synthetic Engine Oil User Manual

INTRODUCTION

This manual provides essential instructions for the proper use and maintenance of Hella Cool Maker 358.128-321 10W-40 Fully Synthetic Engine Oil. Adhering to these guidelines will help ensure optimal engine performance and longevity.

Hella Cool Maker 10W-40 Fully Synthetic Engine Oil is formulated to provide superior protection and performance for your vehicle's engine. Its advanced synthetic blend offers excellent wear protection, extends oil drain intervals, and improves fuel economy.

SAFETY INFORMATION

Always prioritize safety when handling engine oil. Read and understand all safety warnings before use.

- **Skin Contact:** Avoid prolonged or repeated skin contact with used engine oil. Wash thoroughly with soap and water after handling.
- **Eye Contact:** In case of contact with eyes, flush immediately with large amounts of water for at least 15 minutes and seek medical attention.
- **Ingestion:** Do not ingest. If swallowed, do not induce vomiting. Seek immediate medical attention.
- **Inhalation:** Avoid breathing oil mists or vapors. Use in a well-ventilated area.
- **Disposal:** Dispose of used oil and containers responsibly according to local regulations. Do not pour into drains or the environment.
- **Flammability:** Engine oil is combustible. Keep away from open flames, sparks, and hot surfaces. Store in a cool, dry place.
- **Keep Out of Reach:** Keep out of reach of children and pets.

INSTALLATION AND OPERATING INSTRUCTIONS

This section outlines the general procedure for checking and adding engine oil. Always refer to your vehicle's owner's manual for specific instructions and recommended oil change intervals.

Checking Engine Oil Level

1. **Park on Level Ground:** Ensure your vehicle is parked on a level surface.
2. **Engine Off and Cool:** Turn off the engine and wait at least 5-10 minutes for the oil to drain back into the oil pan. For an accurate reading, the engine should be cool.
3. **Locate Dipstick:** Open the hood and locate the engine oil dipstick. It usually has a brightly colored handle (e.g., yellow or orange).
4. **Remove and Wipe:** Pull out the dipstick, wipe it clean with a lint-free cloth or paper towel.
5. **Reinsert and Check:** Fully reinsert the dipstick until it seats properly, then pull it out again. Observe the oil level. It should be between the "MIN" and "MAX" marks.

Adding Engine Oil

1. **Identify Oil Fill Cap:** Locate the engine oil fill cap, usually marked with an oil can symbol or "ENGINE OIL."
2. **Remove Cap:** Unscrew and remove the oil fill cap.
3. **Add Oil Gradually:** If the oil level is below the "MIN" mark, add Hella Cool Maker 10W-40 Fully Synthetic Engine Oil in small increments (e.g., 0.5 liters at a time) using a funnel to prevent spills.
4. **Recheck Level:** After adding oil, wait a few minutes for it to settle, then recheck the oil level with the dipstick as described above. Repeat until the level is within the recommended range.
5. **Secure Cap:** Replace the oil fill cap securely.



Image: Hella Cool Maker 10W-40 Fully Synthetic Engine Oil 3.5L container. This image shows the front view of the product packaging, highlighting the brand, viscosity, and volume.

MAINTENANCE

Regular oil changes are crucial for engine health. Refer to your vehicle's owner's manual for the recommended oil change intervals, which typically depend on mileage, time, and driving conditions.

- **Oil Change Intervals:** Adhere strictly to the manufacturer's recommended oil change schedule. Fully synthetic oils often allow for longer intervals, but always verify with your vehicle's specific requirements.
- **Oil Filter Replacement:** Always replace the oil filter when performing an oil change. A new filter ensures optimal filtration and prevents contaminants from circulating in the fresh oil.
- **Regular Checks:** Periodically check your oil level between changes, especially before long trips. Top up as necessary to maintain the correct level.
- **Monitor Oil Condition:** While checking the level, observe the oil's color and consistency. Extremely dark, thick, or gritty oil may indicate a need for an earlier oil change or a potential engine issue.



Image: Hella Engine Oil 10W-40 Synthetic Lubricant Cool Maker bottle. This image displays a close-up of the Hella 10W-40 engine oil container, emphasizing the product details.

TROUBLESHOOTING

This section addresses common concerns related to engine oil. For persistent issues, consult a qualified mechanic.

Symptom	Possible Cause	Solution
Low Oil Level Warning Light	Insufficient engine oil.	Check oil level and add Hella Cool Maker 10W-40 oil as needed. Inspect for leaks.
Engine Noise (Tapping/Knocking)	Low oil pressure, incorrect oil viscosity, or worn engine components.	Check oil level. Ensure correct oil type (10W-40) is used. If noise persists, seek professional inspection.
Oil Leaks	Loose drain plug, faulty oil filter seal, worn gaskets/seals.	Inspect drain plug and oil filter for tightness. Identify source of leak and repair or replace affected components.
Excessive Oil Consumption	Engine wear (piston rings, valve seals), external leaks.	Monitor oil consumption. If excessive, consult a mechanic for engine diagnosis.

SPECIFICATIONS

Feature	Detail
Brand	Hella
Model Number	358.128-321
Viscosity	10W-40
Type	Fully Synthetic Engine Oil
Liquid Volume	3.5 Liters (3500 Millilitres)
Container Type	Jug
Vehicle Service Type	Car

Feature	Detail
API Standard	SN/CF
Item Weight	3600 Grams
Manufacturer	HELLA India Lighting Ltd

WHAT'S IN THE BOX

- 1 x Hella Cool Maker 10W-40 Fully Synthetic Engine Oil (3.5 L)

WARRANTY AND SUPPORT

For warranty information or technical support regarding Hella Cool Maker 10W-40 Fully Synthetic Engine Oil, please contact your retailer or the manufacturer directly. Keep your purchase receipt as proof of purchase.

Manufacturer Contact: HELLA India Lighting Ltd

For further assistance, please visit the official Hella website or contact their customer service.

