

Midea MERC04C4BAWW

Midea MERC04C4BAWW 3.5 Cubic Feet Convertible Chest Freezer User Manual

Model: MERC04C4BAWW | Brand: Midea

[Introduction](#) [Safety Information](#) [Product Overview](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Midea MERC04C4BAWW 3.5 Cubic Feet Convertible Chest Freezer. Please read these instructions thoroughly before use and retain them for future reference.

The Midea MERC04C4BAWW Chest Freezer offers 3.5 cubic feet of storage for frozen or fresh foods. Its design allows for efficient operation in various environments, making it suitable as a secondary storage unit. A removable storage basket is included to help organize smaller items.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is intended for household use only.
- Ensure the appliance is properly grounded.
- Do not allow children to climb, stand, or hang on the shelves in the freezer.
- Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.

- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the appliance before cleaning or performing any maintenance.

3. PRODUCT OVERVIEW AND FEATURES

The Midea MERC04C4BAWW chest freezer is designed for versatile food storage with several key features:

3.1. Key Components





Figure 3.1: Front view of the Midea MERC04C4BAWW Chest Freezer with the lid open, revealing various frozen food items and a removable basket.

This image displays the overall appearance of the Midea MERC04C4BAWW Chest Freezer. It highlights the top-opening lid and the spacious interior, which is designed to accommodate a variety of frozen goods. The exterior features a clean, white finish.

3.2. Convertible Functionality

This chest freezer can easily switch between freezer and refrigerator modes, adapting to your specific food storage requirements.



Figure 3.2: Illustration of the freezer's convertible feature, showing its ability to function as either a freezer (top) or a refrigerator (bottom) for flexible food preservation.

The diagram illustrates the dual functionality of the Midea chest freezer, allowing users to select between freezing and refrigeration modes based on their storage needs. This feature provides flexibility for different types of food items.

3.3. Garage Ready Design

The freezer is engineered to operate efficiently in non-climate-controlled environments, such as garages or basements. It maintains optimal performance in temperatures ranging from 38°F to 110°F in fridge mode, and 0°F to 110°F in freezer mode.

Power Outage Promise



Figure 3.3: The image shows the Midea chest freezer positioned in a garage, emphasizing its capability to function reliably in a wide range of ambient temperatures.

This image depicts the freezer in a garage environment, highlighting its "Garage Ready" certification. This indicates its robust design for stable operation even in fluctuating temperatures typical of such spaces.

3.4. Power Outage Protection

In the event of a power outage, the freezer is designed to keep its contents frozen for up to 48 hours, helping to preserve your food.

Built-In LED Lighting

Illuminated interior for nighttime access



Figure 3.4: A visual representation of the freezer's ability to maintain freezing temperatures for up to 48 hours during a power interruption, ensuring food safety.

The graphic illustrates the freezer's power outage protection, indicating that it can keep food frozen for up to 48 hours without power. This feature provides peace of mind regarding food spoilage during electrical disruptions.

3.5. Built-in LED Lighting

An interior LED light illuminates the freezer's contents, making it easier to locate items, especially in low-light conditions.



Figure 3.5: The image displays the interior LED lighting of the freezer, which enhances visibility of stored items, particularly useful in darker environments.

This image highlights the built-in LED lighting feature, showing how the interior of the freezer is illuminated when the lid is open, making it easier to see and access items.

3.6. Convenient Design Elements

The freezer includes adjustable legs for leveling, a removable plastic basket for organization, a convenient stay-open lid, and an exterior control panel for easy temperature adjustments.



Figure 3.6: A composite image showcasing various user-friendly features: a removable storage basket, a lid designed to stay open for easy access, a manual defrost drain hole, and an external temperature control dial with a power indicator light.

This collage illustrates several practical design features: the removable basket for organizing smaller items, the lid's ability to stay open for hands-free access, the drain hole for manual defrosting, and the external temperature control for easy adjustments without opening the unit.

4. SETUP

4.1. Unpacking

Carefully remove the freezer from its packaging. Inspect the unit for any damage that may have occurred during shipping. Remove all protective films and packaging materials from the exterior and interior of the freezer.

4.2. Placement

Place the freezer on a flat, stable surface. Ensure there is adequate ventilation around the unit. Maintain at least 5 inches of clearance around the freezer to allow for proper air circulation and efficient operation. The adjustable legs can be used to level the unit.




Figure 4.2: The image demonstrates the versatility of the Midea chest freezer's placement, showing it in a living room, kitchen, and garage, emphasizing its compact size and adaptability to various home environments.

This image showcases the freezer in different household settings (living room, kitchen, garage), illustrating its

compact size and how it can fit into various spaces. Proper clearance around the unit is crucial for optimal performance.

4.3. Initial Power-on

After placing the freezer in its desired location, allow it to stand upright for at least 4 hours before plugging it in. This allows the refrigerant fluids to settle. Once settled, plug the freezer into a dedicated electrical outlet. The green 'RUN' indicator light on the control panel will illuminate, indicating the unit is powered on and operating.

5. OPERATING INSTRUCTIONS

5.1. Temperature Control

The temperature of the freezer is controlled by a dial located on the exterior. Rotate the dial to select your desired temperature setting. Settings typically range from 'Min' (least cold) to 'Max' (coldest). For convertible use, refer to the specific temperature ranges for freezer and refrigerator modes.

Your browser does not support the video tag.

Video 5.1: A demonstration of the temperature control dial and the interior of a white chest freezer, showing its capacity and features like the drain plug.

This video demonstrates the external temperature control dial, showing how to adjust settings. It also provides a view of the freezer's interior, highlighting the spacious storage area and the drain plug for defrosting.

5.2. Internal Organization

The removable plastic basket can be positioned at the top of the freezer for easy access to frequently used or smaller items. This helps in organizing the contents and prevents smaller items from getting lost at the bottom of the unit.

6. MAINTENANCE

6.1. Defrosting

This is a manual defrost freezer. Frost buildup should be removed periodically to maintain efficiency. To defrost, unplug the unit, remove all food items, and open the drain plug located at the bottom front of the freezer. Place a shallow pan or towel underneath the drain to collect water. Allow the frost to melt naturally. Do not use sharp objects to remove ice, as this can damage the interior.

6.2. Cleaning

After defrosting, clean the interior with a mild detergent and warm water. Wipe dry thoroughly before plugging the unit back in and returning food items. The exterior can be cleaned with a soft cloth and mild soap.

7. TROUBLESHOOTING

If your freezer is not operating correctly, check the following common issues before contacting customer support:

- **Freezer not running:** Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
- **Temperature is not cold enough:** Verify the temperature control dial is set to an appropriate level. Ensure the lid is closing properly and not obstructed. Avoid frequent or prolonged lid openings.
- **Excessive frost buildup:** This is a manual defrost unit. Regular defrosting is required. Ensure the lid seal is intact.
- **Unusual noises:** Some operational noises are normal (e.g., compressor running, refrigerant flow). If noises are loud or unusual, ensure the unit is level and not touching walls or other appliances.

8. SPECIFICATIONS

Feature	Detail
Brand	Midea
Model Number	MERC04C4BAWW
Capacity	3.5 Cubic Feet
Color	White
Product Dimensions	17.6 x 21.5 x 33.5 inches (D x W x H)
Item Weight	47.8 pounds
Voltage	115 Volts
Installation Method	Freestanding
Certification	UL
Included Components	Chest freezer, plastic basket, user manual
Door Material Type	Stainless Steel



Figure 8.1: Energy Guide label providing estimated yearly energy cost and electricity usage for the Midea MERC04C4BAWW Chest Freezer.

The Energy Guide label provides important information regarding the estimated yearly energy cost and electricity usage of the freezer, allowing users to understand its energy efficiency.





9. WARRANTY & SUPPORT



Warranty: This Midea chest freezer comes with a 1-year warranty. Please refer to the warranty card included with your product for full terms and conditions.

Customer Support: For any questions, assistance, or to report issues, please contact Midea customer support. Contact information can typically be found in the user manual or on the manufacturer's official website.

© 2025 Midea. All rights reserved.

Related Documents - MERC04C4BAWW

	<p>Midea Chest Freezer User Manual - MERC04C4BAWW, MERC05C4BAWW, MERC07C4BAWW</p> <p>User manual for Midea Chest Freezers (MERC04C4BAWW, MERC05C4BAWW, MERC07C4BAWW). Find detailed instructions on installation, operation, safety precautions, cleaning, maintenance, and troubleshooting for your Midea appliance.</p>
	<p>Midea Chest Freezer User Manual: MERC05C4BAWW, MERC07C4BAWW</p> <p>Comprehensive user manual for Midea Chest Freezers (MERC05C4BAWW, MERC07C4BAWW). Learn about safe operation, installation, maintenance, and troubleshooting for your Midea appliance.</p>
	<p>Midea MRC07M7AWW Chest Freezer User Manual</p> <p>Comprehensive user manual for the Midea MRC07M7AWW Chest Freezer, covering safety instructions, operation, installation, care, and troubleshooting for optimal use.</p>
	<p>Midea Chest Freezer User Manual: MDRC280SL, MDRC405FZ, MDRC564FZ Series</p> <p>Comprehensive user manual for Midea chest freezers, covering safety warnings, proper usage, maintenance, and troubleshooting for models MDRC280SL, MDRC405FZ, and MDRC564FZ.</p>

	<p>Midea MRC09M4AWW Chest Freezer User Manual</p> <p>Comprehensive user manual for the Midea MRC09M4AWW Chest Freezer, covering installation, operation, safety guidelines, maintenance, and troubleshooting.</p>
	<p>Midea Chest Freezer User Manual</p> <p>User manual for Midea Chest Freezer, providing detailed information on safety, operation, maintenance, and troubleshooting. Includes model information and energy saving tips.</p>