

## PPLEE PPLEE-1008I-GN

# PPLEE Extra Loud Vibrating Alarm Clock

## USER MANUAL

### Introduction

Thank you for choosing the PPLEE Extra Loud Vibrating Alarm Clock. This alarm clock is designed to provide effective wake-up solutions for heavy sleepers, individuals who are deaf or hard of hearing, and anyone needing a reliable alarm. It features a large LED display, multiple wake-up modes including a powerful bed shaker, adjustable brightness and volume, a multi-color night light, and convenient USB charging ports. Please read this manual thoroughly to ensure proper setup and operation of your new alarm clock.

### What's in the Box

- 1 x PPLEE Alarm Clock
- 1 x Bed Shaker
- 1 x Power Adapter
- 1 x USB Cable
- 1 x User Manual

### Product Overview

Familiarize yourself with the components and controls of your alarm clock.



Front view of the PPLEE alarm clock with its large green LED display and the connected bed shaker.

# MULTIFUNCTIONAL CLOCK



VIBRATOR



VOLUME  
CONTROL



ADJUSTABLE  
BRIGHTNESS



NIGHT LIGHT



MEMORIZED  
BATTERY



12H/24H Time  
Format



USB CHARGING  
PORT



9-MINS SNOOZE



Diagram illustrating the clock's dimensions and key features such as vibrator, volume control, adjustable brightness, night light, memorized battery, 12H/24H time format, USB charging port, and 9-minute snooze.

The alarm clock features a large 7-inch LED display for clear visibility. On the top, you will find buttons for setting time, alarms, snooze, and controlling the night light. The back of the unit includes dual USB charging ports and connections for the power adapter and bed shaker.

## Setup

1. **Power Connection:** Connect the provided power adapter to the DC IN port on the back of the alarm clock and plug it into a standard wall outlet. The display will light up.
2. **Battery Backup (Optional):** For battery backup functionality during power outages, insert 2 AAA batteries (not included) into the battery compartment on the bottom of the clock. These batteries will preserve time and alarm settings and trigger the alarm during power failure, but will not power the display or USB charging.
3. **Connect Bed Shaker:** Plug the bed shaker's cable into the designated port on the back of the alarm clock. Place the bed shaker under your pillow or mattress for optimal vibration.

## Operating Instructions

### Setting Time and Date

- **Set Time:** Press and hold the "SET TIME" button. Use the "HOUR" and "MINUTE" buttons to adjust the time. Press "SET TIME" again to confirm.
- **12/24 Hour Format:** Slide the "12H/24H" switch button on the back of the clock to select your preferred time format.
- **Daylight Saving Time (DST):** Press and hold the "SET TIME" button to activate or deactivate the DST function.

### Setting the Alarm

## 3 WAKE-UP MODES FOR ALL NEEDS



Wake up only by bed shaker



Wake up only by buzzer



Wake up by both Bed shaker and Buzzer

Visual representation of the three available wake-up modes: vibration only, buzzer only, or both combined.

1. **Set Alarm Time:** Press and hold the "ALARM SET" button. Use the "HOUR" and "MINUTE" buttons to set your desired alarm time. Press "ALARM SET" again to confirm.
2. **Select Alarm Mode:** After setting the alarm time, press the "ALARM MODE" button repeatedly to cycle through the three wake-up modes:
  - **Bed Shaker Only:** The bed shaker will activate.
  - **Buzzer Only:** The alarm sound will play.

- **Bed Shaker & Buzzer:** Both the bed shaker and alarm sound will activate.

3. **Activate/Deactivate Alarm:** Press the "ALARM ON/OFF" button to turn the alarm on or off. An alarm icon will appear on the display when the alarm is active.

## **Snooze Function**

When the alarm sounds, press the large "SNOOZE" button on the top of the clock to temporarily silence the alarm for 9 minutes. The alarm will resume after 9 minutes. To stop the alarm completely, press the "ALARM PAUSE" button.

## **Adjusting Display Brightness**





## 0%-100% BRIGHTNESS DIMMER

Easily adjust to the most comfortable brightness



Illustration showing the adjustable brightness levels of the LED display, from 0% (off) to 100% (full brightness).

The display brightness can be adjusted from 0% to 100%. Use the "DIMMER" button to cycle through brightness levels or hold it to smoothly adjust the brightness to your preference.

### Adjusting Alarm Volume

## 3-LEVEL ADJUSTABLE VOLUME

9-Min big **SNOOZE** easily stops the alarm;



L01 

L02 

L03 

70DB

80DB

90DB

Diagram indicating three adjustable volume levels for the alarm, ranging from 70dB to 90dB.

The alarm volume has 3 levels (Low-Medium-High). Use the "VOLUME" button to select the desired alarm volume.

### Night Light Operation



## 7 COLORS NIGHT LIGHTS

Suitable for sleeping and feeding at night, humanized bedside light



Image displaying the alarm clock with its top night light illuminated in various colors, highlighting the 7-color feature.

The alarm clock features a built-in night light with 7 color options. Press the "LIGHT" button to turn the night light on/off and cycle through the available colors.

### USB Charging Ports

# DUAL USB CHARGING PORT

Meet different charging needs, fully charged when you wake up in the morning



A user charging a mobile phone using one of the dual USB ports located on the back of the alarm clock.

Two USB charging ports are located on the back of the alarm clock. You can use these ports to charge your mobile devices overnight. Note that these ports are for charging only and do not transfer data.

## Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the alarm clock. Do not use liquid cleaners or abrasive sprays.
- **Placement:** Place the alarm clock on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture.
- **Power:** Always use the original power adapter provided with the unit.

## Troubleshooting

| Problem                                 | Possible Cause   | Solution  |
|---|--|---|
| Clock display is off or not working.    | No power, loose connection, or power outage.                     | Ensure power adapter is securely plugged in. Check wall outlet. If using battery backup, ensure batteries are fresh and correctly inserted.   |
| Alarm does not sound or vibrate.        | Alarm is not set, alarm mode is incorrect, or volume is too low. | Verify alarm time is set and activated (alarm icon visible). Check that the correct alarm mode (buzzer, shaker, or both) is selected. Increase alarm volume. Ensure bed shaker is properly connected. |
| Time/settings reset after power outage. | Battery backup not installed or batteries are dead.              | Install 2 new AAA batteries (not included) for backup. Ensure they are inserted with correct polarity.  |
| USB charging not working.               | Device not properly connected or clock not powered.              | Ensure the USB cable is securely connected to both the clock and your device. Confirm the alarm clock is powered by the AC adapter.   |
| Display is too dim or too bright.       | Brightness setting needs adjustment.                             | Press or hold the "DIMMER" button to adjust the display brightness to your desired level.   |

## Specifications

| Feature            | Detail                    |
|--------------------|---------------------------|
| Brand              | PPLEE                     |
| Model Number       | PPLEE-1008I-GN            |
| Display Type       | LED                       |
| Color              | Green Digits + Bed Shaker |
| Product Dimensions | 1.57"W x 7"H              |

| Feature             | Detail  |
|---------------------|---|
| Item Weight         | 0.7 Pounds (11.2 ounces)  |
| Power Source        | Corded Electric with Battery Backup Settings  |
| Battery Requirement | 2 AAA batteries (not included)  |
| Special Features    | Digital LED display, easy to set, large display for vision impaired, outlet operated, USB phone charger, bed shaker, night light, snooze, 12/24H format, DST. |

### Warranty & Support

PPLEE Vibrating Loud Alarm Clock with Bed Shaker provides a **One-Year Warranty** from the date of purchase. Additionally, it includes a **One-Month Money Back Guarantee** and **24-Hour Response** for customer inquiries. If you have any questions or require support regarding your product, please contact us via Amazon. We are committed to responding within 24 hours to assist you. This product is designed for durability and ease of use, making it an excellent choice for personal use or as a gift.