

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AGPTEK](#) /

› [AGPTEK Rechargeable Air Pump Instruction Manual - Model B07QBMQSMS](#)

AGPTEK B07QBMQSMS

AGPTEK Rechargeable Air Pump Instruction Manual

Model: B07QBMQSMS

Brand: AGPTEK

1. INTRODUCTION AND PRODUCT OVERVIEW

Thank you for choosing the AGPTEK Rechargeable Air Pump. This electric air pump is designed for quick inflation and deflation of various inflatable products, offering portability and convenience with its built-in rechargeable battery and multiple charging options. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your device.

3 in 1 Nozzles



Figure 1: AGPTEK Rechargeable Air Pump with included accessories.

2. KEY FEATURES

- **High Capacity Battery:** Equipped with a 4000mAh rechargeable battery for extended use, up to 25 minutes on a full charge. Features an indicator light for charging status and battery level.
- **Multiple Charging Modes:** Built-in USB port allows charging at home, in the car (with included adapter), or via a power bank.
- **Three-in-One Nozzle Design:** Includes small (0.28in), medium (0.35in), and large (0.57in) nozzles to fit various inflatable products.
- **Small, Lightweight & Portable:** Compact design fits easily into backpacks, suitcases, or tool kits, ideal for indoor and outdoor use.
- **Wide Application:** Suitable for swim tubes, inflatable sofas, airbeds, inflatable boats, air mattresses, pool toys, vacuum bags, and bounce houses.



Figure 2: Overview of the pump's high-pressure capability, battery, and charging versatility.

3. PACKAGE CONTENTS

Upon unpacking, please ensure all items are present:

- AGPTEK Rechargeable Air Pump
- Small Nozzle (0.28in)
- Medium Nozzle (0.35in)
- Large Nozzle (0.57in)
- USB Charging Cable
- Car Charger Adapter

Charging at home



Multiple Charging Modes

Ready for pool/camping/indoor/outdoor; Charging in the car

Charging in the car



Power bank



Figure 3: Product details and included accessories.

4. CHARGING INSTRUCTIONS

Before first use, fully charge the air pump. The indicator lights will show the charging status and battery level.

1. Connect the provided USB charging cable to the pump's input port.
2. Plug the other end of the USB cable into a suitable power source:
 - A standard wall adapter (not included) for home charging.
 - The included car charger adapter for in-car charging.
 - A power bank for portable charging.
3. The indicator lights will illuminate to show charging progress. All lights will be solid when fully charged.

Multiple Charging Modes



Figure 4: Various methods for charging the air pump.

5. OPERATING INSTRUCTIONS

5.1. Inflation

1. Select the appropriate nozzle size (S, M, or L) for your inflatable product.
2. Attach the selected nozzle firmly to the inflation port of the air pump (usually marked "INFLATE").
3. Insert the nozzle into the air valve of the item you wish to inflate.
4. Flip the power switch to the "ON" position to start inflation.
5. Once the item is inflated to the desired firmness, turn off the pump and remove the nozzle.



Figure 5: Steps for inflating an item.

5.2. Deflation

1. Select the appropriate nozzle size for the deflation port.
2. Attach the selected nozzle firmly to the deflation port of the air pump (usually marked "DEFLATE").
3. Insert the nozzle into the air valve of the item you wish to deflate.
4. Flip the power switch to the "ON" position to start deflation.
5. Once the item is deflated, turn off the pump and remove the nozzle.



Figure 6: Steps for deflating an item.

Video 1: This video provides an overview of the AGPTEK Rechargeable Air Pump, highlighting its features and ease of use for both inflation and deflation.

6. MAINTENANCE AND CARE

- Keep the air pump clean and free from dust and debris.
- Store the pump in a dry place when not in use.
- Avoid operating the pump for more than 10 minutes continuously to prevent overheating. Allow it to cool down before resuming use.
- Do not block the air intake or outlet during operation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Pump does not turn on.	Low battery or no charge.	Charge the pump fully using the provided USB cable and adapter.
Weak airflow.	Incorrect nozzle size or partially blocked intake/outlet.	Ensure the correct nozzle is used and securely attached. Check for any obstructions in the air intake or outlet.
Pump overheats.	Continuous operation for too long.	Turn off the pump and allow it to cool down for at least 15-20 minutes before resuming use. Avoid continuous operation exceeding 10 minutes.
Nozzle does not fit.	Incompatible valve size.	Ensure you are using one of the three provided nozzles (S, M, L) that matches your inflatable's valve. This pump is not suitable for high-pressure items like tires or balloons.

8. SPECIFICATIONS

- **Brand:** AGPTEK

- **Model:** B07QBMQSMS
- **Color:** Black
- **Material:** Plastic
- **Item Weight:** 414 Grams
- **Product Dimensions:** 4.48" L x 3.89" W x 4.48" H
- **Power Source:** Battery Powered
- **Battery Capacity:** 4000mAh
- **Air Flow Capacity:** 250 Liters Per Minute
- **Maximum Pressure:** 0.44 Pound per Square Inch
- **Operation Mode:** Automatic

9. WARRANTY AND SUPPORT

AGPTEK products are designed for reliability and performance. For warranty information, technical support, or any questions regarding your Rechargeable Air Pump, please refer to the contact information provided on the product packaging or visit the official AGPTEK website. Please retain your proof of purchase for warranty claims.