

[manuals.plus](#) /› [Lasko](#) /› [Lasko T48314 48-inch Oscillating Tower Fan Instruction Manual](#)

Lasko T48314

Lasko T48314 48-inch Oscillating Tower Fan Instruction Manual

Model: T48314

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and save these important safety instructions before using this fan. Failure to follow these instructions may result in fire, electric shock, injury to persons, or property damage.

- Always plug fans directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This fan is equipped with a fused safety plug (Lasko's Blue Plug™). This is a safety feature. Do not remove or tamper with the plug.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Always unplug the fan when moving it from one location to another.
- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.
- Do not use outdoors.
- This fan is not intended for use in wet or damp locations.

Enhanced Safety

Lasko®

BUILT-IN FEATURES GIVE YOU RELIABLE AUTOMATIC
AND MANUAL FAULT PROTECTION



Figure 1: Lasko's Blue Plug safety system, designed for enhanced electrical safety.

2. PRODUCT OVERVIEW

The Lasko T48314 48-inch Oscillating Tower Fan provides powerful and customizable cooling for various indoor spaces. Its sleek, bladeless design integrates seamlessly into home or office environments, offering widespread oscillation for full room air circulation.

Key Features:

- **Powerful Cooling:** 3 quiet speeds with widespread oscillation.
- **Bladeless Design:** Portable and sleek, suitable for various room types.
- **Energy-Saving Timer:** Automatic timer for up to 7 hours of continuous operation.
- **Quiet Nighttime Setting:** Decreases speed and dims control lights for restful sleep.
- **Convenient Remote Control:** Adjust settings from across the room.
- **Enhanced Safety:** ETL listed and equipped with Blue Plug technology.

Better Air Starts Here.

Lasko®



*Source: Circana, LLC, Retail Tracking Service, Small Appliances, Fans, 12 Months Ending March 2025

Figure 2: The Lasko T48314 48-inch Oscillating Tower Fan, featuring a slim design.

3. SETUP AND ASSEMBLY

Assembly is required for the fan base. Follow these general steps:

1. Carefully remove the fan and all components from the packaging.
2. Assemble the two halves of the base by interlocking them.
3. Align the assembled base with the bottom of the fan unit.
4. Secure the base to the fan unit using the provided screws. Ensure all screws are tightened securely.
5. Place the fan on a firm, level surface.

For detailed assembly instructions, refer to the diagrams included in the physical user manual.

4. OPERATING INSTRUCTIONS

Your Lasko T48314 fan can be operated using the control panel on the top of the unit or the included remote control.

Control Panel:



Figure 3: Top-mounted control panel with power, speed, oscillation, timer, and nighttime mode buttons.

- **Power Button ():** Press to turn the fan ON or OFF.
- **Speed Button (⌚):** Cycle through 3 fan speeds: Low, Medium, High.
- **Oscillation Button (⟳):** Activate or deactivate the widespread oscillation feature.
- **Timer Button ():** Set the fan to automatically turn off after 1, 2, 4, or 7 hours.
- **Nighttime Setting Button ():** Activates a quiet mode that decreases speed and dims control lights for undisturbed sleep.

Remote Control:

The remote control provides convenient access to all fan functions from a distance.

Convenient Features

Lasko®



Figure 4: The compact remote control for convenient operation.

- Ensure batteries are correctly installed in the remote control.
- Point the remote control directly at the fan's control panel for optimal response.
- Buttons on the remote correspond to the functions on the control panel.

Video Demonstration:

Your browser does not support the video tag.

Video 1: An overview of the Lasko Tower Fan, demonstrating its features and operation.

5. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and longevity of your fan.

- **Always unplug the fan before cleaning.**
- Use a soft cloth or a vacuum cleaner with a brush attachment to remove dust from the fan grilles and exterior surfaces.
- Do not immerse the fan in water or allow water to drip into the motor housing.
- Do not use gasoline, benzene, paint thinner, or other harsh cleaners, as they may damage the fan's

surface.

- Store the fan in a cool, dry place when not in use.

6. TROUBLESHOOTING

If your fan is not operating as expected, refer to the following common issues and solutions:

- **Fan does not operate:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the Blue Plug safety system has tripped. If so, reset it according to the instructions in the full user manual.
- Verify that the fan's power button is pressed.

- **Reduced airflow:**

- Clean any dust or debris from the air intake and exhaust grilles.
- Ensure the fan is placed in an area with adequate air circulation.

- **Unusual noise:**

- Ensure the fan is on a flat, stable surface.
- Check for any foreign objects that may have fallen into the fan grilles.

If the problem persists after attempting these solutions, contact Lasko customer support.

7. SPECIFICATIONS

Brand	Lasko
Model Name	T48314
Color	Gray
Product Dimensions	12.5"D x 12.5"W x 47.5"H
Item Weight	11.8 Pounds
Power Source	Corded Electric
Wattage	53 watts
Voltage	120 Volts
Air Flow Capacity	818 Cubic Feet Per Minute
Noise Level	51.3 Decibels
Number of Power Levels	3
Control Method	Remote, Push Button
Indoor/Outdoor Usage	Indoor

8. WARRANTY AND SUPPORT

This Lasko T48314 Oscillating Tower Fan comes with a **1 Year Limited Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty service, please contact Lasko Customer Service. You can find contact information on the official Lasko website or in the original product packaging.

For more information, visit the [Lasko Store](#).