



[Manuals.plus](#) /

> [Frigidaire](#) /

> Frigidaire Gallery FGBC5334VS 5.3 Cu. Ft. Built-in Beverage Center User Manual

Frigidaire FGBC5334VS

Frigidaire Gallery FGBC5334VS 5.3 Cu. Ft. Built-in Beverage Center User Manual

Model: FGBC5334VS

1. SAFETY INFORMATION

Please read all safety instructions before operating your new beverage center. Failure to follow these instructions may result in fire, electric shock, or property damage.

Electrical Safety

- Ensure the beverage center is connected to a properly grounded 3-prong outlet.
- Do not use extension cords or ungrounded adapters.
- Unplug the appliance before cleaning or performing any maintenance.

Placement and Installation

- Install the appliance on a level, stable surface capable of supporting its weight when full.
- Allow adequate ventilation space around the unit, especially at the rear and sides, to ensure proper cooling and energy efficiency.
- Do not install near heat sources such as ovens, radiators, or direct sunlight.

Child Safety

- Supervise children when they are near the appliance.
- Ensure children do not climb on or play inside the beverage center.

Flammable Materials

- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

2. PRODUCT OVERVIEW

The Frigidaire Gallery FGBC5334VS is a 5.3 cu. ft. built-in beverage center designed to keep your drinks perfectly chilled. It features touch controls for easy temperature adjustment and bright LED interior lighting.

Front view of the Frigidaire Gallery FGBC5334VS Beverage Center, showcasing its sleek stainless steel design and dark glass door.

Key Features

- **Capacity:** 5.3 cu. ft. total capacity, holding up to 165 cans or 121 bottles.
- **Temperature Range:** Adjustable from 33°F to 50°F (0.5°C to 10°C).
- **Controls:** Convenient touch controls for precise temperature management.
- **Lighting:** Bright LED interior lighting for clear visibility.
- **Shelving:** Durable glass shelves.
- **Door:** Reversible door for flexible installation options.

The beverage center seamlessly integrated into a contemporary entertainment area, demonstrating its built-in capability and stylish appearance.

3. SETUP

Unpacking

1. Carefully remove all packaging materials, including tape and protective films.
2. Inspect the appliance for any shipping damage. Report any damage to your retailer immediately.
3. Keep packaging materials until you are satisfied with the product.

Location and Leveling

- Choose a location with a firm, level floor that can support the weight of the beverage center when fully loaded.
- Ensure there is adequate air circulation around the unit. For built-in installation, follow cabinet manufacturer's guidelines for clearances.
- Level the appliance by adjusting the leveling legs at the bottom corners. Use a level to ensure the unit is perfectly balanced to prevent vibration and ensure proper door sealing.

Detailed dimensions of the beverage center for accurate installation planning.

Electrical Connection

Connect the beverage center to a dedicated 115 Volt, 60 Hz, 15 Amp grounded electrical outlet. Do not use a two-prong adapter or an extension cord.

Door Reversal (Optional)

The door on your beverage center is reversible. If you wish to change the door swing direction, refer to the detailed instructions provided in the separate installation guide or consult a qualified technician.

Initial Operation

After installation, plug in the unit and allow it to cool for at least 2-4 hours before loading beverages. This allows the internal temperature to stabilize.

4. OPERATING

Temperature Control

The beverage center features intuitive touch controls located at the top of the interior. Use the '+' and '-' buttons to adjust the desired temperature. The display will show the current internal temperature.



Interior view of the beverage center with the door open, highlighting the LED lighting and adjustable glass shelves.

- **Recommended Temperature:** For most beverages, a temperature between 38°F and 42°F (3°C and 5°C) is ideal.
- **Temperature Range:** The unit can be set from 33°F to 50°F (0.5°C to 10°C).

Loading Beverages

Arrange bottles and cans on the glass shelves to allow for proper air circulation. Avoid overloading the shelves.



The beverage center fully stocked with cans, demonstrating its ample storage capacity and clear temperature display.



Front view of the beverage center with the door closed, showcasing the organized storage of beverages through the glass door.

- **Can Capacity:** Up to 165 standard 12 oz. cans.
- **Bottle Capacity:** Up to 121 standard 12 oz. bottles.

Interior Lighting

The LED interior lighting can be turned on or off using the light button on the control panel. It provides clear visibility of your beverages.

5. MAINTENANCE

Cleaning

- **Interior:** Clean the interior regularly with a mild detergent and warm water. Rinse thoroughly and dry. Do not use abrasive cleaners or solvents.
- **Exterior:** Wipe the exterior with a soft cloth and mild soap. For stainless steel surfaces, use a stainless steel

cleaner.

- **Door Gasket:** Clean the door gasket regularly to ensure a proper seal.
- **Glass Shelves:** Remove and clean glass shelves with warm soapy water. Dry completely before replacing.

Defrosting

This beverage center features a frost-free defrost system, eliminating the need for manual defrosting. Any accumulated frost will melt automatically and evaporate.

Power Outage

In case of a power outage, keep the door closed to maintain the internal temperature for as long as possible. Avoid opening the door unnecessarily.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in; Circuit breaker tripped/fuse blown; Power outage.	Ensure plug is secure; Reset circuit breaker/replace fuse; Check household power.
Temperature is not cold enough.	Door not closed properly; Door opened too frequently; Warm beverages added; Unit overloaded; Poor ventilation; Temperature setting too high.	Check door seal; Minimize door openings; Allow warm beverages to cool before loading; Do not overload; Ensure proper clearances; Adjust temperature setting lower.
Excessive noise.	Unit not level; Vibrating against wall/cabinet; Normal operating sounds.	Level the unit; Move unit away from contact points; Gurgling/hissing sounds are normal refrigerant flow.
Interior light not working.	Light switch off; LED bulb failure.	Press the light button on the control panel; Contact customer service for LED replacement.
Moisture buildup inside.	High humidity; Door left open; Door gasket not sealing.	This is normal in humid conditions; Ensure door is fully closed; Clean or replace door gasket.

7. SPECIFICATIONS

Specification	Value
Brand	Frigidaire
Model Number	FGBC5334VS
Capacity	5.3 Cubic Feet
Can Capacity (12 oz.)	165

Specification	Value
Bottle Capacity (12 oz.)	121
Product Dimensions (D x W x H)	23.25" x 23.44" x 35"
Item Weight	116 pounds
Installation Type	Built-In
Color	Stainless Steel
Voltage	115 Volts
Wattage	110 watts
Defrost System	Frost Free
Door Hinges	Reversible
Shelf Type	Glass
Annual Energy Consumption	307 Kilowatt Hours Per Year
Refrigerant	R-600A

8. WARRANTY AND SUPPORT

Manufacturer's Warranty

This Frigidaire Gallery beverage center is covered by a **1-year limited warranty** on parts and labor from the date of original purchase. This warranty covers manufacturing defects in materials and workmanship.

For full warranty terms and conditions, please refer to the warranty card included with your product or visit the official Frigidaire website.

Customer Support

For technical assistance, troubleshooting beyond this manual, or to schedule service, please contact Frigidaire Customer Service. Have your model number (FGBC5334VS) and serial number ready when you call.

You can find contact information on the Frigidaire website or in your product registration materials.