

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VOBAGA](#) /

› [VOBAGA Coffee Mug Warmer User Manual](#)

VOBAGA VOB-16-1

VOBAGA Coffee Mug Warmer User Manual

Model: VOB-16-1 | Brand: VOBAGA

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the VOBAGA Coffee Mug Warmer. Keep this manual for future reference.

- **Caution: Hot Surface!** The heating plate becomes hot during operation and remains hot for a period after being turned off. Avoid direct contact with the heating surface to prevent burns.
- Do not immerse the warmer in water or any other liquid.
- Use only with appropriate voltage (110-120V) and power (20 Watts) as specified.
- Ensure the power cord is not damaged and is placed safely to avoid tripping hazards.
- Keep out of reach of children and pets.
- Do not use vacuum-sealed or insulated cups as they may not allow proper heat transfer.
- For best performance, use thin-walled, flat, or slightly concave-bottomed mugs.
- Unplug the warmer when not in use for extended periods.

2. PRODUCT OVERVIEW

The VOBAGA Coffee Mug Warmer is designed to keep your beverages at an optimal drinking temperature. It features a sleek design and user-friendly controls.



Figure 2.1: Top view of the VOBAGA Coffee Mug Warmer, showing the heating plate and power button.

Key Features:

- **3 Temperature Settings:** Easily adjust the warming temperature to your preference.
- **4-Hour Auto Shut-Off:** For safety and energy efficiency, the warmer automatically turns off after 4 hours of continuous operation.
- **Residual Heat Reminder:** The power indicator light flashes after shut-off to warn that the heating plate is still hot.
- **Spill-Proof Design:** Designed to prevent damage from minor spills and facilitate easy cleaning.
- **Durable Materials:** Constructed with heat-resistant and fire-resistant materials.

3. SETUP

1. **Unpack:** Carefully remove the mug warmer from its packaging.
2. **Placement:** Place the warmer on a flat, stable, and heat-resistant surface, such as a desk or countertop. Ensure there is adequate ventilation around the unit.
3. **Connect Power:** Plug the 60-inch UL-approved power cord into a standard 110-120V household electrical outlet.



Figure 3.1: The mug warmer in use with different types of beverages.

4. OPERATING INSTRUCTIONS

Power On/Temperature Selection:

1. To turn on the warmer and select a temperature setting, simply touch the "Power Button" (the power icon on the warmer).
2. Each touch will cycle through the temperature settings:
 - **First Touch:** Activates the highest temperature setting (149°F / 65°C). The power indicator light will be **red**.
 - **Second Touch:** Switches to the medium temperature setting (131°F / 55°C). The power indicator light will be **purple**.
 - **Third Touch:** Switches to the lowest temperature setting (104°F / 40°C). The power indicator light will be **blue**.
3. Place your mug with the beverage onto the heating plate.

Three Temperature Settings






Light colors:			
Drink temp:	149°F	131°F	104°F
Operating:	Touch button once	Touch button Twice	Touch button Triple

Figure 4.1: Visual representation of temperature settings and corresponding light colors.

Automatic Shut-Off:

The warmer is equipped with an automatic shut-off feature that activates after 4 hours of continuous operation. This

enhances safety and conserves energy.

Residual Heat Reminder



After turning off, the **red light flashes** to remind that **the heating plate is still hot** to prevent accidental scald

Figure 4.2: The warmer automatically shuts off after 4 hours.

Residual Heat Reminder:

After the warmer turns off (either manually or automatically), the power indicator light will flash red. This serves as a visual warning that the heating plate is still hot and will continue to flash until the surface temperature drops below 97°F (36°C).



Figure 4.3: The red light flashes to indicate residual heat on the plate.

5. USAGE TIPS

- For optimal warming, use mugs with a flat or slightly concave bottom. This ensures maximum contact with the heating plate.
- Avoid using thick-bottomed or insulated mugs, as they may not warm effectively.
- The warmer is suitable for various materials including tableware, stainless steel cups, ceramic mugs, and glass cups.
- Placing a lid on your mug can help retain heat more effectively.



THREE TEMPERATURE

High-Temp: 149°F
Mid-Temp: 131°F
Low-Temp: 104°F



AUTO SHUT OFF

Automatic Shut Off after continually working 4 hours. Forgotten gospel.



2 IN 1 TOUCH BOTTON

One-button control switch and adjustment temperature. Super easy to use.



Metal WATERPROOF HEATING PLATER

The spill-proof design avoids damage and makes cleaning a breeze.

Figure 5.1: Illustration of suitable mug types for the warmer.

Official Product Videos:

Watch these official videos from the seller for more insights into the VOBAGA Coffee Mug Warmer's features and usage.

6. MAINTENANCE

- **Cleaning:** Always unplug the warmer and allow it to cool completely before cleaning. Wipe the heating plate and body with a soft, damp cloth. Do not use abrasive cleaners or scourers.
- **Storage:** Store the warmer in a dry place when not in use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Warmer does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure the power cord is securely plugged into a working outlet. Try a different outlet. If the problem persists, contact customer support.
Beverage is not warm enough.	Incorrect temperature setting; unsuitable mug type; mug not making full contact.	Select a higher temperature setting. Use a thin-walled, flat-bottomed mug. Ensure the mug is centered on the heating plate.
Power light flashes red after turning off.	Residual heat reminder.	This is a normal safety feature. The light will stop flashing once the plate has cooled down sufficiently.

8. SPECIFICATIONS

- **Model Number:** VOB-16-1
- **Voltage:** 110-120V
- **Rated Power:** 20 Watts
- **Product Dimensions:** 5.3 x 4.5 x 0.7 inches (13.5 x 11.4 x 1.8 cm)
- **Item Weight:** 10.2 ounces (289.2 grams)
- **Cord Length:** 60 inches (1.5 meters)
- **Upper Temperature Rating:** 149°F (65°C)
- **UPC:** 602815748834
- **Manufacturer:** VOBAGA
- **Country of Origin:** China

4-Hour Auto Shut Off

Automatic shut off after continually working 4 hours



Figure 8.1: Diagram showing the physical dimensions of the VOBAGA Coffee Mug Warmer.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official VOBAGA website.

You can also find additional support and resources on the [VOBAGA Store on Amazon](#).