

ZIPRO Beat RS

Zipro Beat RS Magnetic Exercise Bike User Manual

Model: Beat RS | Brand: ZIPRO

1. SAFETY INFORMATION

Before using the Zipro Beat RS Magnetic Exercise Bike, please read and understand all safety instructions. Retain this manual for future reference.

- Consult a physician before starting any new exercise program.
- Ensure all bolts and nuts are securely tightened before each use.
- Place the exercise bike on a flat, stable surface. Use a mat to protect the floor.
- Keep children and pets away from the equipment during operation.
- The maximum user weight for this device is 120 kg.
- Wear appropriate exercise clothing and footwear.
- Stop exercising immediately if you feel faint, dizzy, or experience pain.

2. PRODUCT OVERVIEW

The Zipro Beat RS is a magnetic exercise bike designed for home fitness. It features an ergonomic design, adjustable resistance, and a multi-function computer to track your workout progress.



Figure 1: Overview of the Zipro Beat RS Magnetic Exercise Bike. This image displays the full exercise bike with its main components, including the handlebars, seat, pedals, and central unit with the computer display.

3. ASSEMBLY INSTRUCTIONS

Assembly of the Zipro Beat RS exercise bike typically involves attaching the base stabilizers, pedals, seat, handlebars, and the computer console. Refer to the included assembly diagram for detailed steps.

1. **Attach Stabilizers:** Secure the front and rear stabilizers to the main frame using the provided bolts and washers.
2. **Install Pedals:** Attach the left and right pedals to their respective crank arms. Note that pedals are often marked 'L' and 'R' and thread in opposite directions.
3. **Mount Seat Post and Seat:** Insert the seat post into the frame and secure it. Attach the seat to the seat post.
4. **Assemble Handlebars:** Attach the handlebar post to the main frame, then secure the handlebars to the post. Connect any sensor cables if applicable.
5. **Install Computer Console:** Mount the computer console onto the handlebar post. Connect the sensor cables (pulse, speed) and the battery.



Vélo d'entraînement ZIPRO Beat

ZIPRO Beat est un vélo d'appartement conçu de façon ergonomique, qui trouve sa place dans presque tous les espaces domestiques.

Le système de résistance magnétique avec réglage à 8 niveaux permet d'ajuster précisément l'intensité de l'entraînement selon vos besoins.

Figure 2: A user exercising on the Zipro Beat RS bike, demonstrating its ergonomic design and compact size suitable for home use. This image highlights the bike's overall appearance and how it fits into a living space.

4. OPERATING INSTRUCTIONS

4.1 Adjusting the Seat

Proper seat height is crucial for comfort and effective exercise. Adjust the seat so that your leg is slightly bent at the knee when the pedal is at its lowest point.

Ajustement à la taille



La bonne hauteur de selle augmente l'efficacité des exercices et réduit le risque de blessures.



La forme ergonomique de la selle assure le confort pendant l'entraînement.

Figure 3: Illustration of the seat height adjustment mechanism. The image shows how to raise or lower the seat to achieve the correct ergonomic position for the user.

4.2 Using the Multifunction Computer

The integrated computer displays various workout metrics. It is battery-powered.

- **Power On/Off:** The computer typically turns on automatically when you start pedaling or press any button. It will power off after a period of inactivity.
- **Display Modes:** Use the 'MODE' button to cycle through different display functions such as Time, Speed, Distance, Calories, and Pulse.
- **SCAN Function:** The 'SCAN' function automatically cycles through all metrics, providing a continuous overview of your workout without manual input.
- **Reset:** Press and hold the 'RESET' button to clear all current workout data.
- **Pulse Measurement:** Grip the pulse sensors on the handlebars to display your heart rate. An alarm may sound if your heart rate exceeds a preset safety level.



Figure 4: Close-up view of the multifunction computer display, showing various metrics and control buttons. This image illustrates the interface for tracking workout data.

4.3 Adjusting Resistance

The Zipro Beat RS features an 8-level manual magnetic resistance system. Turn the resistance knob located below the handlebars to increase or decrease the workout intensity.

- Turn the knob clockwise to increase resistance (higher numbers).
- Turn the knob counter-clockwise to decrease resistance (lower numbers).

Réglage manuel de la résistance

Avec le bouton, l'utilisateur peut ajuster la résistance de 1 à 8 en douceur.



Ne nécessite pas d'alimentation, vous pouvez donc vous entraîner n'importe où.



Possibilité de changer rapidement l'intensité pendant la conduite.



L'absence d'électronique complexe signifie un risque réduit de pannes.

Figure 5: Detailed view of the manual resistance adjustment knob. The image shows the numbered dial (1-8) used to control the intensity of the magnetic resistance.

4.4 Using the Device Holder

A dedicated holder is provided on the console for your smartphone or tablet, allowing you to enjoy media during your workout.

Contrôle intuitif de l'ordinateur

Fonction SCAN

Affichage cyclique des paramètres, permettant de suivre l'entraînement sans cliquer et sans lâcher le guidon.



VITESSE

TEMPS

DISTANCE

DISTANCE TOTALE

CALORIES

POULS



Le support pour smartphone ou tablette permet de ranger en toute sécurité l'appareil pendant l'entraînement, ce qui permet de regarder des films ou d'écouter de la musique.

Figure 6: The integrated smartphone or tablet holder on the exercise bike's console. This feature allows users to place their devices securely for entertainment or tracking during exercise.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your exercise bike.

- **Cleaning:** Wipe down the bike with a damp cloth after each use to remove sweat and dust. Avoid abrasive cleaners.
- **Inspection:** Periodically check all bolts, nuts, and moving parts for tightness and wear. Tighten any loose fasteners.
- **Lubrication:** The magnetic resistance system is generally maintenance-free. If you notice any unusual noises from moving parts, consult the manufacturer's support.
- **Storage:** When not in use, store the bike in a dry, cool place. The integrated transport wheels facilitate easy relocation.



Figure 7: Close-up of the transport wheels located at the front base of the exercise bike. These wheels allow for easy movement and storage of the equipment.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your Zippro Beat RS exercise bike.

- **Computer Display Not Working:**
Solution: Check the batteries in the computer console. Replace them if necessary. Ensure all cables connecting to the console are securely plugged in.
- **No Resistance or Inconsistent Resistance:**
Solution: Verify that the resistance adjustment knob is functioning correctly and is not stuck. Ensure no foreign objects are obstructing the magnetic flywheel.
- **Unusual Noises During Operation:**
Solution: Stop exercising and inspect the bike for any loose parts, bolts, or connections. Tighten any loose components. If the noise persists, contact customer support.
- **Unstable During Use:**
Solution: Ensure the bike is placed on a flat, level surface. Adjust the leveling feet (if present) on the stabilizers to eliminate wobbling.

7. SPECIFICATIONS

Detailed technical specifications for the Zipro Beat RS Magnetic Exercise Bike.

Feature	Specification
Model	Beat RS
Brand	ZIPRO
Resistance Mechanism	Magnetic
Resistance Levels	8 (Manual Adjustment)
Maximum User Weight	120 kg
Product Dimensions (L x W x H)	107 x 59 x 127 cm
Product Weight	20.5 kg
Computer Functions	Time, Speed, Distance, Calories, Pulse, SCAN
Power Source (Computer)	Battery-powered
Special Features	Bottle holder, Transport wheels, Device holder
Suggested User Height	155-200 cm

Ajustement parfait et structure stable

ZIPRO









Figure 8: Diagram illustrating the key dimensions of the Zipro Beat RS exercise bike and the suggested user height range. This provides visual context for the product's size and ergonomic fit.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. Specific warranty terms may vary by region and retailer.

If you require technical assistance or have questions not covered in this manual, please contact the manufacturer's customer support or your point of purchase. Keep your purchase receipt and model number (1592574) handy for faster service.

© 2023 ZIPRO. All rights reserved.

	<p>Zipro Beat Magnetic Bike User Manual and Assembly Guide</p> <p>Comprehensive user manual and assembly guide for the Zipro Beat magnetic exercise bike, covering setup, operation, safety, and maintenance. Learn how to use your Zipro Beat for effective home workouts.</p>
	<p>Zipro Nitro RS Magnetic Bike User Manual</p> <p>Comprehensive user manual for the Zipro Nitro RS magnetic bike, covering assembly, operation, safety guidelines, maintenance, and troubleshooting. Includes technical specifications and warranty information.</p>
	<p>ZIPRO Glow Electric-Magnetic Recumbent Bike User Manual</p> <p>This user manual provides comprehensive instructions for the assembly, safe operation, maintenance, and troubleshooting of the ZIPRO Glow electric-magnetic recumbent bike. Designed for home use, it ensures users can maximize their fitness experience while adhering to safety guidelines.</p>
	<p>ZIPRO Wave Electromagnetic Elliptical Trainer User Manual</p> <p>Comprehensive user manual for the ZIPRO Wave electromagnetic elliptical trainer, covering assembly, operation, safety, maintenance, and troubleshooting. Includes technical specifications and program details.</p>
	<p>ZIPRO Neon Magnetic Elliptical Trainer User Manual</p> <p>Comprehensive user manual for the ZIPRO Neon magnetic elliptical trainer, covering assembly, operation, safety precautions, maintenance, and troubleshooting.</p>
	<p>ZIPRO Glow Electric-Magnetic Recumbent Bike User Manual</p> <p>Comprehensive user manual for the ZIPRO Glow electric-magnetic recumbent bike, detailing assembly, operation, safety, maintenance, technical specifications, and troubleshooting for home fitness.</p>

lang:it score:30 filesize: 124.23 K page_count: 3 document date: 2025-07-03

ZIPRO

Beat RS

- PI: Buzzer magnetizujący
- D1: Magnetyka tala
- D2: Magnetyczny czujnik
- D3: Magnetyczny akcelerometr
- D4: Biegnący magnet
- D5: Magnetyczny hamulec mechaniczny
- D6: Ciężar zwieszony
- S1: Magnetyczny czujnik
- R1: Magnetyczny czujnik odkształcenia
- R2: Mechanizm akceleracji tempa
- R3: Wykres akceleracji tempa
- E1: Łącznik magnetyczny
- E2: Monitor magnetyczny



PI: Produktent - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
D1 (Magnetyczny - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
D2 (Magnetyczny - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
D3 (Akcelerometr - 2000 Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
D4 (Biegnący - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
D5 (Hamulec - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
D6 (Ciężar - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
S1 (Ciężar - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
R1 (Ciężar - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
R2 (Ciężar - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
R3 (Ciężar - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
E1 (Ciężar - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland
E2 (Ciężar - Montowany w z.u.m. od: Fabryczna 28A, 33-553 Kraków, Poland

lang:it score:27 filesize: 3.62 M page_count: 180 document date: 2021-06-30

ZPRO	
Beat RS	
<ul style="list-style-type: none"> 1) Baumtypangabe 2) Baumjahr 3) Hersteller 4) Modellnummer 5) Typengruppe 6) Typenklasse 7) Typenvariante 8) Typenbezeichnung 9) Typennummer 10) Typenbezeichnung 11) Typennummer 12) Typenbezeichnung 13) Typennummer 14) Typenbezeichnung 15) Typennummer 16) Typenbezeichnung 17) Typennummer 18) Typenbezeichnung 19) Typennummer 20) Typenbezeichnung 21) Typennummer 22) Typenbezeichnung 23) Typennummer 24) Typenbezeichnung 25) Typennummer 26) Typenbezeichnung 27) Typennummer 28) Typenbezeichnung 29) Typennummer 30) Typenbezeichnung 31) Typennummer 32) Typenbezeichnung 33) Typennummer 34) Typenbezeichnung 35) Typennummer 36) Typenbezeichnung 37) Typennummer 38) Typenbezeichnung 39) Typennummer 40) Typenbezeichnung 41) Typennummer 42) Typenbezeichnung 43) Typennummer 44) Typenbezeichnung 45) Typennummer 46) Typenbezeichnung 47) Typennummer 48) Typenbezeichnung 49) Typennummer 50) Typenbezeichnung 51) Typennummer 52) Typenbezeichnung 53) Typennummer 54) Typenbezeichnung 55) Typennummer 56) Typenbezeichnung 57) Typennummer 58) Typenbezeichnung 59) Typennummer 60) Typenbezeichnung 61) Typennummer 62) Typenbezeichnung 63) Typennummer 64) Typenbezeichnung 65) Typennummer 66) Typenbezeichnung 67) Typennummer 68) Typenbezeichnung 69) Typennummer 70) Typenbezeichnung 71) Typennummer 72) Typenbezeichnung 73) Typennummer 74) Typenbezeichnung 75) Typennummer 76) Typenbezeichnung 77) Typennummer 78) Typenbezeichnung 79) Typennummer 80) Typenbezeichnung 81) Typennummer 82) Typenbezeichnung 83) Typennummer 84) Typenbezeichnung 85) Typennummer 86) Typenbezeichnung 87) Typennummer 88) Typenbezeichnung 89) Typennummer 90) Typenbezeichnung 91) Typennummer 92) Typenbezeichnung 93) Typennummer 94) Typenbezeichnung 95) Typennummer 96) Typenbezeichnung 97) Typennummer 98) Typenbezeichnung 99) Typennummer 100) Typenbezeichnung 	
1) Baumtypangabe	1
2) Baumjahr	1
3) Hersteller	1
4) Modellnummer	1
5) Typengruppe	1
6) Typenklasse	1
7) Typenvariante	1
8) Typenbezeichnung	1
9) Typennummer	1
10) Typenbezeichnung	1
11) Typennummer	1
12) Typenbezeichnung	1
13) Typennummer	1
14) Typenbezeichnung	1
15) Typennummer	1
16) Typenbezeichnung	1
17) Typennummer	1
18) Typenbezeichnung	1
19) Typennummer	1
20) Typenbezeichnung	1
21) Typennummer	1
22) Typenbezeichnung	1
23) Typennummer	1
24) Typenbezeichnung	1
25) Typennummer	1
26) Typenbezeichnung	1
27) Typennummer	1
28) Typenbezeichnung	1
29) Typennummer	1
30) Typenbezeichnung	1
31) Typennummer	1
32) Typenbezeichnung	1
33) Typennummer	1
34) Typenbezeichnung	1
35) Typennummer	1
36) Typenbezeichnung	1
37) Typennummer	1
38) Typenbezeichnung	1
39) Typennummer	1
40) Typenbezeichnung	1
41) Typennummer	1
42) Typenbezeichnung	1
43) Typennummer	1
44) Typenbezeichnung	1
45) Typennummer	1
46) Typenbezeichnung	1
47) Typennummer	1
48) Typenbezeichnung	1
49) Typennummer	1
50) Typenbezeichnung	1
51) Typennummer	1
52) Typenbezeichnung	1
53) Typennummer	1
54) Typenbezeichnung	1
55) Typennummer	1
56) Typenbezeichnung	1
57) Typennummer	1
58) Typenbezeichnung	1
59) Typennummer	1
60) Typenbezeichnung	1
61) Typennummer	1
62) Typenbezeichnung	1
63) Typennummer	1
64) Typenbezeichnung	1
65) Typennummer	1
66) Typenbezeichnung	1
67) Typennummer	1
68) Typenbezeichnung	1
69) Typennummer	1
70) Typenbezeichnung	1
71) Typennummer	1
72) Typenbezeichnung	1
73) Typennummer	1
74) Typenbezeichnung	1
75) Typennummer	1
76) Typenbezeichnung	1
77) Typennummer	1
78) Typenbezeichnung	1
79) Typennummer	1
80) Typenbezeichnung	1
81) Typennummer	1
82) Typenbezeichnung	1
83) Typennummer	1
84) Typenbezeichnung	1
85) Typennummer	1
86) Typenbezeichnung	1
87) Typennummer	1
88) Typenbezeichnung	1
89) Typennummer	1
90) Typenbezeichnung	1
91) Typennummer	1
92) Typenbezeichnung	1
93) Typennummer	1
94) Typenbezeichnung	1
95) Typennummer	1
96) Typenbezeichnung	1
97) Typennummer	1
98) Typenbezeichnung	1
99) Typennummer	1
100) Typenbezeichnung	1

lang:es score:23 filesize: 3.25 M page_count: 94 document date: 2022-12-30