

## roborock S6 Pure

# Roborock S6 Pure Robot Vacuum and Mop User Manual

Model: S6 Pure

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your Roborock S6 Pure Robot Vacuum and Mop. Please read this manual thoroughly before using the product and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Do not use the robot vacuum outdoors or on wet surfaces.
- Do not allow children to operate the robot vacuum.
- Ensure the charging dock is placed on a level surface against a wall.
- Remove any loose cables, small objects, or fragile items from the floor before operation.
- Do not use the robot vacuum to pick up large debris, sharp objects, or liquids.
- Only use the original charging dock and power adapter provided by Roborock.

## PRODUCT COMPONENTS

Familiarize yourself with the main components of your Roborock S6 Pure.



Image: Top view of the Roborock S6 Pure Robot Vacuum, showing the LiDAR sensor tower, power button, and spot cleaning button.

- **LiDAR Navigation System:** For precise mapping and navigation.
- **Main Brush:** For deep cleaning carpets and hard floors.
- **Side Brush:** Sweeps debris from edges and corners.
- **Dustbin:** Collects dirt and debris.
- **Water Tank & Mop Cloth:** For mopping functions.
- **Charging Dock:** For automatic recharging.
- **Power Button:** To turn on/off and start/pause cleaning.
- **Spot Cleaning Button:** For targeted cleaning of small areas.

## SETUP GUIDE

---

### 1. Unpacking and Placement

1. Carefully remove the robot vacuum and all accessories from the packaging.
2. Choose a suitable location for the charging dock. It should be placed against a wall, on a hard, level surface, with at least 0.5 meters (1.6 feet) clear space on both sides and 1.5 meters (4.9 feet) in front.
3. Connect the power adapter to the charging dock and plug it into a wall outlet. Ensure the cable is neatly tucked away to prevent entanglement.

### 2. Initial Charging

Place the robot vacuum onto the charging dock. Ensure the charging contacts on the robot align with those on the dock. The power indicator light on the robot will illuminate, indicating it is charging. Fully charge the robot before first use (approximately 3-5 hours).

### 3. App Installation and Connection

For full functionality, download the Roborock app on your smartphone.

- Scan the QR code in the quick start guide or search for "Roborock" in your app store.
- Open the app and create an account.
- Follow the in-app instructions to add your S6 Pure robot vacuum. This typically involves connecting to the robot's Wi-Fi hotspot and then connecting the robot to your home Wi-Fi network.




Image: The Roborock S6 Pure robot vacuum next to a smartphone displaying the Roborock app interface, demonstrating advanced app control capabilities.

## OPERATING INSTRUCTIONS

### 1. Starting a Clean

- **Via Robot Buttons:** Press the Power button once to start a full clean. Press it again to pause. Press and hold to turn off.
- **Via Roborock App:** Open the app, select your S6 Pure, and tap "Clean" to start. You can also select specific rooms or zones to clean.

# Selective Room Cleaning

Choose which rooms to be clean, and schedule cleaning for specific rooms.




Image: The Roborock S6 Pure robot vacuum cleaning a specific area, illustrating its selective room cleaning feature based on a mapped layout.

## 2. Mopping Function

The S6 Pure can vacuum and mop simultaneously. To use the mopping function:

1. Fill the water tank with clean water.
2. Attach the mop cloth to the water tank.
3. Slide the water tank assembly into the back of the robot until it clicks into place.
4. Start a cleaning cycle. The robot will automatically switch to mopping mode on hard floors.

## 3. Mapping and Navigation

The S6 Pure uses Precision LiDAR Navigation to create an accurate map of your home. This map is used for efficient cleaning paths, multi-floor mapping, and setting no-go zones.

# Precision LiDAR Navigation

Effective home-mapping and  
comprehensive cleaning




Image: A visual representation of the Roborock S6 Pure utilizing LiDAR navigation to map a room, showing distance measurements and effective home-mapping.



# Multi-Floor Mapping




Image: An illustration depicting a multi-story house with the Roborock S6 Pure, showing how it can map and store layouts for different floors.

## 4. Voice Control (Alexa)

The Roborock S6 Pure is compatible with Amazon Alexa. To enable voice control:

1. Ensure your Roborock S6 Pure is connected to the Roborock app and your home Wi-Fi.
2. Open the Amazon Alexa app.
3. Go to "Skills & Games" and search for "Roborock".
4. Enable the Roborock skill and link your Roborock account.
5. You can now use commands like: "Alexa, ask Roborock to start cleaning." or "Alexa, ask Roborock to go home."



Image: The Roborock S6 Pure robot vacuum shown alongside Amazon Echo devices, illustrating its compatibility with Amazon Alexa for voice control.

## MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the lifespan of your robot vacuum.

### 1. Dustbin and Filter

- **Empty Dustbin:** After each cleaning cycle, open the top cover, remove the dustbin, and empty its contents.
- **Clean Filter:** Tap the filter to remove dust. The filter can also be rinsed with water; ensure it is completely dry before reinserting. Clean at least once a week, or more frequently if used often.

### 2. Main Brush and Side Brush

- **Main Brush:** Remove the main brush cover and the brush itself. Use the cleaning tool provided to cut and remove any tangled hair or debris. Clean weekly.
- **Side Brush:** Check for tangled hair or debris. If necessary, remove the screw holding the side brush and clean it. Replace if damaged. Clean monthly.

### 3. Wheels and Sensors

- **Wheels:** Wipe the drive wheels and omnidirectional wheel with a dry cloth to remove dust and hair. Clean monthly.
- **Sensors:** Gently wipe all sensors (cliff sensors, wall sensor, charging contacts) with a soft, dry cloth. Clean monthly.

### 4. Mop Cloth and Water Tank

- **Mop Cloth:** Remove the mop cloth after each use and wash it thoroughly. It can be hand-washed or machine-washed.
- **Water Tank:** Empty any remaining water from the tank after each use. Rinse the tank if necessary.

## TROUBLESHOOTING

---

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Robot does not turn on.	Low battery or not charged.	Place the robot on the charging dock and ensure it is fully charged.
Robot cannot return to charging dock.	Charging dock is blocked or out of range.	Ensure the charging dock has clear space around it. Move the dock to a more central location if needed.

Problem	Possible Cause	Solution
Cleaning performance is poor.	Dustbin full, brushes tangled, or filter clogged.	Empty the dustbin, clean the main brush and side brush, and clean or replace the filter.
Robot gets stuck frequently.	Obstacles, loose cables, or dark surfaces.	Clear the cleaning area of obstacles. Use no-go zones in the app for problematic areas.
App connection issues.	Incorrect Wi-Fi password, router issues, or robot offline.	Ensure correct Wi-Fi password. Restart your router and the robot. Re-pair the robot with the app if necessary.

## SPECIFICATIONS

Feature	Detail
Model Name	S6Pure
Brand	roborock
Product Dimensions	14"L x 14"W x 4"H
Item Weight	15.17 pounds
Battery Life	Up to 180 minutes
Filter Type	Cloth
Control Method	Voice, App
Compatible Devices	Amazon Echo
Power Source	Battery Powered
Voltage	220 Volts
UPC	606015769620

## WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Roborock website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

**Online Resources:** [www.roborock.com](http://www.roborock.com)

**User Manual (PDF):** [Download PDF Manual](#)





	<a href="#">Roborock Q7 Series Robotic Vacuum Cleaner User Manual</a> Comprehensive user manual for the Roborock Q7 Series Robotic Vacuum Cleaner, detailing safety instructions, installation, app connection, operation, routine maintenance, basic parameters, environmental protection, and troubleshooting common issues.
	<a href="#">Roborock S7 Robotic Vacuum Cleaner User Manual: Setup, Operation, and Maintenance Guide</a> This comprehensive user manual for the Roborock S7 robotic vacuum cleaner details setup, operation, safety, app connectivity, maintenance, and troubleshooting. Learn to maximize your cleaning experience with this advanced home appliance from Roborock Technology Co.
	<a href="#">Roborock Qrevo Slim Robotic Vacuum Cleaner User Manual &amp; Guide</a> Comprehensive user manual for the Roborock Qrevo Slim robotic vacuum cleaner, covering setup, operation, maintenance, troubleshooting, and safety instructions.
	<a href="#">Roborock S8 MaxV Ultra Robotic Vacuum Cleaner User Manual   Setup, Operation &amp; Maintenance</a> Comprehensive user manual for the Roborock S8 MaxV Ultra robotic vacuum cleaner. Learn about setup, installation, operation, cleaning modes, routine maintenance, troubleshooting, and basic parameters.
	<a href="#">Roborock Q Revo Robotic Vacuum Cleaner User Manual</a> Comprehensive user manual for the Roborock Q Revo Robotic Vacuum Cleaner, covering installation, operation, maintenance, and troubleshooting for optimal performance.
	<a href="#">Roborock S7 Robotic Vacuum Cleaner: User Manual, Features, and Maintenance</a> Comprehensive user manual for the Roborock S7 robotic vacuum cleaner, covering setup, operation, maintenance, troubleshooting, and safety guidelines. Learn about its features, app connectivity, and warranty information.