Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Toro /
- > Toro 131-4556 Grass Bag & Frame Instruction Manual

Toro 131-4556

Toro 131-4556 Grass Bag & Frame Instruction Manual

Model: 131-4556 | Brand: Toro

INTRODUCTION

This manual provides detailed instructions for the proper installation, operation, and maintenance of your Genuine Toro 131-4556 Grass Bag & Frame Kit. This genuine OEM Toro part replaces Toro 114-2664 and is designed to fit specific Toro lawn mower models. For optimal performance and safety, please read and understand all instructions before use.

Compatibility Note: This part fits specific Toro models including 20092, 20093, 20095, 20099, 20353, 20355, 20357, 20381, 20382, 20383, 20384, 20792, 20793, 20794, 20795, 20796, 20797, 20964, 20965, 21381, 21382, 21383, 21385, 21386, 21387, 21388, 21389, 21690, 21691, 21766, 21767, 21768, 21863 Mowers. Always consult your specific lawn mower's user manual to verify the correct part number for your model and serial number range.



Image: The Toro 131-4556 Grass Bag and Frame, featuring the black mesh bag with the red Toro logo.

SETUP AND INSTALLATION

Follow these steps to replace your lawn mower's grass bag and frame:

1. Remove the Old Bag:

- · Lift up the lawn mower's rear shield.
- Unclip the bag retainers that secure the old bag to the frame.
- · Carefully slide the old bag off the frame.

2. Install the New Bag:

- Take the new Toro 131-4556 grass bag.
- Slide the frame into the new bag, ensuring it is properly seated.
- Clip the bag retainers onto the frame to secure the new bag.

3. Attach to Mower:

- · Lift up the mower's rear shield again.
- Position the assembled new bag and frame into place on the lawn mower, ensuring it locks securely.

Your browser does not support the video tag.

Video: A demonstration of how to replace a lawn mower grass bag and frame, showing the steps for removal and installation.

OPERATING INSTRUCTIONS

Once the grass bag and frame are securely installed, you can operate your lawn mower as usual. Ensure the bag is properly attached before starting the mower to prevent grass clippings from being discharged

improperly.

- Regular Emptying: For efficient grass collection and to prevent clogging, empty the grass bag regularly, especially when mowing tall or wet grass. A full bag can reduce the mower's cutting performance and increase strain on the engine.
- Safety: Always turn off the lawn mower engine and disconnect the spark plug wire before attaching, removing, or emptying the grass bag to prevent accidental starting.

MAINTENANCE

Proper maintenance of your grass bag will extend its lifespan and ensure continued performance:

- Cleaning: After each use, especially when mowing wet grass, remove the bag and shake out any remaining clippings. If necessary, rinse the bag with water and allow it to air dry completely before reattaching or storing. This prevents mold, mildew, and unpleasant odors.
- **Inspection:** Periodically inspect the bag for any tears, holes, or signs of wear. Check the frame for bends or damage. Replace the bag or frame if significant damage is found to maintain effective grass collection and safety.

TROUBLESHOOTING

If you encounter issues with your grass bag, consider the following common solutions:

· Poor Grass Collection:

- Ensure the bag is not overfilled.
- Check for blockages in the mower's discharge chute or the bag's entry point.
- Verify the bag is securely attached to the mower and the rear shield is properly closed.
- · Clean the bag mesh to ensure proper airflow.

• Bag Tearing or Damage:

- Inspect the mowing area for debris (rocks, sticks) that could be thrown into the bag.
- Ensure the bag is not dragging on the ground or rubbing against sharp edges of the mower.
- If the bag is old and worn, replacement may be necessary.

SPECIFICATIONS

Feature	Detail
Brand	Toro
Model Number	131-4556
Replaces Part Number	114-2664
Color	Black
Item Weight	6.14 pounds (2.79 Kilograms)
Product Dimensions	16 x 10.5 x 29 inches

Manufacturer	Toro
Power Source	Manual (for mower operation)
Style	Push (for mower type)

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support for your Toro 131-4556 Grass Bag & Frame, please refer to the documentation provided with your original lawn mower or visit the official Toro website. You may also contact Toro customer service directly for assistance.

© 2025 Toro. All rights reserved.

Related Documents - 131-4556

Count on It. Discontinuo II. Discontin	Toro 21in Recycler/Rear Bagging Lawn Mower Parts Catalog (Model 21332) Comprehensive parts catalog for the Toro 21in Recycler/Rear Bagging Lawn Mower, Model 21332. Includes detailed diagrams and part numbers for all assemblies: Housing, Bag, Engine, Wheels, Handle, and Attachments & Accessories.
From No. 386 SM No. 9 Counted on No. 22/2/10 Recryptoriff 15 15 15 15 15 15 15 15 15 15 15 15 15	Toro 22in Recycler Lawn Mower with SmartStow Parts Catalog Official parts catalog for the Toro 22in Recycler Lawn Mower with SmartStow, Model No. 21465. Includes detailed diagrams and part numbers for various assemblies such as housing, grass bag, engine, wheels, and handle.
TORIO Cream on R. 22th Recycler Lawn Mover B	TORO 22in Recycler Lawn Mower (Model 20372) Parts Catalog Official parts catalog for the TORO 22in Recycler Lawn Mower, Model 20372. Find part numbers, descriptions, and assembly details for your TORO mower.



Toro Lawn & Garden Range 2014 Brochure - SEO Optimized

Explore the 2014 Toro Lawn & Garden range, featuring high-performance Recycler and TimeMaster™ lawn mowers. Discover turf equipment from The Toro Company, a trusted leader with over a century of experience, designed for homeowners with large gardens. Includes information on models like 20975, 20977, and Titan Zero Turn mowers.



Toro TimeMaster 30in Lawn Mower Parts Catalog | Model 21219

Official parts catalog for the Toro TimeMaster 30in Lawn Mower (Model 21219). Find replacement parts, diagrams, and part numbers for your Toro mower.



Toro TimeMaster 30in Lawn Mower Parts Catalog

Official parts catalog for the Toro TimeMaster 30-inch lawn mower (Model 21199), featuring detailed breakdowns of all assemblies, including part numbers, quantities, and descriptions for ordering replacement components. Covers housing, spindle, engine, wheels, handle, and accessories.