

## Midea MFCD05P2NBBW

# Midea MFCD05P2NBBW 5 Cubic Feet Chest Freezer User Manual

Model: MFCD05P2NBBW | Brand: Midea

## 1. INTRODUCTION

Thank you for choosing the Midea MFCD05P2NBBW 5 Cubic Feet Chest Freezer. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read it thoroughly before use and keep it for future reference.



Image 1: The Midea MFCD05P2NBBW 5 Cubic Feet Chest Freezer in its closed state, showcasing its compact design and

white finish.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

To reduce the risk of fire, electric shock, or injury when using your freezer, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not damage the refrigerant circuit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

## 3. SETUP AND INSTALLATION

---

### 3.1 Unpacking

Carefully remove all packaging materials. Dispose of packaging responsibly. Ensure no parts are missing or damaged. Keep packaging materials away from children.

### 3.2 Location Requirements

Place the freezer on a flat, stable surface strong enough to support it when fully loaded. Allow adequate space around the freezer for proper ventilation (at least 10 cm on sides and back, 30 cm above). Avoid direct sunlight or heat sources. The dimensions of the freezer are approximately 52 cm (width) x 73 cm (depth) x 85 cm (height), and it weighs 20 kg.

### 3.3 Electrical Connection

Ensure the power supply matches the voltage requirements of the freezer (240 Volts). Plug the freezer into an exclusive, properly grounded wall outlet. Do not use extension cords or adapter plugs.

### 3.4 Initial Cleaning

Before first use, clean the interior and exterior of the freezer with a soft cloth and mild detergent. Rinse with clean water and dry thoroughly. Allow the freezer to stand upright for at least 2-4 hours before plugging it in to allow refrigerants to settle.

## 4. OPERATING YOUR FREEZER

---

### 4.1 Temperature Control

The freezer features an adjustable temperature control system. You can select the perfect temperature for your food, ranging from approximately 10°C for fruits and vegetables (when used as a refrigerator) down to -24°C for freezing your favorite foods. Locate the control knob, typically on the lower front panel, and turn it to your desired setting. Lower numbers indicate warmer temperatures, higher numbers indicate colder temperatures.

## 4.2 Security Lock

For added safety and peace of mind, the freezer is equipped with a security lock on the lid. This feature helps keep your family and home secure, preventing accidental access, especially by children, and ensuring your stored food items remain safe.

## 4.3 Internal LED Lighting

The freezer includes internal LED lighting. This illumination helps you save time and energy by making it easier to locate your food items quickly and efficiently, even in low-light conditions.



Image 2: The Midea MFCD05P2NBBW 5 Cubic Feet Chest Freezer with its lid open, revealing the spacious interior and internal components.

## 4.4 General Operation Tips

- Avoid opening the lid frequently to maintain internal temperature.
- Do not overload the freezer; allow space for air circulation.
- Ensure the lid is closed tightly after each use.

## 5. CARE AND MAINTENANCE

## 5.1 Cleaning

The freezer is designed for easy cleaning. Regularly clean the interior and exterior surfaces with a mild detergent and warm water. Avoid abrasive cleaners or sharp objects that could damage the surfaces. Ensure the freezer is unplugged before cleaning.

## 5.2 Defrosting

Over time, frost will accumulate inside the freezer. Defrost the freezer when the frost layer is about 0.5 cm thick. Unplug the unit, remove all food, and allow the frost to melt naturally. Use a soft cloth to wipe away melted water. Do not use sharp objects to remove ice.

## 5.3 Power Outage

In case of a power outage, keep the freezer lid closed. Food will remain frozen for several hours if the lid is not opened. For longer outages, consider transferring food to another freezer or using dry ice.

## 6. TROUBLESHOOTING

If you experience issues with your freezer, consult the following table for common problems and solutions:

| Problem                        | Possible Cause                                                                                               | Solution                                                                                                                    |
|--------------------------------|--------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Freezer does not operate       | Not plugged in; circuit breaker tripped; power outage.                                                       | Check power cord; reset circuit breaker; check household power supply.                                                      |
| Temperature is not cold enough | Temperature control set too warm; lid not closed properly; excessive lid openings; warm food recently added. | Adjust temperature control to a colder setting; ensure lid is sealed; reduce lid openings; allow time for new food to cool. |
| Excessive frost buildup        | Lid not sealed properly; frequent lid openings; high humidity.                                               | Check lid gasket for damage; reduce lid openings; defrost the unit.                                                         |
| Unusual noises                 | Freezer not level; objects vibrating against the unit; normal operating sounds.                              | Adjust leveling feet; move objects away from the freezer; some sounds (e.g., refrigerant flow) are normal.                  |

## 7. SPECIFICATIONS

| Feature                | Detail                |
|------------------------|-----------------------|
| Brand                  | Midea                 |
| Model Number           | MFCD05P2NBBW          |
| Color                  | White                 |
| Dimensions (W x D x H) | 52 cm x 73 cm x 85 cm |
| Capacity               | 5 Cubic Feet          |
| Voltage                | 240 Volts             |

| Feature          | Detail                  |
|------------------|-------------------------|
| Material         | Stainless-Steel         |
| Product Weight   | 20 Kilograms            |
| Door Orientation | Front (Top-opening lid) |

## 8. WARRANTY AND SUPPORT

### 8.1 Warranty Information

Midea offers a **5-year warranty on the compressor** of this product. If you are not satisfied with the performance of your Midea product, and it is registered in the program, you may contact the customer service center within a maximum period of 60 days after the product has been delivered to your home to request an exchange.




### 8.2 Customer Support

For technical assistance, warranty claims, or general inquiries, please refer to the contact information provided with your purchase documentation or visit the official Midea website for your region.

© 2025 Midea. All rights reserved.

### Related Documents - MFCD05P2NBBW

|                                                                                     |                                                                                                                                                                                                                                                                               |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p><a href="#">Midea Chest Freezer User Manual: MERC05C4BAWW, MERC07C4BAWW</a><br/> Comprehensive user manual for Midea Chest Freezers (MERC05C4BAWW, MERC07C4BAWW). Learn about safe operation, installation, maintenance, and troubleshooting for your Midea appliance.</p> |
|  | <p><a href="#">Midea MRC07M7AWW Chest Freezer User Manual</a><br/> Comprehensive user manual for the Midea MRC07M7AWW Chest Freezer, covering safety instructions, operation, installation, care, and troubleshooting for optimal use.</p>                                    |

|                                                                                    |                                                                                                                                                                                                                                                                                                                                                  |
|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     | <p><a href="#"><u>Midea Chest Freezer User Manual: MDRC280SL, MDRC405FZ, MDRC564FZ Series</u></a></p> <p>Comprehensive user manual for Midea chest freezers, covering safety warnings, proper usage, maintenance, and troubleshooting for models MDRC280SL, MDRC405FZ, and MDRC564FZ.</p>                                                        |
|    | <p><a href="#"><u>Midea Chest Freezer User Manual - MERC04C4BAWW, MERC05C4BAWW, MERC07C4BAWW</u></a></p> <p>User manual for Midea Chest Freezers (MERC04C4BAWW, MERC05C4BAWW, MERC07C4BAWW). Find detailed instructions on installation, operation, safety precautions, cleaning, maintenance, and troubleshooting for your Midea appliance.</p> |
|   | <p><a href="#"><u>Midea MRC09M4AWW Chest Freezer User Manual</u></a></p> <p>Comprehensive user manual for the Midea MRC09M4AWW Chest Freezer, covering installation, operation, safety guidelines, maintenance, and troubleshooting.</p>                                                                                                         |
|  | <p><a href="#"><u>Midea Chest Freezer User Manual</u></a></p> <p>User manual for Midea Chest Freezer, providing detailed information on safety, operation, maintenance, and troubleshooting. Includes model information and energy saving tips.</p>                                                                                              |