

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Speedlink](#) /

› [Speedlink PIAVO Wireless Ergonomic Vertical Mouse Instruction Manual](#)

### Speedlink SL-630019-BK-01

# Speedlink PIAVO Wireless Ergonomic Vertical Mouse Instruction Manual

Model: SL-630019-BK-01

## INTRODUCTION

This manual provides instructions for the Speedlink PIAVO Wireless Ergonomic Vertical Mouse (Model SL-630019-BK-01). This ergonomic mouse is designed to promote a natural, relaxed wrist posture, reducing strain on the hand, arm, shoulder, and neck during extended computer use. It features 5 buttons, adjustable DPI settings, and wireless 2.4 GHz connectivity.



**Figure 1:** Speedlink PIAVO Wireless Ergonomic Vertical Mouse, front view. This image shows the overall ergonomic design of the mouse.

## PACKAGE CONTENTS

---

Please verify that all items are present in the package:

- Speedlink PIAVO Wireless Ergonomic Vertical Mouse
- USB-A Receiver
- Battery (pre-installed or included separately)
- Instruction Manual (this document)



Figure 2: Packaging of the Speedlink PIAVO Wireless Ergonomic Vertical Mouse. The box indicates "Wireless Vertical Mouse" and "10m Range".

## SETUP

---

1. **Insert Battery:** If the battery is not pre-installed, open the battery compartment on the underside of the mouse and insert the included battery, ensuring correct polarity.
2. **Connect USB Receiver:** Locate an available USB-A port on your computer or laptop. Insert the USB-A receiver into the port.
3. **Power On Mouse:** Locate the On/Off switch on the underside of the mouse. Slide the switch to the "On" position.
4. **Driver Installation:** The mouse is designed for plug-and-play operation. Your operating system (e.g., Windows) should automatically detect and install the necessary drivers. This process typically takes a few seconds.
5. **Testing:** Once installed, move the mouse to test cursor movement. If the cursor does not respond, ensure the mouse is powered on and the USB receiver is securely connected.



**Figure 3:** Underside of the mouse, illustrating the battery compartment and the On/Off switch. Ensure the switch is in the 'On' position for operation.

## OPERATING INSTRUCTIONS

---

The Speedlink PIAVO mouse features 5 buttons and adjustable DPI settings for optimal control.

- **Left Click Button:** Standard primary click function.
- **Right Click Button:** Standard secondary click function.
- **Scroll Wheel:** For scrolling through documents and web pages. Can also be pressed for a middle-click function.
- **DPI Switch Button:** Located near the scroll wheel. Press this button to cycle through the available DPI settings (800, 1200, 1600 DPI). This adjusts the cursor speed and sensitivity.
- **Forward/Backward Buttons:** Located on the side of the mouse, typically used for navigation in web browsers or file explorers.



**Figure 4:** Top-down view of the mouse, highlighting the left/right click buttons, scroll wheel, and DPI switch button.



**Figure 5:** Side view of the mouse, illustrating the ergonomic grip and the forward/backward navigation buttons.

## **Energy Saving Mode**

The mouse features an energy-saving mode to conserve battery life. If the mouse is inactive for a period, it will enter a sleep state. To wake it up, simply move the mouse or press any button.

## MAINTENANCE

To ensure the longevity and optimal performance of your Speedlink PIAVO mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the mouse. Avoid using harsh chemicals or abrasive cleaners.
- **Sensor Cleaning:** Occasionally, dust or debris may accumulate around the optical sensor on the underside of the mouse. Use a soft brush or compressed air to gently clean the sensor area.
- **Battery Replacement:** When the mouse performance degrades or it stops responding, it may be time to replace the battery. Open the battery compartment, remove the old battery, and insert a new one of the same type, observing polarity.
- **Storage:** When not in use for extended periods, it is recommended to switch off the mouse using the On/Off switch to conserve battery life. Store the mouse and USB receiver in a dry, dust-free environment.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Mouse not responding / Cursor not moving.	Mouse is switched off. Low or depleted battery. USB receiver not properly connected. Out of range.	Ensure the On/Off switch is in the "On" position. Replace the battery. Ensure the USB receiver is fully inserted into a working USB port. Try a different USB port. Move the mouse closer to the USB receiver (within 10 meters).
Erratic cursor movement.	Dirty optical sensor. Using the mouse on an unsuitable surface.	Clean the optical sensor on the underside of the mouse. Use the mouse on a clean, non-reflective, opaque surface or a mouse pad.
DPI setting resets after sleep/reboot.	This is a known characteristic for some mice; the DPI setting may revert to default.	Press the DPI switch button to select your preferred sensitivity after waking the mouse or restarting the computer.

## SPECIFICATIONS

Model Number	SL-630019-BK-01
Connectivity	Wireless 2.4 GHz via USB-A Receiver
Movement Detection	Optical
Number of Buttons	5
DPI Settings	800, 1200, 1600 DPI (Adjustable)
Hand Orientation	Right-handed

<b>Wireless Range</b>	Up to 10 meters
<b>Power Source</b>	Battery-powered (Battery included)
<b>Compatible Operating Systems</b>	Windows
<b>Weight</b>	106 Grams
<b>Color</b>	Black

## WARRANTY AND SUPPORT

---

Information regarding specific warranty terms and customer support contact details is not available in the provided product data. Please refer to the product packaging or the manufacturer's official website for the most current warranty information and support options.

For further assistance, you may visit the [Speedlink official website](#).