

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Husla](#) /

› [Husla Electric Kettle User Manual](#)

## Husla CZAJNIK ELEKTRYCZNY HUS

# Husla Electric Kettle User Manual

Model: **CZAJNIK ELEKTRYCZNY HUS** | Brand: **Husla**

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read these instructions carefully before using your Husla Electric Kettle and retain them for future reference. Failure to follow these safety guidelines may result in fire, electric shock, or injury.

- Do not immerse the kettle, power base, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the rating label matches your mains supply voltage.
- Always unplug the kettle from the power outlet when not in use, before cleaning, and before filling or emptying.
- Keep the appliance out of reach of children and pets. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate the kettle with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use the kettle only with the supplied power base.
- Place the kettle on a firm, flat, heat-resistant surface, away from edges and heat sources.
- Do not fill the kettle above the MAX mark or below the MIN mark to prevent boiling dry or overflow.
- Avoid contact with steam escaping from the spout or lid when water is boiling.
- Do not open the lid while water is boiling.
- This kettle is for boiling water only. Do not use it for heating other liquids or food.
- Do not use abrasive cleaning agents or harsh chemicals on the kettle.

## 2. PRODUCT OVERVIEW

---

The Husla Electric Kettle is designed for efficient and safe water boiling. It features a durable stainless steel body with a stylish grey finish and a comfortable wooden-look handle.



**Figure 2.1:** Front view of the Husla Electric Kettle, showcasing its sleek grey body, wooden-look handle, and spout.



**Figure 2.2:** Side view of the kettle, highlighting the integrated power indicator and the base connection point.



**Figure 2.3:** Top-down view showing the stainless steel interior of the kettle and the removable lid.



Figure 2.4: Angled view of the kettle, providing a comprehensive look at its design and components.

### 3. SETUP

---

1. **Unpack:** Carefully remove the kettle and its power base from the packaging. Dispose of all packaging materials responsibly.
2. **First Use Cleaning:** Before first use, or if the kettle has been stored for a long period, fill the kettle with clean water to the MAX level. Boil the water, then discard it. Repeat this process two to three times to remove any manufacturing residues.
3. **Positioning:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the power

cord is not dangling where it can be tripped over or pulled.

4. **Connect Power:** Plug the power cord into a suitable grounded electrical outlet.

## 4. OPERATING INSTRUCTIONS

---

1. **Fill the Kettle:** Remove the kettle from its power base. Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below the MIN mark or above the MAX mark (1.5 Litres).
2. **Close the Lid:** Ensure the lid is securely closed before placing the kettle back on its base.
3. **Place on Base:** Position the kettle firmly onto its power base.
4. **Switch On:** Press the ON/OFF switch located on the handle or base. The indicator light will illuminate, signaling that the kettle is heating.
5. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off.
6. **Pouring:** Carefully lift the kettle from the base and pour the hot water. Be cautious of hot steam.
7. **Re-boiling:** If you need to re-boil, wait a few moments for the thermostat to reset before pressing the switch again.

## 5. MAINTENANCE AND CLEANING

---

Regular cleaning will help maintain the performance and longevity of your kettle.

- **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
- **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas.
  - Fill the kettle with a mixture of one part white vinegar and two parts water.
  - Boil the mixture and let it stand for at least 30 minutes, or longer for heavy scale.
  - Pour out the mixture and rinse the interior thoroughly with fresh water several times.
  - For stubborn deposits, a non-abrasive descaling solution designed for kettles can be used following the product's instructions.
- **Storage:** When not in use, store the kettle in a clean, dry place. You can wrap the power cord around the base for neat storage if a cord wrap feature is present.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Kettle does not turn on.	<p>Not plugged in.</p> <p>Power outlet is not working.</p> <p>Kettle not properly seated on base.</p> <p>Switch not pressed.</p> <p>Kettle has boiled dry (safety cut-off activated).</p>	<p>Ensure the plug is fully inserted into the outlet.</p> <p>Test the outlet with another appliance.</p> <p>Ensure the kettle is correctly placed on the power base.</p> <p>Press the ON/OFF switch firmly.</p> <p>Unplug, let cool for 15 minutes, then refill and try again.</p>
Water not boiling or taking too long.	<p>Limescale buildup.</p> <p>Kettle overfilled.</p>	<p>Descal the kettle as per "Maintenance and Cleaning" section.</p> <p>Do not fill above the MAX mark.</p>
Water leaking from the kettle.	<p>Lid not closed properly.</p> <p>Kettle overfilled.</p>	<p>Ensure the lid is securely closed.</p> <p>Do not fill above the MAX mark.</p>

## 7. TECHNICAL SPECIFICATIONS

<b>Brand</b>	Husla
<b>Model</b>	CZAJNIK ELEKTRYCZNY HUS
<b>Capacity</b>	1.5 Litres
<b>Material</b>	Stainless steel
<b>Color</b>	Grey
<b>Special Feature</b>	Portable
<b>Voltage</b>	230 Volts
<b>Finish Type</b>	Painted
<b>Product Dimensions (L x W x H)</b>	24 cm x 24 cm x 25.5 cm
<b>Power</b>	20000 Watts <i>(Note: This value is as provided in product specifications. Typical kettle power is 1500-2200W.)</i>

## 8. WARRANTY AND SUPPORT INFORMATION

Your Husla Electric Kettle is manufactured to high-quality standards. For information regarding warranty

coverage, please refer to the warranty card included with your purchase or the terms and conditions provided by your retailer at the time of purchase.

For technical support, troubleshooting assistance beyond this manual, or spare parts inquiries, please contact the Husla customer service department or your authorized retailer. Contact details can typically be found on the product packaging or the brand's official website.

*Please retain your proof of purchase for any warranty claims.*