

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [WallarGe](#) /

> [WallarGe 14.5" Large Digital Wall Clock User Manual](#)

## WallarGe CL5003

# WallarGe 14.5" Large Digital Wall Clock User Manual

Model: CL5003 | Brand: WallarGe

## INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your WallarGe 14.5" Large Digital Wall Clock. Designed for clarity and ease of use, this clock features a high-definition LCD screen displaying time, temperature, and date with jumbo numbers for excellent readability from a distance. It is battery-operated for flexible placement and includes an automatic Daylight Saving Time (DST) adjustment feature.



**Figure 1:** Front view of the WallarGe 14.5" Large Digital Wall Clock, showcasing its large, easy-to-read display with time, day, month, date, and temperature.

## SETUP

### 1. Battery Installation

The clock requires 4xAA batteries (not included). Locate the battery compartment on the back of the clock. Open the

cover, insert the batteries according to the polarity indicators (+/-), and close the cover securely. A low battery indicator will appear on the screen when replacement is needed.




Figure 2: Rear view of the clock, highlighting the battery compartment and the fold-out stand. The battery compartment requires 4xAA batteries.

## 2. Placement Options

Your WallarGe digital clock offers versatile placement options:

- **Wall Mount:** Use the two mounting holes on the back of the clock. A mounting template ruler is included to assist with accurate hole placement (8.7 inches distance between holes).
- **Desk/Tabletop:** Unfold the integrated stand located on the back of the clock to prop it up on any flat surface.

## OPERATING INSTRUCTIONS

All function buttons are located on the back of the clock for easy access and setting.

## 1. Setting Time and Date

1. Press the "SET" button to enter setting mode.
2. Use the "+/12/24" and "-/°C/°F" buttons to adjust the values (e.g., hour, minute, year, month, date).
3. Press "SET" again to confirm each setting and move to the next parameter.
4. Continue until all desired settings (time, year, month, date) are configured.

## 2. Display Modes (Day/Temperature)

The clock offers three selectable display modes for the day and temperature information. Press the dedicated button on the back to cycle through these options:

- **Mode 1:** Day only (e.g., SUN)
- **Mode 2:** Temperature only (e.g., 80.6°F)
- **Mode 3:** Day and Temperature switch every 10 seconds.



**Figure 3:** Visual representation of the three display modes for day and temperature, allowing users to customize their preferred information display.

### 3. Automatic Daylight Saving Time (AUTO DST)

The clock features an AUTO DST function that automatically adjusts the time forward or backward by one hour during Daylight Saving Time transitions. This feature can be turned off manually if not required.




**Figure 4:** Illustration of the automatic Daylight Saving Time adjustment feature, showing how the clock shifts time by one hour for "Fall Back" and "Spring Forward."

### 4. Standard/Military Time Mode Switchable

You can switch between 12-hour (AM/PM) and 24-hour (Military) time formats using the appropriate button on the back of the clock.

## Standard/Military Time Mode Switchable (Optional Alarm Function)



Standard Time  
(AM/PM)



Military Time  
(24Hr)




Figure 5: The clock's display showing both 12-hour (Standard Time with AM/PM indicator) and 24-hour (Military Time) formats, demonstrating the switchable feature.

### 5. Alarm and Timer Functions

The clock includes optional alarm and timer functions. Refer to the specific buttons on the back labeled "Alarm Set" and "Timer" for detailed setup. The timer can be cleared by pressing the "Timer:clear" button.

## MAINTENANCE

### 1. Battery Replacement

When the low battery indicator appears on the display, replace all 4xAA batteries promptly to ensure continuous and accurate operation. Always use new batteries and dispose of old ones responsibly.

### 2. Cleaning

To clean the clock, gently wipe the display and casing with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as

these may damage the surface.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Display is blank or dim.	Low or no batteries; incorrect battery insertion.	Replace batteries with new 4xAA batteries. Ensure correct polarity.
Time is incorrect.	Time not set correctly; DST setting incorrect.	Manually set the time and date. Check AUTO DST setting.
Temperature reading is inaccurate.	Clock placed near heat/cold source; sensor obstruction.	Relocate the clock to a stable room temperature environment. Ensure sensor is clear.
Buttons are unresponsive.	Temporary software glitch; low batteries.	Remove and reinsert batteries to reset the clock. Replace batteries if low.

## SPECIFICATIONS

---

- **Model:** CL5003
- **Display Type:** Digital LCD
- **Product Dimensions:** 14"W x 6"H (35.56 cm x 15.24 cm)
- **Time Display Size:** 8.1" x 4.3" (20.57 cm x 10.92 cm)
- **Power Source:** 4xAA Batteries (not included)
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Special Features:** Large Display, Temperature Display, Daylight Saving (AUTO DST), Foldable Stand, Battery Indicator, Day of the Week, Calendar
- **Indoor/Outdoor Usage:** Indoor
- **Item Weight:** 1.63 pounds (0.74 kg)
- **Temperature Range:** -14°F to 99.9°F (-9.9°C to 37.7°C)
- **Temperature Sensor Accuracy:** +/- 0.1°F
- **Temperature Update Frequency:** Every 10 seconds

# Large LCD Clock with Big Numbers



Figure 6: Detailed dimensions of the WallarGe clock, indicating its overall width and height, as well as the size of the digital display area.

## WARRANTY AND SUPPORT

WallarGe is committed to providing high-quality products. For any questions, concerns, or support needs regarding your digital wall clock, please contact the seller directly through your purchase platform. Please retain your proof of purchase for any warranty claims.