



Manuals.plus /

› Aigostar /

› Aigostar Elsa Evaporative Air Cooler User Manual

Aigostar Elsa

Aigostar Elsa Evaporative Air Cooler User Manual

MODEL: ELSA

Safety Instructions
Product Components
Setup
Operation
Maintenance
Troubleshooting
Specifications
Warranty & Support

Product Overview

The Aigostar Elsa Evaporative Air Cooler is designed to provide a comfortable indoor environment through its cooling, purification, and humidification functions. This unit utilizes water evaporation to lower ambient temperatures, offering an energy-efficient alternative to traditional air conditioners. It features multiple modes and speeds, a convenient timer, and remote control operation for ease of use.



Image: The Aigostar Elsa Evaporative Air Cooler, showcasing its sleek design, air output, and included remote control and ice boxes.

Important Safety Instructions

Please read all instructions carefully before using this appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is placed on a stable, level surface to prevent tipping.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug the appliance from the power outlet when not in use, before filling or emptying the water tank, and before cleaning or performing any maintenance.
- Keep the appliance out of reach of children and pets.
- Do not block the air inlets or outlets. Ensure adequate space around the unit for proper airflow.
- Use only clean tap water in the water tank. Do not add any chemicals or additives other than the provided ice boxes.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Do not operate the appliance if it has been dropped or damaged in any manner.

Product Components

Familiarize yourself with the main parts of your Aigostar Elsa Evaporative Air Cooler:

- **Control Panel:** Located on the top of the unit for manual operation.
- **Air Outlet:** Front grille where cooled air is discharged.
- **Water Tank:** Removable tank at the bottom for water and ice boxes.
- **Dust-proof Bracket/Filter:** Located at the rear, filters incoming air.
- **Remote Control:** For convenient operation from a distance.
- **Ice Boxes:** Two reusable ice boxes included to enhance cooling.
- **Wheels:** Four omnidirectional wheels for easy mobility.



Image: Detailed view of the top control panel, showing the digital display and various function buttons for mode, timer, purify, power, cool, swing, and speed.



Image: The rear of the unit, highlighting the removable dust-proof bracket, the water tank access, and the two included ice boxes.

Setup and Initial Use

1. **Unpacking:** Carefully remove the air cooler from its packaging. Check for any damage during transit.
2. **Attach Wheels:** If not already attached, insert the four wheels into the designated slots at the bottom of the unit until they click into place.
3. **Fill Water Tank:**
 - Pull out the water tank from the rear of the unit.
 - Fill the tank with clean tap water. Do not exceed the 'MAX' fill line. The tank has a 7-liter capacity.
 - For enhanced cooling, place the two included ice boxes (after freezing them) into the water tank.
 - Carefully push the water tank back into the unit until it is securely in place.



Image: Illustrates the process of filling the water tank, highlighting the water cooling system.



Image: Shows the 7-liter water tank capacity and the water tank knob for secure closure.

4. **Placement:** Position the air cooler on a firm, level surface in the desired room. Ensure it is near a power outlet and has clear space around it for optimal airflow.
5. **Power Connection:** Plug the power cord into a standard electrical outlet.

Operating Instructions

The Aigostar Elsa can be operated using either the control panel on top of the unit or the included remote control.

Control Panel Functions:

- **ON/OFF (Power Button):** Press to turn the unit on or off.
- **MODE:** Cycles through different operating modes (Normal, Natural, Sleep).
- **SPEED:** Adjusts fan speed (Low, Mid, High).
- **COOL:** Activates the evaporative cooling function. Ensure water is in the tank.
- **SWING:** Activates the automatic horizontal oscillation of the internal louvers. Vertical louvers can be adjusted manually.
- **TIMER:** Sets the operating time from 1 to 12 hours.
- **PURIFY:** Activates the air purification function.

Remote Control Usage:

The remote control allows you to operate all functions from a distance of up to 5 meters.



Image: A user operating the air cooler with the remote control, demonstrating its convenience.

Airflow Adjustment:

- **Horizontal Swing:** Press the 'SWING' button on the control panel or remote for automatic left-to-right oscillation.
- **Vertical Adjustment:** Manually adjust the vertical louvers on the front grille to direct airflow up or down as desired.



Image: Illustrates how to manually adjust the vertical airflow and the automatic horizontal swing controlled by the remote.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your air cooler.

- 1. Before Cleaning:** Always unplug the appliance from the power outlet before cleaning or performing any maintenance.
- 2. Cleaning the Water Tank:**
 - Empty any remaining water from the tank.
 - Remove the water tank from the unit.
 - Clean the tank with a soft cloth and mild detergent. Rinse thoroughly with clean water.
 - Allow the tank to air dry completely before reinserting.
 - It is recommended to clean the water tank at least once a week, or more frequently if used continuously.
- 3. Cleaning the Dust-proof Bracket/Filter:**
 - Locate the dust-proof bracket at the rear of the unit.
 - Carefully remove the bracket.

- Clean the filter with a soft brush or vacuum cleaner to remove accumulated dust. For deeper cleaning, wash with water and mild detergent, then rinse and dry completely.
 - Reattach the dust-proof bracket securely.
4. **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
 5. **Storage:** If storing the unit for an extended period, ensure the water tank is empty and clean, and the unit is dry. Store in a cool, dry place away from direct sunlight.

Troubleshooting Guide

Before contacting customer support, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; Power button not pressed; Remote control batteries depleted.	Check power cord connection and outlet; Press the ON/OFF button; Replace remote control batteries.
No cool air/Insufficient cooling.	Water tank empty; COOL function not activated; Ice boxes not frozen or used; Room humidity too high.	Fill water tank; Activate COOL function; Use frozen ice boxes; Evaporative coolers are less effective in high humidity.
Water leaking from the unit.	Water tank overfilled; Water tank not properly seated; Unit is tilted.	Do not exceed 'MAX' fill line; Ensure water tank is securely pushed in; Place unit on a level surface.
Weak airflow.	Dust filter clogged; Air inlets/outlets blocked; Fan speed set too low.	Clean the dust filter; Ensure clear space around the unit; Increase fan speed.
Unusual noise.	Unit not level; Foreign object inside; Water pump issue.	Place unit on a level surface; Unplug and check for obstructions (if safe); Contact customer support if noise persists.

Technical Specifications

- **Brand:** Aigostar
- **Model Name:** Elsa
- **Power Consumption:** 75 Watts
- **Water Tank Capacity:** 7 Liters
- **Control Type:** Remote control, Buttons
- **Special Features:** Timer (1-12h), Air Purification, Oscillation (Swing)
- **Modes:** 3 (Normal, Natural, Sleep)
- **Speeds:** 3 (Low, Mid, High)
- **Noise Level:** 70 dB
- **Dimensions (L x W x H):** 36 x 36 x 76 cm
- **Weight:** 8.24 kg
- **Included Components:** Remote control, 2 Ice Boxes
- **Mounting Type:** Freestanding

Warranty and Customer Support

Aigostar products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. The specific warranty period may vary by region and retailer.

For warranty claims, technical assistance, or any questions regarding your Aigostar Elsa Evaporative Air Cooler, please contact Aigostar customer support through their official website or the retailer from whom you purchased the product. Please have your model number and purchase receipt ready when contacting support.

You can find more information and contact details on the official Aigostar website: www.aigostar.com