

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [COSTWAY](#) /

› [COSTWAY Water Cooler Dispenser Instruction Manual](#)

COSTWAY LM-YL1-109B

COSTWAY Water Cooler Dispenser Instruction Manual

Model: LM-YL1-109B

1. PRODUCT OVERVIEW

The COSTWAY Water Cooler Dispenser is designed to provide convenient access to both hot and cold water from 3-5 gallon bottles. Featuring compression refrigeration technology, a child safety lock for hot water, and a practical storage cabinet, this top-loading dispenser is suitable for home or office use.



Figure 1: Front view of the COSTWAY Water Cooler Dispenser with a water bottle installed.

Key Features:

- **Hot & Cold Water:** Provides instant hot water (190°F-203°F) and chilled cold water (43°F-50°F) with separate

on/off switches for energy saving.

- **Top Loading Design:** Compatible with standard 3-5 gallon water bottles for easy replacement.
- **Child Safety Lock:** A security lock on the hot water tap prevents accidental dispensing and ensures safety.
- **Integrated Storage Cabinet:** A convenient compartment at the bottom for storing cups or small items.
- **Easy Maintenance:** Features a detachable anti-dust mite water barrel seat and a removable drip tray for simple cleaning.
- **Durable Construction:** Made from Acrylonitrile Butadiene Styrene (ABS) for longevity and easy cleaning.

2. SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove the water cooler from its packaging. Inspect for any damage.
2. **Placement:** Place the dispenser on a flat, stable surface away from direct sunlight and heat sources. Ensure adequate ventilation around the back of the unit.
3. **Initial Cleaning:** Before first use, clean the water barrel seat and drip tray with mild soap and warm water. Rinse thoroughly.
4. **Install Water Bottle:**
Remove the cap from a 3 or 5-gallon water bottle. Carefully lift the bottle and place it inverted onto the top-loading water barrel seat. Ensure the bottle is seated firmly and water begins to flow into the dispenser's internal reservoirs.



Anti-Dust Mite Water Barrel Seat

- The seat is detachable for easy cleaning
- Anti-dust mite design ensures the sanitation of drinking water

Removable Drip Tray

- Easy to move it and clean it with soap water



Figure 2: Proper placement of the water bottle on the dispenser.

5. **Connect Power:** Plug the power cord into a grounded electrical outlet (110V/60Hz).
6. **Activate Heating/Cooling:** Locate the ON/OFF switches for hot and cold water on the back of the unit. Turn them to the "ON" position. Allow approximately 15-30 minutes for the water to reach optimal hot and cold temperatures before dispensing.
7. **Important Safety Tip:** *Do not heat water without a water bottle installed or with very little water remaining in the bottle. This can damage the heating element.*

3. OPERATING INSTRUCTIONS

The COSTWAY Water Cooler Dispenser is designed for simple and safe operation.

Dispensing Cold Water:

- Place your cup or container under the blue cold water tap.
- Push the blue lever down to dispense cold water. Release the lever to stop the flow.

Dispensing Hot Water (with Child Lock):

- Place your cup or container under the red hot water tap.
- To dispense hot water, you must first push the red safety lock button inward, then simultaneously push the red lever down.
- Release both the button and the lever to stop the flow. This two-step process prevents accidental hot water dispensing, especially important for households with children.



Figure 3: Hot water tap with integrated child safety lock.

Control Panel Indicators:

- The control panel features indicator lights for "HOT", "POWER", and "COLD" to show the status of the heating, power, and cooling functions.

Storage Cabinet:

The bottom section of the dispenser includes a small storage cabinet. This space is ideal for keeping disposable cups or other small accessories conveniently within reach, promoting hygiene in public or shared environments.



Large Capacity

Compatible with 3 or 5 Gallon Bottles



Figure 4: Open storage cabinet at the base of the dispenser.

4. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and hygienic operation of your water cooler dispenser.

1. Drip Tray Cleaning:

The drip tray is removable for easy cleaning. Simply slide it out, rinse it with gentle soap and warm water, and

dry thoroughly before replacing.



Figure 5: Removable drip tray for easy cleaning.

2. Water Barrel Seat Cleaning:

The anti-dust mite water barrel seat is detachable. Lift it off the dispenser, clean it with mild soap and water, and ensure it is completely dry before reattaching. This helps maintain water sanitation.

3. Exterior Cleaning:

Wipe the exterior ABS body of the dispenser with a damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.

4. Internal Cleaning (Periodically):

For thorough internal cleaning, it is recommended to consult the manufacturer's specific guidelines or a qualified service technician. This typically involves draining the reservoirs and sanitizing the internal components.

5. TROUBLESHOOTING

If you encounter issues with your water cooler dispenser, please refer to the following common troubleshooting tips. For persistent problems, contact customer support.

- **No Water Dispensing:**

- Ensure the water bottle is properly seated and not empty.
- Check if the dispenser is plugged into a working power outlet.
- Verify that the hot/cold switches on the back are in the "ON" position.

- **Water Not Hot/Cold Enough:**

- Allow sufficient time (15-30 minutes) after plugging in or replacing the bottle for temperatures to stabilize.
- Ensure the hot/cold switches on the back are "ON".
- Check if the unit is placed in an area with proper ventilation and not exposed to extreme temperatures.

- **Unusual Noises:**

- A slight humming sound from the compressor is normal.
- Ensure the unit is on a level surface to prevent vibrations.
- If noises are loud or unusual, unplug the unit and contact customer support.

- **Leaking:**

- Check the water bottle for cracks or damage.
- Ensure the water bottle is correctly seated on the dispenser.
- Inspect the drip tray for overflow.
- If leaking persists, discontinue use and contact customer support.

6. SPECIFICATIONS

Attribute	Detail
Brand	COSTWAY
Model Number	LM-YL1-109B
Color	White
Material	Acrylonitrile Butadiene Styrene (ABS)
Capacity	3-5 Gallon Bottles
Product Dimensions (D x W x H)	11"D x 12"W x 32"H
Item Weight	24 pounds
Wattage	500 watts
Installation Type	Freestanding

Attribute	Detail
Access Location	Top
Number of Settings	2 (Hot, Cold)
Hot Water Temperature	Up to 203°F (95°C)
Cold Water Temperature	As low as 43°F (6°C)
Power Source	Corded Electric



Color	White	Voltage	110V/60Hz
Cooling power	80 W	Heating power	500 W
Net Weight	20 lbs	Settings	Cold/ Hot

Figure 6: Product dimensions and key specifications.

7. WARRANTY AND SUPPORT

For specific warranty details and customer support, please refer to the documentation included with your product or visit the official COSTWAY website. You can also find more information and contact options through the [COSTWAY Brand Store on Amazon](#).

Please retain your proof of purchase for any warranty claims or support inquiries.