

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [MOYAGOA](#) /

> [TOPVISION T6 Projector User Manual](#)

## MOYAGOA T6

# TOPVISION T6 Projector User Manual

Brand: MOYAGOA | Model: T6

## 1. SETUP GUIDE

This section provides instructions for setting up your TOPVISION T6 Projector for the first time.

### 1.1 Unboxing and Components

Carefully remove all components from the packaging. Ensure all items listed in the packing list are present.



Figure 1: TOPVISION T6 Projector with included 100-inch projection screen.

## 1.2 Connecting Your Devices

The TOPVISION T6 Projector offers multiple connectivity options for various devices.




Figure 2: Connecting a smartphone to the projector using an HDMI adapter (adapter not included).

- **HDMI:** Connect your laptop, game console (PS4), Fire Stick, or other HDMI-enabled devices using an HDMI cable. The projector has multiple HDMI ports.
- **USB:** Insert a USB drive to play media files directly.
- **VGA:** Use a VGA cable to connect older computers or devices.
- **AV:** Connect legacy devices using the AV input.
- **TF Card:** Insert a TF (MicroSD) card for direct media playback.
- **Smartphone Connection:** For smartphones, an additional HDMI adapter (Lightning to HDMI for Apple, Micro USB/Type C to HDMI for Android) is required.

Video 1: Official product video demonstrating the TOPVISION T6 Home Theater Projector's features and connectivity options.

## 2. OPERATING INSTRUCTIONS

Learn how to operate your TOPVISION T6 Projector for optimal viewing experience.

### 2.1 Powering On/Off

- To power on, connect the power cable and press the power button on the projector or remote control.
- To power off, press the power button again. The projector will enter standby mode.

### 2.2 Focus and Keystone Adjustment

Adjust the image clarity and shape using the focus and keystone correction dials located on the top of the projector.



Figure 3: Use the dials to adjust image focus and correct trapezoidal distortion (keystone).

- **Focus:** Rotate the focus dial until the projected image is sharp and clear.
- **Keystone Correction:** Adjust the keystone dial to correct any trapezoidal distortion, ensuring a rectangular image. The projector supports  $\pm 15^\circ$  keystone correction.

## 2.3 Screen Size and Zoom Function

The projector supports a display size of up to 240 inches. You can also adjust the image size digitally.



Figure 4: The projector can project a large image up to 240 inches for an immersive experience.

- **Digital Zoom:** Use the remote control to access the 50%-100% zoom function, allowing you to adjust the image size without moving the projector.

## 2.4 Audio Settings

The projector features built-in HI-FI stereo speakers. For enhanced audio, connect external speakers.



Figure 5: Built-in HiFi speakers provide clear stereo sound.

- **Built-in Speakers:** The integrated speakers provide sufficient audio for most uses.
- **External Audio:** Connect external speakers or headphones via the 3.5mm audio output port for a more powerful or private listening experience.

### 3. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your projector.

#### 3.1 Cleaning the Lens

Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Avoid abrasive materials or harsh chemicals.

#### 3.2 Ventilation and Cooling

The projector is equipped with a dual-fan cooling system to prevent overheating. Ensure proper ventilation by keeping the air inlets and outlets clear of obstructions.



Figure 6: The powerful cooling system helps maintain optimal operating temperature and reduces noise.

#### 3.3 Lamp Life

The projector lamp has an estimated life of 60,000 hours, providing long-term usage without frequent lamp replacement.

## 4. TROUBLESHOOTING

This section addresses common issues you might encounter with your projector.

- **Blurry Image:** Adjust the focus and keystone correction dials. Ensure the projector is placed on a stable, level surface. If edges are blurry, this can be normal for some projection angles.
- **No Sound:** Check the volume settings on both the projector and the connected device. Ensure external speakers are properly connected if used.
- **No Signal/Connection Issues:** Verify that the correct input source is selected on the projector. Check all cable connections (HDMI, USB, VGA, AV) for secure fit. For smartphone connections, ensure the correct HDMI adapter is used and functioning.
- **Image Too Dim:** Ensure the room is sufficiently dark for optimal viewing, especially during daytime.

## 5. SPECIFICATIONS

| Feature                 | Detail  |
|-------------------------|---|
| Model Number            | T6  |
| Brand                   | MOYAGOA   |
| Manufacturer            | TOPVISION   |
| Product Dimensions      | 8.6 x 6.2 x 3.7 inches  |
| Item Weight             | 4.8 pounds  |
| Display Resolution      | 1920 x 1080 (1080P Supported)                                       |
| Visible Screen Diagonal | 100 inches / 254 cm   |
| Connectivity Technology | Bluetooth, Wi-Fi, USB, HDMI, VGA, AV, TF Card                       |
| Special Features        | Built-In Speaker, Portable, Built-In Cooling System, Built-In Wi-Fi |
| Recommended Uses        | Home Cinema, Gaming   |
| Lamp Life               | 60,000 hours  |

## 6. WARRANTY AND SUPPORT

---

For warranty information and further support, please refer to the official product documentation or contact MOYAGOA customer service.

An official User Manual (PDF) is available for download: [Download User Manual \(PDF\)](#)