



[Manuals.plus](#) /

> [John Timberland](#) /

> John Timberland Arrington Outdoor Wall Light Fixture (Model 77M05) Instruction Manual

John Timberland 77M05

John Timberland Arrington Outdoor Wall Light Fixture Instruction Manual

Model: 77M05

INTRODUCTION

Thank you for choosing the John Timberland Arrington Outdoor Wall Light Fixture. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: Risk of Electric Shock. Disconnect power at the circuit breaker or fuse box before installation or servicing.

- All electrical connections must be in accordance with local codes and ordinances, National Electric Code (NEC), and ANSI/NFPA 70-1999.
- Consult a qualified electrician if you are unsure about proper installation.
- Use only UL or ETL listed wire connectors.
- Do not exceed the maximum wattage specified for the bulb.
- Ensure the fixture is securely mounted to a structural element.
- Wear safety glasses and gloves during installation.

PACKAGE CONTENTS

Verify that all components are present before discarding packaging materials.

- Arrington Outdoor Wall Light Fixture (2 units)
- Mounting Hardware (screws, wire nuts)
- Instruction Manual

Note: Light bulbs are not included and must be purchased separately.

SPECIFICATIONS

Model Number	77M05
Dimensions (each)	13" High x 6.75" Wide (top) x 8" Wide (bottom) x 8.75" Extension from wall
Backplate Dimensions	7" High x 5" Wide
Weight (each)	4.99 lbs
Material	Alloy Steel, Clear Glass
Finish	Mystic Black
Bulb Type	Standard-medium base (E26)
Max Wattage	60 Watts (per bulb)
Voltage	120 Volts
Usage	Outdoor, Wall Mount, Vertical Installation Only
Water Resistance	Water Resistant



This diagram provides key measurements for the Arrington wall light, including its height (13 inches), width (8 inches), and how far it extends from the wall (8.75 inches). The backplate dimensions are also indicated.

SETUP AND INSTALLATION

Professional installation is recommended for electrical fixtures. If you are performing the installation yourself, ensure you follow all safety guidelines and local electrical codes.

1. **Turn Off Power:** Before starting, turn off the electricity at the main fuse box or circuit breaker to prevent electrical shock.
2. **Prepare Mounting Surface:** Ensure the wall surface is clean, dry, and structurally sound to support the fixture's weight.
3. **Attach Mounting Plate:** Secure the mounting plate (usually pre-attached to the fixture or included separately) to the

electrical junction box using the provided screws.

4. Make Electrical Connections:

- Connect the fixture's black wire to the house's black (hot) wire.
- Connect the fixture's white wire to the house's white (neutral) wire.
- Connect the fixture's ground wire to the house's ground wire (or to the mounting plate if no house ground is available).
- Secure all connections with wire nuts and wrap with electrical tape for added safety.

5. Mount the Fixture: Carefully align the fixture with the mounting plate and secure it using the provided screws. Ensure the fixture is installed vertically as shown in product images.

6. Install Bulbs: Insert two standard-medium base (E26) bulbs, up to 60 watts each (not included), into the sockets. Edison-style filament bulbs are recommended for aesthetic appeal.

7. Restore Power: Once installation is complete and all connections are secure, turn the electricity back on at the circuit breaker.



This image displays two Arrington outdoor wall light fixtures, showcasing their rustic modern design with clear glass panels and a mystic black finish. The fixtures are designed for exterior wall mounting.



A side profile of the Arrington wall light, showing its depth and the sturdy black metal frame, ready for vertical installation.

OPERATING INSTRUCTIONS

The John Timberland Arrington Outdoor Wall Light Fixture operates via your home's standard wall switch. Once installed and powered, simply use the connected wall switch to turn the lights on or off.

- **Bulb Replacement:** To replace a bulb, ensure the power is turned off at the circuit breaker. Allow the old bulb to cool completely before unscrewing it. Insert a new E26 base bulb (up to 60 watts) into the socket.



A detailed view of the Edison-style filament bulb (not included) within the Arrington fixture, highlighting the clear glass shade and the bulb's warm glow.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your outdoor wall light.

- **Cleaning:** Clean the fixture with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.
- **Inspection:** Periodically inspect the fixture for any signs of wear, damage, or loose connections. Address any issues

promptly.

- **Weather Resistance:** While the fixture is water-resistant, extreme weather conditions may require additional inspection.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty bulb.	Check circuit breaker or fuse. Verify all wire connections are secure (with power off). Replace bulb with a new one.
Light flickers.	Loose bulb. Loose wire connection. Incorrect bulb type/wattage.	Tighten bulb. Check wire connections (with power off). Ensure bulb meets specifications.

WARRANTY AND SUPPORT

This John Timberland Arrington Outdoor Wall Light Fixture comes with a **Limited 1-Year Warranty** from the manufacturer, Lamps Plus. This warranty covers defects in materials and workmanship under normal use. For warranty claims, technical support, or any questions regarding your product, please contact Lamps Plus customer service directly. Please have your model number (77M05) and proof of purchase available.

PRODUCT VIDEO OVERVIEW

Your browser does not support the video tag.

This video provides an overview of John Timberland's classic outdoor lighting styles, including porch and patio lighting, and fountains. It showcases the brand's design philosophy and range of products.