

Gardena Aquazoom M

Gardena Oscillating Sprinkler Aquazoom M

Model: 18712-34

Instruction Manual

1. INTRODUCTION

Thank you for choosing the Gardena Oscillating Sprinkler Aquazoom M. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your sprinkler to ensure efficient and effective watering of your lawn or garden. Please read these instructions carefully before first use and keep them for future reference.

2. SETUP

Follow these steps to set up your Gardena Oscillating Sprinkler Aquazoom M:

1. **Unpack:** Carefully remove the sprinkler from its packaging. Ensure all components are present.
2. **Positioning:** Place the sprinkler on a flat, stable surface within the area you intend to water. Ensure it is not obstructed by plants or other objects.
3. **Hose Connection:** Connect a standard garden hose to the sprinkler's inlet connector. The design allows for easy assembly and a secure hose connection.
4. **Water Supply:** Turn on the water supply gradually to avoid sudden pressure surges.



Image 1: The Gardena Aquazoom M sprinkler in operation, demonstrating water coverage and showing the adjustment sliders.

The sprinkler is designed for stability and efficient water distribution across your lawn.

3. OPERATING

The Aquazoom M offers precise control over the watering area:

- **Adjusting Spray Width:** Use the red sliders on the side of the sprinkler to set the desired spray width. Move them inwards to narrow the spray or outwards to widen it.
- **Adjusting Spray Length:** The black sliders at each end of the sprinkler control the watering length. Adjust these to define the start and end points of the oscillating spray.
- **Watering Area:** The sprinkler is capable of watering areas up to 250m² (approximately 2690 sq ft), providing even and precise watering.
- **Water Flow:** Ensure adequate water pressure for optimal performance. The sprinkler is designed to deliver an even water pattern across the entire adjusted area.

Refer to Image 1 in the Setup section for a visual representation of the adjustment controls.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your sprinkler:

- **Nozzle Cleaning:** The soft plastic nozzles are designed for easy cleaning. If a nozzle becomes clogged, gently rub it with your finger or a soft brush to dislodge any debris. Do not use sharp objects.
- **Filter Cleaning:** Periodically check and clean the filter located at the hose connection point to prevent blockages from sediment in the water supply.
- **Winter Storage:** Before the first frost, disconnect the sprinkler from the hose and drain all water from it. Store the sprinkler in a frost-free, dry location to protect it from frost damage. The sprinkler is designed with frost and UV protection, but proper storage is recommended for extended lifespan.
- **UV Protection:** The materials used in the sprinkler are UV-resistant, ensuring durability even with prolonged exposure to sunlight.

5. TROUBLESHOOTING

If you encounter issues with your sprinkler, consider the following common solutions:

- **Uneven Spray Pattern:**
 - Check for clogged nozzles and clean them as described in the Maintenance section.
 - Ensure adequate water pressure. Low pressure can result in a reduced and uneven spray.
 - Verify that the sprinkler is placed on a level surface.
- **Reduced Watering Distance:**
 - Confirm that the water supply valve is fully open.
 - Inspect the hose for kinks or leaks that might reduce water pressure.
 - Clean the inlet filter to ensure unrestricted water flow.
- **Sprinkler Not Oscillating:**
 - Ensure sufficient water pressure. The oscillation mechanism requires a certain pressure to function correctly.
 - Check for any debris obstructing the internal mechanism. If accessible, gently clear any blockages.

6. SPECIFICATIONS

Brand	Gardena
Model Number	18712-34
Material	Plastic
Color	Black
Item Weight	0.82 Kilograms
Maximum Coverage Area	Up to 250m ²
Features	Even and precise watering, Easy assembly, Frost and UV protection, Soft plastic nozzles for easy cleaning

7. WARRANTY AND SUPPORT

Gardena products are manufactured to high-quality standards and come with a manufacturer's warranty.

For specific warranty details, please refer to the warranty card included with your purchase or visit the official Gardena website.

For technical support, spare parts, or any questions regarding your Gardena Oscillating Sprinkler Aquazoom M, please contact Gardena customer service. Contact information can typically be found on the product packaging or on the official Gardena website (www.gardena.com).