

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [YUSTDA](#) /

> [YUSTDA AC Adapter Charger Instruction Manual for Electrolux Ergorapido EL2081A Series \(Model TNS30Wxy\)](#)

## YUSTDA TNS30Wxy

# YUSTDA AC Adapter Charger Instruction Manual

Model: TNS30Wxy for Electrolux Ergorapido EL2081A Series

## 1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your YUSTDA AC Adapter Charger, Model TNS30Wxy. This power supply unit is designed to provide reliable power to compatible devices, specifically the Electrolux Ergorapido EL2081A Series. Please read this manual thoroughly before use and retain it for future reference.



Image: The YUSTDA AC Adapter Charger, showcasing its robust and space-saving construction, designed for long-term, safe operation.

## 2. SAFETY INFORMATION

Your safety is paramount. Please observe the following precautions to prevent injury or damage to the product and connected devices.

- **Risk of Electric Shock:** Do not disassemble the adapter. Refer all servicing to qualified personnel.
- **Heat Warning:** The adapter may become warm during operation. This is normal. Ensure adequate ventilation around the adapter and avoid covering it.
- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose to water, rain, or excessive humidity.
- **Proper Connection:** Ensure the adapter is fully inserted into the power outlet and the device's charging port. Loose connections can cause overheating or damage.
- **Cable Care:** Do not place heavy objects on the power cord or subject it to sharp bends. Inspect the cord regularly for damage.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use for extended periods or during electrical storms.

This adapter is equipped with multiple safety protections:

- **Over Current Protection:** Safeguards against excessive current flow.
- **Total Power Protection:** Prevents damage from power surges.
- **Over Voltage Protection:** Protects against input voltage fluctuations.
- **Short Circuit Protection:** Automatically shuts down in case of a short circuit.
- **Over-Temperature Protection:** Monitors and prevents overheating.



Image: Visual representation of the adapter's integrated safety mechanisms, ensuring reliable and protected power delivery.

### 3. SETUP

1. **Verify Compatibility:** Ensure your device, such as the Electrolux Ergorapido EL2081A Series, requires a power adapter with the specifications listed in Section 6 of this manual.
2. **Connect to Device:** Insert the DC output plug of the adapter firmly into the charging port of your Electrolux Ergorapido EL2081A Series device.

3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard wall outlet (100-240VAC, 50/60Hz).
4. **Confirm Power:** Your device should indicate that it is receiving power or charging.



Image: The AC adapter connected to a power strip, demonstrating a typical setup for charging a device.

## 4. OPERATING INSTRUCTIONS

Once connected, the adapter will supply power to your device. For optimal performance and longevity:

- Use the adapter only with compatible devices as specified.
- Avoid operating the adapter in extreme temperatures or direct sunlight.
- Do not block the ventilation of the adapter.
- If the adapter shows signs of damage or malfunction, discontinue use immediately.

## 5. MAINTENANCE

Proper care will extend the life of your AC adapter.

- **Cleaning:** Disconnect the adapter from the power source and device before cleaning. Use a soft, dry

cloth to wipe the exterior. Do not use liquid cleaners or solvents.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly winding the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of wear, cuts, or damage.

## 6. TROUBLESHOOTING

If you encounter issues with your AC adapter, try the following steps:

- **No Power to Device:**
  - Ensure the adapter is securely plugged into both the wall outlet and the device.
  - Test the wall outlet with another appliance to confirm it is functional.
  - Check the adapter's cable for any visible damage.
- **Adapter Overheating:**
  - Ensure the adapter has adequate ventilation and is not covered.
  - Verify that the device being charged is compatible and not drawing excessive power.
  - If overheating persists, discontinue use and contact support.
- **Device Not Charging Properly:**
  - Confirm the device's charging port is clean and free of debris.
  - Ensure the adapter's output plug is fully inserted and making good contact.

If these steps do not resolve the issue, please refer to the Warranty and Support section.

## 7. SPECIFICATIONS

Technical details for the YUSTDA AC Adapter Charger Model TNS30Wxy:

Feature	Detail
<b>Model Number</b>	TNS30Wxy
<b>Input Voltage</b>	100-240VAC
<b>Input Frequency</b>	50/60Hz
<b>Output Current</b>	1 Amps
<b>Connector Type</b>	Proprietary
<b>Compatible Devices</b>	Electrolux Ergorapido EL2081A Series (and other compatible devices)
<b>Safety Features</b>	Over Current Protection, Total Power Protection, Over Voltage Protection, Short Circuit Protection, Over-Temperature Protection
<b>Certifications</b>	FCC, CE, RoHS

Feature	Detail
Power Source	Corded Electric




Image: The product label detailing the model number, input, and output specifications of the YUSTDA AC Adapter.

## High Quality Power Cable Design



Image: An illustration highlighting the high-quality construction of the power cable, featuring copper wire and durable PVC insulation.

### 8. WARRANTY AND SUPPORT

YUSTDA products are manufactured with high-quality materials and undergo rigorous testing to ensure reliability. For any questions, concerns, or technical support regarding your AC adapter, please contact our customer service team.

**Customer Support Email:** [epcustomerservice@yahoo.com](mailto:epcustomerservice@yahoo.com)

Please include your product model number (TNS30Wxy) and a detailed description of your inquiry when contacting support to facilitate a quicker resolution.