

Klarstein New Breeze 9

Klarstein New Breeze 9 Portable Air Conditioner

User Manual

1. INTRODUCTION

Thank you for choosing the Klarstein New Breeze 9 Portable Air Conditioner. This unit is designed to provide a comfortable indoor climate through its 3-in-1 functions: cooling, dehumidification, and ventilation. With a cooling capacity of 9000 BTU / 2.6 kW, it is suitable for rooms ranging from 26 to 44 m². This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure optimal performance of your appliance.

2. SAFETY INSTRUCTIONS

Please read these safety instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or injury.

- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the unit with a damaged cord or plug. Contact qualified service personnel for repairs.
- Keep the appliance away from heat sources, direct sunlight, and flammable materials.
- Do not insert objects into the air outlets or inlets.
- Always unplug the unit before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Ensure proper ventilation when operating the unit.
- Do not use the appliance in wet environments such as bathrooms or laundries.

3. PRODUCT OVERVIEW AND COMPONENTS

The Klarstein New Breeze 9 is a compact and mobile air conditioning unit designed for ease of use and portability. It features a control panel on top and comes with a remote control for convenient operation.



Figure 1: Klarstein New Breeze 9 Portable Air Conditioner with key dimensions.



Figure 2: Key features and components of the air conditioner.

Included Components:

- Klarstein New Breeze 9 Portable Air Conditioner Unit
- Remote Control (batteries included)
- Exhaust Hose (approx. 150 cm length, 14 cm diameter)
- Window Adapter for Exhaust Hose
- User Manual

An optional window sealing kit is available separately for enhanced efficiency.

4. SETUP AND INSTALLATION

Follow these steps to set up your air conditioner for first use:

1. **Unpacking:** Carefully remove the unit from its packaging. Retain the packaging for future storage or transport.
2. **Positioning:** Place the air conditioner on a flat, stable surface. Ensure there is at least 30 cm of clear space around the unit for proper airflow. The integrated floor casters allow for easy movement.
3. **Exhaust Hose Installation:**
 - Attach one end of the exhaust hose to the air outlet on the back of the unit.
 - Attach the window adapter to the other end of the exhaust hose.
 - Extend the exhaust hose and position the window adapter in a partially open window or a dedicated window sealing kit (if used) to vent hot air outside. Ensure the hose is as straight and short as possible to maximize efficiency.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

The Klarstein New Breeze 9 can be controlled via the touch panel on the top of the unit or using the included remote control.

Control Panel and Display:

The control panel features an LCD display and LED indicators for various functions. Refer to Figure 2 for the general layout.

Operating Modes:

The unit offers three primary operating modes:

- **Cooling Mode:** Standard operation for cooling rooms. Set your desired temperature between 16°C and 30°C.
- **Dehumidification Mode (Drying):** Removes excess moisture from the air, reducing humidity. The fan operates at a low speed in this mode.
- **Fan Mode:** Circulates air without cooling. This mode is energy-efficient and can be used for general air movement.

Fan Speed Settings:

In Cooling and Fan modes, you can select from four fan speeds:

- Low
- Medium
- High
- Auto (the unit adjusts fan speed based on room temperature)

Timer Function:

The programmable timer allows you to set the unit to turn on or off automatically after a specified period. The timer can be adjusted in 0.5-hour increments, up to a maximum of 10 hours.

Sleep Mode:

Activate Sleep Mode for quieter operation and gradual temperature adjustment during the night. In this mode, the cooling performance is reduced by 3°C over 3 hours, and then the temperature is maintained at that level.

Remote Control:

The remote control provides convenient access to all functions from a distance. Ensure the remote control has working batteries (included) and is pointed towards the unit's receiver.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your air conditioner.

Cleaning the Air Filter:

The air filter should be cleaned regularly (every two weeks or more often depending on usage) to prevent

dust buildup and maintain airflow.

1. Unplug the air conditioner from the power outlet.
2. Locate and remove the air filter (usually at the back or side of the unit).
3. Clean the filter with a vacuum cleaner or wash it gently with lukewarm water and mild detergent.
4. Rinse thoroughly and allow the filter to air dry completely before reinserting it into the unit.

Cleaning the Unit Exterior:

Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals, abrasives, or solvents, as these can damage the surface.

Storage:

If storing the unit for an extended period:

- Drain any accumulated water from the unit.
- Clean the air filter and the exterior.
- Store the unit in a dry, cool place, preferably in its original packaging.

7. TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power cord not plugged in; Fuse blown; Unit is in standby mode.	Check power connection; Check circuit breaker/fuse; Press power button.
Insufficient cooling	Air filter clogged; Exhaust hose blocked or improperly installed; Room too large; Doors/windows open; Temperature setting too high.	Clean air filter; Check exhaust hose for kinks/blockages and proper sealing; Close doors/windows; Lower temperature setting.
Unit is noisy	Unit not on a flat surface; Air filter clogged; Foreign object in fan.	Place on a flat surface; Clean air filter; Turn off and inspect for obstructions.
Water leakage	Drain plug not properly sealed; Water tank full (if applicable).	Ensure drain plug is secure; Drain water tank.

8. SPECIFICATIONS

Feature	Specification
Brand	Klarstein
Model Name	New Breeze 9
Cooling Capacity	9000 BTU / 2.6 kW
Energy Efficiency Class	A
Room Size (Recommended)	26 to 44 m ²

Feature	Specification
Temperature Range	16 - 30 °C
Operating Modes	Cooling, Dehumidification, Fan
Fan Speeds	4 (Low, Medium, High, Auto)
Control Method	Touch Panel, Remote Control
Timer	0.5 - 10 hours
Noise Level (Min-Max)	50 - 64 dB
Product Dimensions (W x H x D)	29.5 x 77 x 36 cm
Product Weight	24.3 kg
Power Source	Corded Electric
Compressor Type	Rotary Scroll
External Unit Required	No
Minimum Window Opening Width	10.5 cm (for exhaust hose adapter)

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your purchase or contact your retailer. If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact Klarstein customer support. Have your model number and purchase details ready when contacting support.