

Mediashop M21360

Livington InstaChill Evaporative Air Cooler User Manual

Model: M21360
Brand: Mediashop

1. INTRODUCTION

The Livingston InstaChill is an evaporative air cooler designed to provide a refreshing and humidified environment. It utilizes a unique evaporation technology to cool the air without the use of chemical refrigerants. This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your InstaChill unit.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the unit is placed on a stable, level surface to prevent tipping and water spillage.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the unit from the power outlet before filling the water tank, cleaning, or performing any maintenance.
- Keep the appliance out of reach of children and pets.
- Do not block the air inlets or outlets. Ensure adequate space around the unit for proper air circulation.
- Use only clean, cold water in the water tank. Do not add any chemicals, oils, or other substances to the water.
- Do not operate the unit if the power cord or plug is damaged, or if the unit malfunctions or has been dropped.
- This appliance is for indoor use only. Do not use outdoors or in wet environments.

3. PACKAGE CONTENTS

Verify that all items are present and in good condition upon unpacking:

- Livingston InstaChill Evaporative Air Cooler Unit
- Remote Control with Batteries

4. SETUP

1. **Unpacking:** Carefully remove the InstaChill unit and all accessories from the packaging. Retain the packaging for future storage or transport.

2. **Placement:** Place the unit on a firm, level surface in the desired location. Ensure there is at least 20 cm of clear space around the air inlets and outlets for optimal performance.
3. **Fill Water Tank:**



Image: Hand pouring water into the Livingston InstaChill's water tank.

Pull out the water tank drawer located at the bottom of the unit. Slowly fill the 8.5-liter water tank with clean, cold tap water. For enhanced cooling performance, you may add chilled water or ice cubes to the tank. Do not exceed the maximum fill line indicated on the tank.

4. **Insert Remote Control Batteries:** Open the battery compartment on the remote control and insert the included CR2 battery, observing the correct polarity.
5. **Power Connection:** Plug the power cord into a standard 240V electrical outlet.

5. OPERATING INSTRUCTIONS





Image: The Livingston InstaChill unit, showcasing its sleek design and the cool air it circulates.



Image: Key features of the InstaChill, including its three adjustable speed and cooling levels, a powerful motor for efficient air circulation, and the convenience of a practical remote control.

1. **Power On/Off:** Press the **POWER** button on the control panel or remote control to turn the unit on or off.
2. **Adjust Fan Speed:** Press the **SPEED** button repeatedly to cycle through the three available fan speeds (Low, Medium, High).
3. **Activate Cooling Function:** Press the **COOL** button to activate the evaporative cooling function. The unit will begin to draw water from the tank to cool the air. Press again to deactivate.
4. **Swing Function:** Press the **SWING** button to activate the oscillation feature, which distributes cool air across a wider area. Press again to stop oscillation.
5. **Timer Function:** Use the **TIMER** button to set an automatic shut-off time for the unit. Refer to the control panel for specific timer increments.
6. **Remote Control Usage:** The included remote control allows for convenient operation of all functions from a distance. Point the remote control directly at the unit's sensor.



Image: The Livingston InstaChill providing a comfortable cooling breeze in a home setting, ideal for activities like ironing.



Image: The InstaChill positioned in an office environment, demonstrating its suitability for personal cooling during work.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your InstaChill unit.

- **Water Tank Cleaning:** To prevent mold, mildew, and unpleasant odors, clean the water tank regularly (at least once a week or more frequently with heavy use). Unplug the unit, remove the water tank, and wash it with mild soap and water. Rinse thoroughly and dry before reinserting.
- **Filter Cleaning:** The unit is equipped with three special filters. Periodically check the filters for dust and debris. Gently remove them and clean with a soft brush or vacuum cleaner. If heavily soiled, rinse with water and allow to air dry completely before reinserting.
- **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the unit for an extended period, ensure the water tank is empty and dry, and the filters are clean. Store in a cool, dry place away from direct sunlight.

INSTACHILL

livington®



**BIS ZU
12
STUNDEN**

**Laufleistung
pro Tankfüllung**

**8,5 L
TANK**

**Kühlt & erfrischt
mit reinem Wasser**

3 Spezial-Filter

**M
MEDIASHOP**

**AS SEEN ON
TV
ORIGINAL**

Image: Operational details of the InstaChill, illustrating its ability to run for up to 12 hours on a single tank fill, its 8.5-liter water tank, and the presence of three specialized filters for air purification.




Image: The Livingston InstaChill enhancing comfort in a living space, providing a pleasant atmosphere for relaxation.

7. TROUBLESHOOTING

If you encounter issues with your Livingston InstaChill, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Remote control batteries depleted or incorrectly inserted.	Check if the power cord is securely plugged into a working outlet. Replace or correctly insert remote control batteries.
No cooling effect	Water tank is empty; Cooling function not activated.	Fill the water tank. Press the COOL button to activate the cooling function.
Unit is noisy	Normal operation at higher fan speeds; Unit not on a stable surface.	Some operational noise is normal. Ensure the unit is placed on a flat, stable surface.

Problem	Possible Cause	Solution
Water leakage	Water tank overfilled; Tank not properly seated.	Do not overfill the water tank. Ensure the water tank is correctly and securely inserted into its compartment.

If the issue persists after attempting these solutions, please contact customer support.



Image: The InstaChill providing cooling in a garage or workshop, suitable for various personal spaces.



Image: The Livingston InstaChill, highlighting its "Very Good" overall rating (1.4) from DtGV (Deutsche Gesellschaft für Verbraucherstudien mbH) for evaporative coolers.

8. SPECIFICATIONS

Feature	Specification
Model Number	M21360
Dimensions (L x W x H)	28.1 x 28.1 x 91.3 cm
Weight	6.35 kg
Voltage	240 Volts
Power Type	Battery (for remote control) / Corded Electric (for unit)
Airflow Capacity	529.72 cubic feet per minute
Noise Level	40 dB
Water Tank Capacity	8.5 Liters (2.2 Gallons)

Feature	Specification
Recommended Room Size	Up to 30 square meters
Special Features	Timer, Remote Control
Included Components	Livingston InstaChill unit, Remote control with batteries

9. WARRANTY AND SUPPORT

For information regarding warranty coverage, product registration, or technical support, please refer to the documentation provided with your purchase or visit the official Mediashop website. You may also contact your retailer for assistance.