



[Manuals.plus](#) /

› [hauck](#) /

› hauck Cyclone Pedal Go Kart T90602 Instruction Manual

hauck T90602

hauck Cyclone Pedal Go Kart T90602 Instruction Manual

Model: T90602

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your hauck Cyclone Pedal Go Kart. Please read all instructions carefully before use and retain this manual for future reference.

The hauck Cyclone Pedal Go Kart is designed for children aged approximately 4 to 10 years, with a maximum weight capacity of 55 kg (121 lbs). It features a robust tubular steel frame, 12-inch EVA foam plastic wheels, an adjustable bucket seat, and a handbrake for rear wheels.



Image: The hauck Cyclone Pedal Go Kart in red and black, showcasing its design.

2. SAFETY INFORMATION

- Always supervise children during use.
- Ensure the child wears appropriate safety gear, including a helmet.
- Do not use on public roads, near motor vehicles, or on steep inclines.
- Ensure all bolts and fasteners are securely tightened before each use.
- The go-kart is designed for one rider only.
- Maximum user weight: 55 kg (121 lbs).
- Recommended age: 4-10 years.

3. SETUP AND ASSEMBLY

The hauck Cyclone Pedal Go Kart is designed for straightforward assembly. While the product description states "No Assembly Required", minor setup may be needed to ensure optimal performance and safety. Please follow the included manufacturer's assembly guide for detailed steps.

Key Assembly Points:

- **Wheel Attachment:** Ensure all wheels are securely attached and rotate freely. The 12-inch EVA foam plastic wheels are designed for a smooth ride.

- **Steering Column:** Verify the steering wheel and column are firmly connected and allow for full range of motion.
- **Seat Adjustment:** The bucket seat is adjustable. Adjust it to a comfortable position for the rider, ensuring their feet can reach the pedals fully and comfortably.
- **Brake System:** Confirm the handbrake for the rear wheels is properly installed and functions effectively. Test the brake before the first ride.
- **Frame Inspection:** Check the tubular steel frame for any signs of damage or loose connections.



Image: Diagram highlighting the adjustable bucket seat, handbrake, and robust tubular steel frame.

4. OPERATING INSTRUCTIONS

4.1 Getting Started

1. Ensure the rider is wearing a helmet and appropriate footwear.
2. Adjust the seat to allow the rider to comfortably reach the pedals.
3. Familiarize the rider with the steering and braking mechanisms in a safe, open area.

4.2 Pedaling

The go-kart is pedal-powered. The rider uses their feet to push the pedals forward, which drives the rear wheels. Encourage a smooth, continuous pedaling motion.

4.3 Steering

The steering wheel controls the front wheels. Turn the wheel left to go left and right to go right. Practice gentle turns before attempting sharper maneuvers.

4.4 Braking

The go-kart is equipped with a handbrake that operates on both rear wheels. To slow down or stop, pull the handbrake lever firmly. Teach the rider to apply the brake gradually to avoid sudden stops.

Your browser does not support the video tag.

Video: Official product video demonstrating the hauck Cyclone Pedal Go Kart in use, highlighting its features and operation.

5. MAINTENANCE

- **Cleaning:** Wipe down the go-kart with a damp cloth and mild soap. Avoid harsh chemicals.
- **Inspection:** Regularly check all nuts, bolts, and screws for tightness. Tighten any loose fasteners.
- **Wheel Care:** Inspect the EVA foam plastic wheels for wear or damage. Ensure they are free of debris.
- **Brake System:** Periodically check the handbrake cable and mechanism for proper function and wear. Adjust if necessary according to manufacturer guidelines.
- **Storage:** Store the go-kart in a dry place, away from direct sunlight and extreme temperatures, to prolong its lifespan.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Go-kart does not move when pedaled.	Chain is loose or disengaged.	Inspect the chain for proper tension and engagement. Re-engage if dislodged.
Steering is difficult or loose.	Loose steering column connection or damaged components.	Check and tighten all steering assembly bolts. Inspect for any visible damage.
Brake is ineffective.	Brake cable loose or worn brake pads.	Adjust the brake cable tension. If pads are worn, contact customer support for replacements.
Unusual noises during operation.	Loose parts, debris in wheels, or worn bearings.	Inspect all components for tightness. Remove any debris from wheels. If noise persists, contact customer support.

7. SPECIFICATIONS

- **Model Number:** T90602
- **Brand:** hauck
- **Age Range:** Approximately 4 - 10 years (Manufacturer Minimum Age: 48 months, Maximum Age: 120 months)
- **Maximum User Weight:** 55 kg (121 lbs)

- **Material Type:** Alloy Steel (frame)
- **Wheel Type:** 12-inch EVA Foam Plastic Wheels
- **Item Weight:** 10.3 Kilograms (22.7 lbs)
- **Dimensions (L x W x H):** 46.06" x 20.47" x 28.43" (117 x 52 x 72.2 cm)
- **Seat to Pedal Length:** Front position: 43.9 cm (17.3 in); Back position: 51 cm (20.1 in)
- **Brake System:** Handbrake for both rear wheels

Specifications

Length from Middle of Seat to Pedal

Front position: 43.9 cm; back position: 51 cm

Maximum User Weight

55 kg/122 lbs.

Dimensions

41.7" x 20.1" x 23.2"



Weight

10.28 kg/22.7 lbs.



Image: Visual representation of the go-kart with key specifications.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official hauck website. You may also contact the seller, Spreetail, for assistance.

- **Manufacturer:** Hauck UK Ltd
- **Seller:** Spreetail

- **Protection Plans:** Optional 2-Year Protection Plan and Complete Protect plans may be available for purchase.