

## Xiaomi XM800010

# Xiaomi Mi Dual Mode Wireless Mouse Silent Edition User Manual

Model: XM800010

## INTRODUCTION

The Xiaomi Mi Dual Mode Wireless Mouse Silent Edition is designed for seamless connectivity and quiet operation. This manual provides detailed instructions to help you set up, operate, maintain, and troubleshoot your mouse, ensuring optimal performance and user experience.

## PRODUCT OVERVIEW

Familiarize yourself with the components and features of your Xiaomi Mi Dual Mode Wireless Mouse.



**Figure 1:** Angled view of the Xiaomi Mi Dual Mode Wireless Mouse Silent Edition, showcasing its ergonomic design and black finish.



**Figure 2:** Top-down view of the mouse, highlighting the scroll wheel and the mode switch button.



**Figure 3:** Bottom view of the mouse, showing the power switch, mode switch button, and the battery compartment cover.



**Figure 4:** The mouse positioned next to a laptop, illustrating its compact size and suitability for various workspaces.



**Figure 5:** Visual representation of the mouse dimensions, approximately 11 cm in length and 6 cm in width.

## SETUP

---

### 1. Battery Installation

The mouse requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the bottom of the mouse (refer to Figure 3).
2. Slide the cover open.
3. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

### 2. Powering On

On the bottom of the mouse, slide the power switch to the "ON" position.

### 3. Connecting to Your Device

The Xiaomi Mi Dual Mode Wireless Mouse supports two connection modes: 2.4GHz RF (via USB receiver) and Bluetooth LE 4.0.

### 3.1. 2.4GHz RF Connection (USB Receiver)

1. Locate the USB receiver inside the battery compartment.
2. Remove the USB receiver.
3. Plug the USB receiver into an available USB port on your computer.
4. Ensure the mouse is in 2.4GHz mode. Press the mode switch button on the bottom of the mouse until the indicator light turns green (refer to Figure 3 for button location).
5. Your computer should automatically detect and install the necessary drivers. The mouse is ready for use.

### 3.2. Bluetooth Connection

1. Ensure your computer's Bluetooth is enabled.
2. Press the mode switch button on the bottom of the mouse until the indicator light turns blue (refer to Figure 3 for button location).
3. Press and hold the mode switch button for 3 seconds until the blue light starts blinking rapidly. This indicates pairing mode.
4. On your computer, go to Bluetooth settings and search for new devices.
5. Select "Mi Mouse Silent Edition" (or similar) from the list of available devices and click "Pair" or "Connect".
6. Once paired, the blue light on the mouse will stop blinking and remain solid for a few seconds before turning off. The mouse is now connected.

## OPERATING INSTRUCTIONS

---

### Basic Functions

- **Left Click:** Primary selection and activation.
- **Right Click:** Opens context menus.
- **Scroll Wheel:** Scrolls content vertically. Pressing the scroll wheel acts as a middle click.
- **Side Buttons:** The mouse features two side buttons, typically configured for "Forward" and "Back" navigation in web browsers and file explorers.

### Switching Between Devices (Dual Mode)

The dual-mode feature allows you to seamlessly switch between two connected devices (one via 2.4GHz RF and one via Bluetooth). Simply press the mode switch button on the bottom of the mouse to toggle between the green (2.4GHz) and blue (Bluetooth) connection modes.

### DPI (Dots Per Inch)

The mouse operates at a resolution of 1200 DPI, providing precise and smooth cursor movement for most tasks.

## MAINTENANCE

---

### Cleaning

- To clean the mouse, use a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the mouse.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the surface.

- Regularly clean the optical sensor on the bottom of the mouse to ensure accurate tracking.

## Battery Replacement

When the mouse performance degrades or the indicator light flashes, it may be time to replace the batteries. Follow the "Battery Installation" steps in the Setup section to replace the two AAA batteries.

## Storage

When not in use for extended periods, turn off the mouse using the power switch on the bottom to conserve battery life. Store the mouse in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Mouse not responding	Low battery; Mouse is off; Incorrect connection mode; USB receiver not plugged in (for 2.4GHz); Bluetooth not paired.	Replace batteries; Turn on the mouse; Switch to correct mode (green for 2.4GHz, blue for Bluetooth); Plug in USB receiver; Re-pair Bluetooth.
Cursor movement is erratic or jumpy	Dirty optical sensor; Unsuitable surface; Interference.	Clean the optical sensor; Use on a clean, non-reflective surface (e.g., mouse pad); Move mouse closer to receiver/device; Reduce other wireless interference.
Cannot switch between devices	Mode switch button not pressed correctly; One mode not properly connected.	Ensure a firm press on the mode switch button; Verify both 2.4GHz and Bluetooth connections are established.
Short battery life	Frequent usage; Low-quality batteries; Mouse left on when not in use.	Use high-quality alkaline batteries; Turn off mouse when not in use.

## SPECIFICATIONS

- **Model:** XM800010
- **Connectivity:** Dual Mode (2.4GHz RF via USB receiver, Bluetooth LE 4.0)
- **DPI:** 1200 dpi
- **Buttons:** 4 (Left, Right, Scroll Wheel/Middle, Side 1, Side 2)
- **Range:** Up to 10 meters (Bluetooth)
- **Power:** 2 x AAA Batteries
- **Dimensions:** Approximately 11 x 6 x 3.5 cm
- **Weight:** Approximately 56 g (without batteries)
- **Material:** ABS plastic, aluminum alloy (scroll wheel)
- **Operating System Compatibility:** Windows, macOS, Linux, Android, iPadOS (Bluetooth dependent)

## WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Xiaomi website or contact your local authorized Xiaomi service center. Keep your purchase receipt as proof of purchase for warranty claims.

Online Support: [Visit Xiaomi Global Support](#)

© 2024 Xiaomi. All rights reserved.