

NEBO NEB-KEY-0005

NEBO Mycro Rechargeable LED Keychain Light

INSTRUCTION MANUAL

Product Overview

The NEBO Mycro is a compact, rechargeable LED keychain light designed for portability and versatile illumination. It features multiple light modes, including a powerful 400-lumen Turbo mode, and is constructed from durable aircraft-grade aluminum. This manual provides detailed instructions for its proper use and care.



Image: The NEBO Mycro keychain light in silver, shown alongside its Micro-USB charging cable. This image highlights the compact design of the flashlight and the included charging accessory.

Setup

Initial Charging

Before first use, fully charge the NEBO Mycro. Locate the Micro-USB charging port, typically covered by a protective cap. Connect the included Micro-USB cable to the flashlight and the other end to a standard USB power source (e.g., computer, wall adapter). The charging indicator light will illuminate to show charging status.

HIGH-QUALITY COMPONENTS

AIRCRAFT-GRADE ANODIZED ALUMINUM BODY

CORROSION RESISTANT

MICRO-USB PORT

FULLY RECHARGES IN LESS THAN 2 HOURS




Image: An exploded view diagram of the NEBO Mycro, illustrating its internal components, including the Micro-USB charging port and the aircraft-grade anodized aluminum body. This image helps identify the charging port location.

A full charge typically takes less than 2 hours. The indicator light will change color (e.g., from red to green) when charging is complete.

Operating Instructions

The NEBO Mycro features a primary button for power and mode selection. It includes six distinct light modes.



SIX UNIQUE LIGHT MODES



Image: A close-up of the NEBO Mycro flashlight, highlighting the primary button and listing the six unique light modes: Turbo (400 lumens), High, Medium, Low, Green, and Red. This visual aid clarifies button function and mode options.

Power On/Off and Mode Selection

1. **To Turn On:** Press the primary button once. The light will activate in the last used mode (due to power memory setting).
2. **To Cycle Modes:** While the light is on, press the primary button repeatedly to cycle through High, Medium, Low, Green, and Red modes.
3. **Turbo Mode:** Double-press the primary button at any time to activate Turbo mode (400 lumens). This mode provides maximum brightness for a short duration.
4. **To Turn Off:** Press and hold the primary button for approximately 1-2 seconds. If the light has been in a single mode for more than 8 seconds, a single press will turn it off.

Mode Details

- **Turbo:** 400 lumens (momentary burst).
- **High:** Optimal visibility.
- **Medium:** Balanced output.
- **Low:** Extended runtime, up to 5 hours.

- **Green & Red:** Designed to help maintain night vision.

Maintenance

Charging

Regularly charge the device to maintain optimal performance. Use only the provided Micro-USB cable or a compatible alternative. Avoid over-discharging the battery completely, as this can reduce its lifespan.

Cleaning

Wipe the exterior of the flashlight with a soft, damp cloth as needed. Do not use abrasive cleaners or solvents, as these may damage the finish or internal components. Ensure the charging port cover is securely closed to maintain water resistance.

Storage

Store the NEBO Mycro in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to approximately 50% capacity every few months to prevent deep discharge.

Troubleshooting

- **Light does not turn on:**
 - Ensure the battery is charged. Connect to a power source using the Micro-USB cable.
 - Check for any obstructions around the button.
- **Light modes are not cycling:**
 - Ensure the button is being pressed firmly and released.
 - If the light has been on a single mode for an extended period, a single press may turn it off. Try turning it off and on again.
- **Charging indicator not working:**
 - Verify the Micro-USB cable is securely connected to both the flashlight and the power source.
 - Try a different USB cable or power source.
- **Reduced brightness or runtime:**
 - The battery may be low. Recharge the device fully.
 - Extreme temperatures can affect battery performance. Operate within recommended temperature ranges.

Specifications



IMPOSSIBLY BRIGHT

With up to 400 lumens of power, the MYCRO™ is capable of shining a brilliant beam of light up to 269 feet away.



Image: The NEBO Mycro flashlight illuminating a dark outdoor scene, demonstrating its powerful beam capable of reaching up to 269 feet. This image illustrates the effective range and brightness of the device.

NEBO Mycro Technical Specifications

Feature	Detail
Model Name	Nebo - NEB-KEY-0005
Dimensions	1.73"D x 1.16"W x 0.67"H
Weight	0.13 Pounds
Brightness (White)	Up to 400 Lumens (Turbo Mode)
Light Source Type	LED
Power Source	Battery Powered
Battery Type	200 mAh Lithium Polymer (Rechargeable)
Run Time (Low)	Up to 5 hours

Feature	Detail
Water Resistance Level	Water Resistant
Material	Aircraft-grade Anodized Aluminum
Included Components	Micro-USB to USB charging cable

Warranty Information

The NEBO Mycro Rechargeable LED Keychain Light comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Support

For further assistance, technical support, or warranty inquiries, please visit the official NEBO website or contact their customer service department. You can often find additional resources, FAQs, and contact information on the [NEBO Store on Amazon](#) or the manufacturer's dedicated support channels.