

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [WisFox](#) /
- › [WisFox 2.4G Wireless Mouse User Manual](#)

## WisFox HU-XI-201

# WisFox 2.4G Wireless Mouse User Manual

Model: HU-XI-201

## INTRODUCTION

---

Thank you for choosing the WisFox 2.4G Wireless Mouse. This ergonomic computer mouse is designed for comfort and efficiency, featuring adjustable DPI levels and a stable wireless connection. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.



Image: The WisFox 2.4G Wireless Mouse in green, showcasing its ergonomic design and compact size, alongside its USB receiver and Type-C adapter.

## PACKAGE CONTENTS

---

Please verify that all items are present in your package:

- 1 x WisFox 2.4G Wireless Mouse

- 1 x USB Receiver (stored in the battery compartment)
- 1 x Type-C Adapter
- 1 x User Manual (this document)

## PRODUCT OVERVIEW

---

Familiarize yourself with the components of your WisFox Wireless Mouse:

**Left Click Button:** Standard primary mouse button.

**Right Click Button:** Standard secondary mouse button.

**Scroll Wheel:** For vertical scrolling and middle-click functionality.

**DPI Switch Button:** Adjusts cursor sensitivity.

**Page Up Button (Side):** Navigates up a page or performs custom function.

**Page Down Button (Side):** Navigates down a page or performs custom function.

**Battery Slot:** Located on the underside, for 1 AA battery (not included).

**USB Receiver Storage:** Compartment next to the battery slot for the USB receiver.

**On/Off Switch:** Power control for the mouse.

# SIX BUTTON DESIGN



Image: A detailed diagram illustrating the six-button design of the WisFox Wireless Mouse, including labels for the DPI switch, page up/down buttons, and the location of the battery slot, USB receiver, and On/Off switch on the underside.

## SETUP


- 1. Install Battery:** Open the battery compartment cover on the underside of the mouse. Insert one AA battery (not included), ensuring correct polarity (+/-). Close the cover securely.
- 2. Retrieve USB Receiver:** The USB receiver is stored inside the battery compartment for convenience. Carefully remove it.
- 3. Connect Receiver:**
  - For devices with a standard USB-A port, plug the USB receiver directly into an available USB port on your computer or laptop.
  - For devices with a USB-C port, attach the included Type-C adapter to the USB receiver, then plug the combined unit into an available USB-C port on your device.



## COMPATIBLE WITH ALL USB AND TYPE C PORT



USB Port



Type-C Port

Image: An illustration demonstrating how to connect the WisFox Wireless Mouse receiver to both standard USB ports and Type-C ports using the provided adapter, highlighting its plug-and-play functionality.

4. **Power On:** Slide the On/Off switch on the underside of the mouse to the "ON" position. The mouse will automatically connect to the receiver. No additional drivers are required.

## OPERATING INSTRUCTIONS

1. **DPI Adjustment:** Press the DPI switch button located behind the scroll wheel to cycle through the three adjustable DPI levels: 800, 1200, and 1600. This allows you to customize the cursor sensitivity to your preference for different tasks.



Image: The WisFox Wireless Mouse positioned near a sleeping baby, emphasizing its noiseless click feature and indicating the adjustable DPI settings (800-1200-1600).

## 2. Button Functions:

- **Left/Right Click:** Perform standard click actions. The mouse features noiseless clicks for a quiet user experience.
- **Scroll Wheel:** Roll up or down to scroll through documents and web pages. Press down for middle-click functionality.
- **Side Buttons (Page Up/Page Down):** These buttons typically function as 'back' and 'forward' in web browsers or file explorers. Their functionality may vary depending on the application or operating system.

## 3. Auto Sleep Mode: To conserve battery life, the mouse features an intelligent power management system:

- After 1 minute of idling, the mouse will enter a power-saving mode.
- After 8 minutes of idling, it will enter a deeper sleep mode.
- To wake the mouse, simply double-click any button or move the mouse.

# SMART POWER MANAGEMENT

Save battery life and reduce battery replacement



**1** Min  
Power Saving Mode

**8** Mins  
Auto Sleep Mode




Image: An illustration detailing the smart power management features of the WisFox Wireless Mouse, showing it enters power-saving mode after 1 minute and auto sleep mode after 8 minutes of inactivity to save battery life.

## MAINTENANCE

---

Proper care will extend the life of your WisFox Wireless Mouse:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, but ensure no liquid enters the mouse.
- **Battery Replacement:** Replace the AA battery when the mouse performance degrades or it fails to respond. Always dispose of used batteries responsibly.
- **Storage:** When not in use for extended periods, turn off the mouse using the On/Off switch and store the USB receiver in its dedicated compartment to prevent loss.
- **Avoid Extreme Conditions:** Do not expose the mouse to extreme temperatures, direct sunlight, or excessive moisture.

## TROUBLESHOOTING

---

Problem	Solution
Mouse not responding.	<ul style="list-style-type: none"> <li>◦ Ensure the mouse is turned ON.</li> <li>◦ Check battery level and replace if necessary.</li> <li>◦ Verify the USB receiver is securely plugged into a working USB port.</li> <li>◦ Try plugging the receiver into a different USB port.</li> <li>◦ Move the mouse closer to the receiver to ensure it's within the 33ft range.</li> </ul>
Cursor movement is erratic or jumpy.	<ul style="list-style-type: none"> <li>◦ Clean the optical sensor on the underside of the mouse.</li> <li>◦ Use the mouse on a clean, non-reflective surface.</li> <li>◦ Adjust the DPI setting to a lower level if the cursor is too sensitive.</li> </ul>
Side buttons not working as expected.	<ul style="list-style-type: none"> <li>◦ Functionality of side buttons can vary by application. Test in a web browser (back/forward).</li> <li>◦ Ensure your operating system and drivers are up to date.</li> </ul>
Mouse frequently enters sleep mode.	<ul style="list-style-type: none"> <li>◦ This is a power-saving feature. Double-click or move the mouse to wake it. This behavior is normal.</li> </ul>

## SPECIFICATIONS

---

- **Model:** HU-XI-201
- **Connectivity:** 2.4G Wireless
- **DPI Levels:** 800, 1200, 1600 (Adjustable)
- **Buttons:** 6 (Left, Right, Scroll Wheel, DPI, Page Up, Page Down)
- **Power Source:** 1 x AA Battery (not included)
- **Wireless Range:** Up to 33 feet (10 meters)
- **Compatibility:** Windows 7/8/10/XP, Vista 7/8, Linux, Mac OS (V10.4 or higher), PC, Laptop, MacBook, Chromebook.
- **Dimensions:** 4.09 x 2.4 x 1.57 inches (105mm x 60mm x 40mm)
- **Weight:** 2.4 ounces
- **Special Features:** Ergonomic Design, Noiseless Click, Auto Sleep Mode, Portable, Lightweight.



Image: A visual representation of the WisFox Wireless Mouse's dimensions (105mm/4.13in length, 60mm/2.36in width, 40mm/1.58in height) and its compact, portable nature, shown fitting easily into a bag.



## WIDELY COMPATIBILITY

Windows, MacOS, Android, iOS



Image: An illustration highlighting the wide compatibility of the WisFox Wireless Mouse with Windows, macOS, Android, and iOS operating systems.

## WARRANTY AND SUPPORT

---

WisFox provides a 24-month guarantee and 90-day no-questions-asked return policy for this product. For any questions, technical assistance, or warranty claims, please contact WisFox customer support. Refer to the contact information provided with your purchase or visit the official WisFox website for support details.

**Manufacturer:** WisFox

**Country of Origin:** China

