Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > VOVO /
- > VOVO STYLEMENT TCB-090SA Smart Toilet User Manual

VOVO TCB-090SA

VOVO STYLEMENT TCB-090SA Smart Toilet User Manual

Model: TCB-090SA

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your VOVO STYLEMENT TCB-090SA Smart Toilet. Please read this manual thoroughly before installation and use to ensure proper function and safety.



Figure 1: VOVO STYLEMENT TCB-090SA Smart Toilet

2. KEY FEATURES

- Automatic Dual Flush: Smart seat sensor differentiates between small and full flushes (1.12 GPF / For 35 PSI).
- Heated Seat: Adjustable temperature for enhanced comfort.
- Warm Water & Dryer: Water heating system and built-in air dryer with adjustable temperatures.
- Wireless Remote Control: Controls posterior, feminine, and turbo wash functions, auto deodorization, and other settings.
- Tankless Flushing System: Tornado wash cleans the inner bowl powerfully using direct water supply.
- Night Light: Integrated LED night light for convenience in low light conditions.
- Self-Cleaning Nozzle: Stainless steel nozzle automatically cleans itself before and after use.
- Auto Open/Close Lid: Motion sensor provides hands-free operation.

3. SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance of your smart toilet. Please follow these steps carefully.

3.1 Pre-Installation Checks

- Ensure the product dimensions (28.3"D x 16.1"W x 21"H) are suitable for your bathroom space.
- Verify the availability of a standard electrical outlet (120V AC) near the toilet.
- Confirm water pressure is at least 35 PSI for optimal flushing.



Figure 2: Product dimensions and required electrical outlet.

3.2 Installation Steps

- 1. **Turn off Water Supply:** Locate the water shut-off valve for your toilet and turn it off. Flush the toilet to drain the tank.
- 2. Remove Existing Toilet Seat: Unscrew and remove your old toilet seat.
- 3. **Install Mounting Bracket:** Use the provided template and mounting hardware to secure the base bracket onto the toilet bowl. Adjust its position to align with the front of the toilet.
- 4. **Connect Water Line:** Attach the provided T-valve to your toilet's water supply line. Connect the water hose from the T-valve to the smart toilet unit. Ensure all connections are tight to prevent leaks.
- 5. **Attach Smart Toilet Unit:** Carefully slide the smart toilet unit onto the mounting bracket until you hear a 'click', indicating it is securely locked in place.

- 6. **Restore Water Supply:** Slowly turn on the water shut-off valve. Check for any leaks around the connections.
- 7. **Plug In Power:** Plug the smart toilet's power cord into the electrical outlet. Check that the power LED light on the unit illuminates.
- 8. **Mount Remote Control:** Attach the remote control holder to a convenient wall surface using the adhesive or screws provided. Place the remote control in its holder.

Your browser does not support the video tag.

Video 1: Official VOVO STYLEMENT TCB-090SA/TCB-090S Installation and Function Guide. This video demonstrates the step-by-step installation process and highlights key functions of the smart toilet.



Figure 3: Illustration of attaching the lower part of the toilet to the floor flange.



Figure 4: Illustration of connecting the upper part of the smart toilet to the base.




Figure 5: Illustration of turning on the water supply after installation.


4. OPERATING INSTRUCTIONS

Your VOVO STYLEMENT TCB-090SA Smart Toilet offers a range of features controlled via the wireless remote.

4.1 Remote Control Functions

REMOTE CONTROLLER





4. Posterior

Press the Feminine button to operate.

6. TURBO WASH Technology

Water pressure can be adjusted while the function is under operation.

5. Feminine

Press the Feminine button to operate.

7. Dryer

Use the dry function after using the posterior.

Figure 6: Wireless remote control for the smart toilet, detailing various functions.

- Stop: Stops all current operations.
- Posterior Wash: Provides a rear wash. Adjustable water pressure and nozzle position.
- Feminine Wash: Provides a gentle front wash. Adjustable water pressure and nozzle position.
- Turbo Wash: Stronger wash function for thorough cleaning.
- Dry: Activates the warm air dryer. Adjustable air temperature.
- Seat Temperature: Adjusts the heated seat temperature (multiple levels).
- Water Temperature: Adjusts the wash water temperature (multiple levels).
- Nozzle Position: Adjusts the nozzle's forward/backward position.
- Water Pressure: Adjusts the intensity of the water spray.
- LED Light: Toggles the bowl's night light.
- Power Save: Activates energy-saving mode.
- Nozzle Cleaning: Initiates the self-cleaning cycle for the nozzle.

4.2 Automatic Functions

• Auto Open/Close Lid: The lid automatically opens when a user approaches and closes after use, thanks to an integrated motion sensor.

- Automatic Dual Flush: The smart seat sensor detects the duration of use and automatically selects between a small flush or a full flush, providing hands-free operation.
- Auto Deodorization: An automatic system activates to remove unpleasant odors during and after use.



Figure 7: The smart toilet's automatic open/close lid function.

Figure 8: The integrated LED night light provides illumination for nighttime use.

5. MAINTENANCE

Regular maintenance ensures the longevity and hygienic operation of your smart toilet.

- **Nozzle Cleaning:** The stainless steel nozzle performs an automatic self-cleaning cycle before and after each use. For additional cleaning, use the 'Nozzle Cleaning' button on the remote control.
- Exterior Cleaning: Wipe the exterior surfaces with a soft, damp cloth and mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.
- **Filter Maintenance:** Periodically check and clean the water inlet filter to prevent blockages and maintain optimal water flow.




Figure 9: The 3-in-1 full stainless steel nozzle features a self-cleaning mechanism.

6. TROUBLESHOOTING

If you encounter any issues with your VOVO STYLEMENT TCB-090SA Smart Toilet, please refer to the following common troubleshooting tips:

- **No Power:** Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker if necessary.
- No Water Spray: Verify that the water supply valve is fully open. Check if the water inlet filter is clogged.
- Remote Control Not Responding: Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the toilet unit.
- Lid Not Opening/Closing Automatically: Check for any obstructions around the motion sensor. Ensure the sensor is clean.
- Leaks: Turn off the water supply immediately. Check all water connections for tightness. If leaks persist, contact customer support.

For persistent issues or problems not listed here, please contact VOVO customer support.

7. SPECIFICATIONS

| Feature | Specification |
|---------------------|--|
| Model Number | TCB-090SA |
| Color | White |
| Product Dimensions | 28.3"D x 16.1"W x 21"H |
| Material | Ceramic (Toilet), Polypropylene (Seat) |
| Item Weight | 115 Pounds |
| Installation Type | Floor Mounted |
| Flush Volume | 1.12 GPF (for 35 PSI) |
| Power Source | Corded Electric (AC 120V) |
| Included Components | Installation Kit |

8. WARRANTY AND SUPPORT

VOVO provides customer support for its products. For any inquiries, technical assistance, or warranty claims, please refer to the contact information provided with your product packaging or visit the official VOVO website. The product is returnable until Jan 31, 2026, as per Amazon's policy. Protection plans are also available for purchase.

© 2023 VOVO. All rights reserved.

Related Documents - TCB-090SA

