

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Redragon](#) /

› [Redragon GS520 RGB Desktop Speakers User Manual](#)

## Redragon GS520

# Redragon GS520 RGB Desktop Speakers User Manual

Model: GS520

## INTRODUCTION

---

This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your Redragon GS520 RGB Desktop Speakers. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

## PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 2 x Stereo Speakers



Image: The Redragon GS520 RGB Desktop Speakers, showing both units with their RGB lighting active.

## SETUP

Follow these steps to set up your Redragon GS520 speakers:

1. **Placement:** Position the two stereo speakers on either side of your monitor or desired listening area. Ensure they are within 31 inches (80 cm) of each other, as this is the maximum cable length between the two units.
2. **Power Connection:** Connect the USB cable from the speakers to an available USB port on your PC, laptop, or a USB power adapter. The speakers are USB powered (5 Volts DC).
3. **Audio Connection:** Connect the 3.5mm audio cable from the speakers to the 3.5mm audio output jack on your computer, TV, or laptop.
4. **Power On:** Press and hold the power button located on the top of the right speaker to turn the speakers on.

5. **Volume Adjustment:** Use the individual volume up (+) and volume down (-) buttons on the right speaker to adjust the audio level.



**ANVIL**  
RGB COMPUTER STEREO  
DESKTOP SPEAKERS

Image: A pair of Redragon GS520 speakers positioned on a desk next to a computer monitor and keyboard, illustrating a typical setup.

# Touch Controlled RGB Lighting Bar

6 Modes Switchable via Touch Control



Image: A detailed view of the right speaker, highlighting the volume up, volume down, and power buttons for easy access and control.

## OPERATING INSTRUCTIONS

### Audio Playback

Once connected, the speakers will output audio from your connected device. Ensure your device's volume is also adjusted appropriately.

### RGB Lighting Control

The GS520 speakers feature a touch-controlled RGB lighting bar with 6 selectable modes. To change the lighting mode or turn the lights off, gently tap the touch sensor located on the top of the right speaker.

# RICH, CRYSTAL SOUND

Full Range 2.0 for Clear Bass



Image: An illustrative diagram demonstrating the touch control area on top of the speaker for cycling through the 6 RGB lighting modes.

## Volume Control

Individual buttons for volume up and volume down are provided on the right speaker for precise audio level adjustments.

## MAINTENANCE

To ensure the longevity and optimal performance of your speakers, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker surfaces. Avoid using liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the speakers with care. Avoid dropping them or subjecting them to strong impacts.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound output.	Speakers not powered on. Volume too low. Incorrect audio cable connection. Device audio output settings.	Press and hold the power button to turn on. Increase volume using the (+) button on the speaker and on your device. Ensure the 3.5mm audio cable is securely connected to the correct audio output jack (often green). Check your computer's sound settings to ensure the correct playback device is selected.
RGB lighting not working or stuck.	Lighting mode off. Temporary software glitch.	Tap the touch sensor on top of the right speaker to cycle through modes. Disconnect and reconnect the USB power cable to reset the speakers.
Distorted sound.	Volume too high. Poor audio source quality.	Lower the volume on both the speakers and your device. Test with a different audio source or file.

## SPECIFICATIONS

Feature	Detail
Model Name	Anvil (GS520)
Speaker Type	Multimedia, 2.0 Channel Stereo
Connectivity	USB (Power), 3.5mm Audio Cable
Input Voltage	5 Volts (DC)
Speaker Maximum Output Power	3 Watts
Frequency Response	20 KHz
RGB Lighting Modes	6 (Touch Controlled)
Material	Aluminum, Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	3.5"D x 4"W x 7"H
Item Weight	1.8 Pounds
Cable Length (between speakers)	Up to 31 inches (80 cm)

## WARRANTY AND SUPPORT

Redragon provides a limited warranty for the GS520 speakers. For detailed warranty information, product support, or technical assistance, please visit the official Redragon website or contact their customer service. Keep your purchase receipt for warranty claims.

For additional resources and product information, you may visit the [Redragon Store on Amazon](#).

