

KLARSTEIN Shiraz Uno (HEA-90300-zght, 10035028A)

KLARSTEIN Shiraz Uno Wine Cooler Instruction Manual

Model: Shiraz Uno (HEA-90300-zght, 10035028A)

Brand: KLARSTEIN

1. INTRODUCTION

Thank you for choosing the KLARSTEIN Shiraz Uno Wine Cooler. This manual provides essential information for the safe installation, operation, and maintenance of your appliance. Please read these instructions carefully before use and keep them for future reference.

2. SAFETY INSTRUCTIONS

- Ensure the appliance is properly grounded.
- Do not operate the appliance with a damaged power cord or plug.
- Place the wine cooler on a firm, level surface to prevent vibrations.
- Allow adequate ventilation around the unit. Maintain a minimum clearance of 10 cm (4 inches) from walls and other objects.
- Do not block ventilation openings.
- Keep the appliance away from direct sunlight and heat sources (e.g., stoves, heaters).
- Do not store explosive substances or flammable materials inside the appliance.
- Unplug the appliance before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PRODUCT OVERVIEW

The KLARSTEIN Shiraz Uno is a single-zone wine cooler designed for optimal storage of red, white, and sparkling wines. It features a sleek design with a glass door, soft-touch controls, and internal LED lighting.

Key Features:

- **Single Cooling Zone:** Provides a consistent temperature for ideal wine maturation.
- **Temperature Range:** Adjustable from 5°C to 18°C (41°F to 64°F).
- **Capacity:** 63 Liters, accommodating up to 24 standard wine bottles.
- **Low Vibration & UV Protection:** Ensures wine quality is preserved.
- **Quiet Operation:** Operates at a low noise level of 45 dB.
- **Soft-Touch Control Panel:** For intuitive temperature and light adjustments.
- **Active Carbon Filter:** Helps maintain an odor-free internal environment.
- **Freestanding Design:** Allows flexible placement in your home.



The image shows a front view of the KLARSTEIN Shiraz Uno wine cooler. The cooler is black with a glass door and internal LED lighting. The temperature display on the top panel shows 18°C. The cooler is surrounded by feature callouts in Italian.

1 ZONA DI RAFFREDDAMENTO PER UNA MATURAZIONE IDEALE

TEMPERATURA A SCELTA DA 5 A 18 °C

COMODO PANNELLO DI CONTROLLO SOFT-TOUCH

EXTRA SICURO: BASSE VIBRAZIONI E PROTEZIONE UV

SILENZIOSO 45 DB

SPAZIO PER UN MASSIMO DI 24 BOTTIGLIE DI VINO

Un elegante punto d'attrazione: Ideale per conservare e presentare i vini

Image 3.1: Front view of the KLARSTEIN Shiraz Uno wine cooler, highlighting its single cooling zone, 5-18°C temperature range, soft-touch control panel, low vibration, UV protection, 45 dB silent operation, and capacity for 24 wine bottles.

1 ZONA - RAFFREDDAMENTO PERFETTO DEL TUO VINO PREFERITO



Ideale per le bottiglie di champagne



32 cm

24
Bottiglie



Temperatura di conservazione selezionabile da 5 a 18 °C

Image 3.2: Interior view of the wine cooler, demonstrating its capacity for 24 bottles and suitability for champagne bottles. The image also reiterates the 5-18°C selectable storage temperature.

4. SETUP

4.1 Unpacking and Inspection

1. Carefully remove all packaging materials.
2. Inspect the wine cooler for any shipping damage. If damage is found, do not plug in the unit and contact your retailer.
3. Remove any internal packing, such as tape or foam, from the shelves and interior.

4.2 Placement

- Place the wine cooler on a flat, stable surface strong enough to support the unit when fully loaded.
- Ensure there is adequate air circulation around the unit. Leave at least 10 cm (4 inches) of space at the back and sides, and 30 cm (12 inches) at the top for proper ventilation.
- Avoid placing the unit in direct sunlight or near heat-generating appliances (e.g., oven, dishwasher, refrigerator).

- Do not install in areas where the temperature can drop below 5°C (41°F) or rise above 32°C (90°F).

4.3 Leveling the Unit

The wine cooler has adjustable leveling feet. Turn the feet clockwise to raise the unit or counter-clockwise to lower it. Ensure the unit is perfectly level to minimize vibrations and ensure proper door sealing.

4.4 Initial Cleaning

Before first use, clean the interior and exterior of the wine cooler with a soft cloth and a mild detergent solution. Rinse with clean water and dry thoroughly.

4.5 Power Connection

After placing and leveling the unit, allow it to stand upright for at least 2-4 hours before plugging it into a power outlet. This allows the refrigerant to settle. Connect the appliance to a dedicated, properly grounded electrical outlet.

4.6 First Use

Once plugged in, the unit will start cooling. Allow it to run for at least 24 hours empty to reach the desired temperature before loading bottles.

ELEMENTO D'ATTRAZIONE OVUNQUE VUOI: GRAZIE ALLA STRUTTURA INDIPENDENTE



Image 4.1: The wine cooler shown in a room setting with its dimensions (43 cm width, 45 cm depth, 74.5 cm height)

indicated, emphasizing its freestanding structure for flexible placement.

5. OPERATING INSTRUCTIONS

5.1 Control Panel

The wine cooler features a soft-touch control panel located on the top front of the unit. The display shows the current internal temperature.




Image 5.1: Detailed view of the wine cooler's control panel, showing intuitive operation. Also visible are the stylish internal lighting, height-adjustable shelves, removable metal inserts, and the active carbon filter for odor-free storage.

5.2 Setting the Temperature

1. Press the **Power** button to turn on the unit.
2. Use the **Up** (^) and **Down** (v) arrows to adjust the desired temperature. The temperature will flash on the display as you adjust it.
3. Once the desired temperature is set, the display will stop flashing and show the actual internal temperature. The unit will then work to reach and maintain this temperature.

5.3 Internal Light

Press the **Light** button (often represented by a light bulb icon) on the control panel to turn the internal LED light on or off. The light is designed for display purposes and should not be left on for extended periods as it can slightly affect internal temperature.

5.4 Loading Bottles

- Arrange bottles to allow for proper air circulation. Do not overload the shelves.
- The shelves are designed to accommodate standard 750ml wine bottles. Larger or irregularly shaped bottles may reduce the total capacity.
- For optimal storage, place bottles horizontally to keep corks moist.

5.5 Recommended Serving Temperatures

- **Red Wines:** 14-18°C (57-64°F)
- **White Wines:** 8-12°C (46-54°F)
- **Sparkling Wines/Champagne:** 5-7°C (41-45°F)

6. MAINTENANCE

6.1 Cleaning

Regular cleaning helps maintain the performance and appearance of your wine cooler.

1. Always unplug the appliance before cleaning.
2. **Interior:** Clean the interior with a soft cloth, warm water, and a mild, non-abrasive detergent. Do not use harsh chemicals or abrasive cleaners.
3. **Exterior:** Wipe the exterior with a soft, damp cloth. For glass surfaces, use a glass cleaner.
4. **Door Seal:** Clean the door gasket regularly to ensure a tight seal.
5. Ensure all parts are dry before plugging the unit back in.

6.2 Defrosting

The wine cooler is designed for automatic defrosting. However, if a significant layer of ice builds up, manually defrost the unit:

1. Unplug the unit.
2. Remove all bottles and shelves.
3. Leave the door open to allow ice to melt naturally. Place a towel at the bottom to absorb water.
4. Once defrosted, clean and dry the interior thoroughly before restarting.

6.3 Active Carbon Filter

The active carbon filter helps eliminate odors. It is recommended to replace the filter every 3-6 months, depending on usage and environment, to maintain optimal odor control.

6.4 Power Outage

In case of a power outage, the wine cooler will generally maintain its temperature for several hours if the door remains closed. Avoid opening the door unnecessarily.

6.5 Vacation

- **Short Vacations (less than 3 weeks):** Leave the wine cooler operating normally.

- **Long Vacations (more than 3 weeks):** Remove all bottles, unplug the unit, clean and dry the interior thoroughly, and leave the door slightly ajar to prevent odors and mold growth.

7. TROUBLESHOOTING

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
Wine cooler does not operate.	No power; unit unplugged; circuit breaker tripped.	Check power supply, plug, and circuit breaker.
Unit is not cooling sufficiently.	Door not closed properly; excessive door openings; warm ambient temperature; ventilation blocked; temperature setting too high.	Ensure door is sealed; reduce door openings; ensure proper ventilation; lower temperature setting.
Excessive noise.	Unit not level; loose parts; bottles vibrating.	Adjust leveling feet; check for loose components; rearrange bottles.
Internal light not working.	Light switch off; LED bulb failure.	Press light button; contact support for bulb replacement.
Water on the floor.	Drainage hole blocked; excessive humidity.	Clear drainage hole; ensure proper ventilation.

8. SPECIFICATIONS

Specification	Value
Brand	KLARSTEIN
Model Number (Manufacturer)	HEA-90300-zght
Model Number (Energy Label)	10035028A
Capacity	63 Liters / 24 Bottles
Temperature Range	5 - 18°C
Dimensions (D x W x H)	45 cm x 43 cm x 74.5 cm
Weight	24.7 kg
Noise Level	45 dB
Annual Energy Consumption	142 kWh/year
Energy Efficiency Class	G
Installation Type	Freestanding
Country of Origin	China




ENERG ⚡



Klarstein

10035028A




G

G

142 kWh/annum



24



ABCD

2019/2016

Image 8.1: The energy label for the KLARSTEIN Shiraz Uno wine cooler, showing its energy class G, annual energy consumption of 142 kWh, 24 bottle capacity, and 45 dB noise level.

Scheda informativa del prodotto				Queste impostazioni non sono in contrasto con le condizioni di conservazione di cui all'allegato IV, tabella 3			
REGOLAMENTO DELEGATO (UE) 2019/2016 DELLA COMMISSIONE per quanto riguarda l'etichettatura energetica degli apparecchi di refrigerazione							
Nome o marchio del fornitore: Klarstein							
Indirizzo del fornitore: Chal - Tec GmbH, Wallstraße 16, 10179 Berlin, DE							
Identificativo del modello: 10035028A							
Tipo di apparecchio di refrigerazione:							
Apparecchio a bassa rumorosità:	No	Tipo di apparecchio:	a libera installazione				
Frigorifero cantina:	Sì	Altro apparecchio di refrigerazione:	No				
Parametri generali del prodotto:							
Parametro	Valore	Parametro	Valore				
Dimensioni complessive (millimetri)	Altezza	740	Volume totale (dm ³ o l)	63			
	Larghezza	430					
	Profondità	450					
EI	179	Classe di efficienza energetica	G				
Emissioni di rumore aereo (dB(A) re 1 pW)	45	Classe di emissione di rumore aereo	D				
Consumo annuo di energia (kWh/a)	142	Classe climatica:	temperata				
Temperatura ambiente minima (°C) per la quale l'apparecchio di refrigerazione è adatto	16	Temperatura ambiente massima (°C) per la quale l'apparecchio di refrigerazione è adatto	32				
Configurazione invernale	No						
Parametri degli scomparti:							
Tipo di scomparto	Parametri e valori degli scomparti						
	Volume dello scomparto (dm ³ o l)	Impostazioni di temperatura raccomandate per una conservazione ottimale degli alimenti (°C)	Capacità di congelamento (kg/24 h)	Defrosting type (auto-defrost=A, manual defrost=M)			
Dispensa	No	-	-	-	-	-	-
Cantina	Sì	63,0	12	-	-	-	A
Temperatura moderata	No	-	-	-	-	-	-
Alimenti freschi	No	-	-	-	-	-	-
Raffreddamento	No	-	-	-	-	-	-
0 stelle o produzione di ghiaccio	No	-	-	-	-	-	-
1 stella	No	-	-	-	-	-	-
2 stelle	No	-	-	-	-	-	-
3 stelle	No	-	-	-	-	-	-
4 stelle	No	-	-	-	-	-	-
Sezione a 2 stelle	No	-	-	-	-	-	-
Scomparto a temperatura variabile	-	-	-	-	-	-	-
Per i frigoriferi cantina							
Numero di bottiglie di vino standard			24				
Parametri della sorgente luminosa:							
Tipo di sorgente luminosa			-				
Classe di efficienza energetica			-				
Durata minima della garanzia offerta dal fabbricante: 24 mesi							
Informazioni supplementari:							
Link al sito web del fabbricante, che riporta le informazioni di cui all'allegato, punto 4, lettera a), del regolamento (UE) 2019/2019 della Commissione: www.klarstein.de							

Pagina 1 / 2

Pagina 2 / 2

Image 8.2: Detailed regulatory information and energy label data for the KLARSTEIN Shiraz Uno (Model 10035028A). This includes manufacturer details, energy consumption, noise level, and a link to the EPREL database for further information.

For more detailed product information, please visit the EU EPREL database: <https://eprel.ec.europa.eu/qr/403268>

9. WARRANTY AND SUPPORT

9.1 Manufacturer's Warranty

This KLARSTEIN wine cooler comes with a manufacturer's warranty of **24 months** from the date of purchase. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, spare parts, or warranty inquiries, please contact KLARSTEIN customer support. Refer to the contact information provided with your purchase documentation or visit the official KLARSTEIN website for support details.