

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Port Designs](#) /

› [Port Designs Wireless 2.4GHz Rechargeable Bluetooth PRO Mouse User Manual](#)

## Port Designs 3567049007157

# Wireless 2.4GHz Rechargeable Bluetooth PRO Mouse User Manual

Brand: Port Designs | Model: 3567049007157

## INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Port Designs Wireless 2.4GHz Rechargeable Bluetooth PRO Mouse. This versatile device offers seamless connectivity across multiple platforms and devices, enhancing your productivity and user experience.

## KEY FEATURES

- **Multi-Device Connectivity:** Connect and switch between up to three devices independently using 2.4GHz wireless or Bluetooth.
- **Dual Connectivity Options:** Features both USB-A and USB-C compatibility for broad device support.
- **Adjustable Precision:** Five adjustable DPI (Dots Per Inch) levels for optimal cursor speed and accuracy.
- **Long-lasting Battery:** Integrated rechargeable battery provides up to 6 months of autonomy on a single full charge, thanks to its economy mode.
- **Ergonomic Design:** Lightweight and ambidextrous design ensures optimal comfort during extended use.
- **Silent Clicks:** Designed for quiet operation, minimizing click noise.
- **Enhanced Functionality:** Equipped with 5 buttons and a responsive scroll wheel for improved work efficiency.
- **Plug-and-Play:** Ready for use immediately upon connection.
- **Wide Compatibility:** Compatible with Windows, Mac OS, Chrome OS, and Android operating systems.

## PACKAGE CONTENTS

Please ensure all items are present in the package:

- Port Designs Wireless 2.4GHz Rechargeable Bluetooth PRO Mouse
- USB-A Receiver
- USB-C Adapter (for USB-A receiver)

- Charging Cable (USB-A to USB-C)
- User Manual (this document)

## SETUP

---

### Charging the Mouse

Before first use, it is recommended to fully charge the mouse. Connect the provided charging cable to the mouse's charging port and to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.

### Connecting via 2.4GHz Wireless (USB Receiver)

1. Locate the USB receiver, typically stored in a compartment on the underside of the mouse.
2. Insert the USB-A receiver into an available USB-A port on your computer. If your device only has USB-C ports, attach the USB-C adapter to the USB-A receiver first, then insert it into the USB-C port.
3. Turn on the mouse using the power switch on its underside.
4. Set the connection mode switch on the underside of the mouse to the "2.4G" position (usually indicated by a small icon or number 1).
5. The mouse should automatically connect to your device. No additional drivers are typically required for Windows, Mac OS, or Chrome OS.

### Connecting via Bluetooth

The mouse supports two Bluetooth connections (BT1 and BT2).

1. Turn on the mouse using the power switch on its underside.
2. Set the connection mode switch on the underside of the mouse to either the "BT1" or "BT2" position.
3. Press and hold the Bluetooth pairing button (often located near the mode switch) for 3-5 seconds until the indicator light starts blinking rapidly, indicating pairing mode.
4. On your device (computer, tablet, smartphone), open Bluetooth settings.
5. Search for new devices. The mouse should appear as "Port Designs Mouse" or similar.
6. Select the mouse to pair. The indicator light on the mouse will become solid when successfully paired.
7. Repeat steps 2-6 to pair with a second Bluetooth device using the other Bluetooth channel (BT2).

## OPERATING INSTRUCTIONS

---

### Switching Between Devices

Use the connection mode switch on the underside of the mouse to seamlessly switch between the 2.4GHz wireless connection (1) and the two Bluetooth connections (BT1 and BT2).

### Adjusting DPI (Sensitivity)

The mouse features a dedicated DPI button, usually located behind the scroll wheel. Press this button to cycle through the five adjustable DPI levels (e.g., 800, 1200, 1600, 2000, 2400 DPI). The indicator light may briefly change color or blink to indicate the current DPI setting.



Figure 1: Top view of the mouse, highlighting the DPI button and scroll wheel.

## Button Functions

The mouse is equipped with 5 buttons for enhanced functionality:

- **Left Click:** Standard primary click function.
- **Right Click:** Standard secondary click function (context menu).
- **Scroll Wheel Click:** Often used for middle-click or auto-scroll.
- **DPI Button:** Cycles through sensitivity settings.
- **Side Buttons (Forward/Backward):** Typically used for navigation in web browsers or file explorers. These buttons may be programmable in certain applications or operating systems.



Figure 2: Feature diagram of the mouse, illustrating button locations and connectivity options.

## MAINTENANCE

---

### Cleaning

To maintain optimal performance and appearance, regularly clean your mouse. Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the mouse.

### Battery Care

- Avoid fully discharging the battery frequently.
- Store the mouse in a cool, dry place when not in use for extended periods.
- If the mouse will not be used for a long time, charge it to about 50% before storage.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Mouse not responding.	Low battery; incorrect connection mode; receiver not properly inserted (2.4GHz); Bluetooth not paired.	Charge the mouse. Ensure the mode switch is set correctly (2.4G, BT1, or BT2). Re-insert the USB receiver. Re-pair Bluetooth.
Lag or intermittent connection.	Interference; distance from receiver/device; low battery.	Move closer to the receiver/device. Ensure no large metal objects are between the mouse and receiver. Charge the mouse.
DPI button not changing sensitivity.	Software conflict; mouse malfunction.	Restart your computer. Ensure no other mouse software is interfering. If problem persists, contact support.
Mouse not detected by Bluetooth.	Mouse not in pairing mode; Bluetooth on device is off; device not compatible.	Ensure mouse is in pairing mode (blinking light). Turn on Bluetooth on your device. Check device compatibility.

## SPECIFICATIONS

---

**Model Number:** 3567049007157

**Connectivity:** 2.4GHz Wireless (USB-A/USB-C receiver), Bluetooth (BT1, BT2)

**Movement Detection:** Optical

**Number of Buttons:** 5

**DPI Levels:** 5 adjustable levels (e.g., 800, 1200, 1600, 2000, 2400)

**Battery:** 1 Lithium Ion battery (included), rechargeable

**Battery Life:** Up to 6 months (depending on usage)

**Wireless Range:** Up to 20 meters (2.4GHz), up to 10 meters (Bluetooth)

**Dimensions:** 2.68 x 4.29 x 1.69 inches (6.8 x 10.9 x 4.3 cm)

**Weight:** 3.17 ounces (90 grams)

**Color:** Black

**Compatibility:** Windows, Mac OS, Chrome OS, Android

## WARRANTY AND SUPPORT

---

Port Designs products are designed for reliability and performance. For warranty information, technical support, or service inquiries, please refer to the official Port Designs website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

**Website:** [www.portdesigns.com](http://www.portdesigns.com)

**Customer Service:** Refer to the website for regional contact information.



