

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Vigor](#) /
- > [Vigor VBA-25L Inox Wet/Dry Vacuum Cleaner Instruction Manual](#)

Vigor VBA-25L

Vigor VBA-25L Inox Wet/Dry Vacuum Cleaner Instruction Manual

Model: VBA-25L (9934022)

1. PRODUCT OVERVIEW

The Vigor VBA-25L is a robust 25-liter stainless steel wet/dry vacuum cleaner designed for versatile cleaning tasks. It features a powerful 1500W motor, HEPA filtration for dry vacuuming, and a sponge filter for wet applications. This model also includes a power outlet for connecting electric tools, enhancing its utility in workshops and various environments.

Key Features:

- 1500W Motor for strong suction.
- 25-liter stainless steel (Inox) tank.
- Wet and dry vacuuming capabilities.
- HEPA filter for efficient dry dust collection.
- Sponge filter for liquid aspiration.
- Integrated power outlet for electric tools.
- Standard accessories included for various cleaning needs.



Figure 1: Vigor VBA-25L Inox Wet/Dry Vacuum Cleaner. This image displays the complete vacuum cleaner unit, highlighting its stainless steel tank and overall design.

2. PACKAGE CONTENTS AND ASSEMBLY

Before assembly, ensure all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support.



Figure 2: Included accessories for the Vigor VBA-25L. This image shows the hose, extension tubes, floor nozzle, crevice tool, brush attachment, HEPA filter, sponge filter, and dust bag.

2.1. Unpacking and Inspection

1. Carefully remove all components from the packaging.
2. Verify that all parts are included as per the list below.
3. Inspect for any visible damage.

2.2. Components List

- Vacuum unit with motor head and stainless steel tank
- Flexible hose
- Extension tubes (typically 2-3 pieces)
- Floor nozzle (for wet/dry use)
- Crevice tool
- Brush attachment
- HEPA filter (for dry vacuuming)
- Sponge filter (for wet vacuuming)
- Dust bag (for dry vacuuming)

2.3. Initial Assembly Steps

1. Attach the wheels (if separate) to the base of the tank.
2. Secure the motor head onto the stainless steel tank using the provided latches.
3. Insert the flexible hose into the suction inlet on the tank. Ensure it clicks securely into place.
4. Connect the desired extension tubes to the hose handle.
5. Attach the appropriate nozzle or brush to the end of the extension tube.

3. OPERATING INSTRUCTIONS

Always ensure the vacuum cleaner is unplugged before changing filters or accessories.

3.1. Dry Vacuuming

1. Ensure the HEPA filter is correctly installed over the motor cage.
2. Insert a dust bag into the tank, ensuring the opening aligns with the hose inlet.
3. Close the motor head securely.
4. Plug the power cord into a suitable electrical outlet.
5. Turn on the vacuum cleaner using the power switch.
6. After use, turn off the vacuum, unplug it, and empty the dust bag or tank as needed.

3.2. Wet Vacuuming

1. **Remove the dust bag and HEPA filter.**
2. Install the sponge filter over the motor cage.
3. Close the motor head securely.
4. Plug the power cord into a suitable electrical outlet.
5. Turn on the vacuum cleaner using the power switch.
6. Vacuum liquids. The float mechanism will automatically stop suction when the tank is full.
7. After use, turn off the vacuum, unplug it, and empty the liquid from the tank.

3.3. Using the Power Outlet for Tools

- The vacuum cleaner is equipped with a power outlet for connecting electric tools.
- Connect your electric tool (e.g., sander, saw) to this outlet.
- When the tool is switched on, the vacuum cleaner will automatically start, providing dust extraction.
- When the tool is switched off, the vacuum cleaner will continue to run for a few seconds to clear the hose, then shut off.
- Ensure the tool's power consumption does not exceed the vacuum cleaner's specified limit for the outlet.

4. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner. Always unplug the unit before performing any maintenance.

4.1. Emptying the Tank

- Unlatch and remove the motor head.
- For dry debris, carefully remove the dust bag and dispose of its contents.
- For liquids, carefully pour out the collected liquid into a suitable drain.
- Clean the inside of the tank with a damp cloth if necessary and allow it to dry completely before reassembly.

4.2. Filter Cleaning and Replacement

- **HEPA Filter:** For dry use, tap the filter gently to dislodge dust. For thorough cleaning, rinse under cold running water. Allow it to air dry completely (24-48 hours) before reinstallation. Do not use detergents or hot water. Replace the HEPA filter periodically or if damaged.
- **Sponge Filter:** For wet use, rinse the sponge filter under cold running water to remove debris. Squeeze out excess water and allow it to air dry completely before storing or using for dry vacuuming (after removing HEPA filter).

4.3. Accessory Cleaning

- Clean nozzles, brushes, and hoses with water and mild detergent.
- Ensure all accessories are dry before storing.
- Check the hose for blockages regularly and clear them if found.

4.4. Storage

- Store the vacuum cleaner in a dry, cool place, away from direct sunlight and extreme temperatures.
- Ensure the tank is empty and clean, and filters are dry before storage.
- Wrap the power cord neatly to prevent damage.

5. TROUBLESHOOTING

Refer to this section for common issues and their solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Vacuum does not start.	No power supply. Power switch off. Overheating protection activated.	Check power cord connection and wall outlet. Turn power switch to ON. Unplug, let cool for 30 minutes, then restart.
Loss of suction power.	Tank full. Filter clogged. Hose/nozzle blocked. Motor head not sealed properly.	Empty the tank. Clean or replace filter. Clear blockages from hose and accessories. Ensure motor head latches are secure.
Water leaking from tank.	Tank overfilled during wet vacuuming. Seals damaged or improperly seated.	Empty the tank. Do not exceed maximum fill line. Check and reseal seals. Replace if damaged.
Excessive dust escaping.	HEPA filter missing or damaged. Dust bag improperly installed or full.	Ensure HEPA filter is correctly installed and undamaged. Replace if necessary. Install dust bag correctly or replace if full.

6. TECHNICAL SPECIFICATIONS

Model	VBA-25L
Model Number	9934022
Brand	Vigor
Power	1500 Watts
Capacity	25 Liters
Tank Material	Stainless Steel (Inox)
Filter Type	HEPA, Cartridge, Sponge
Airflow	96 m ³ /h
Depression (Suction Power)	18 kPa

Weight	9.51 Kilograms
Dimensions (L x W x H)	57.79 x 40.1 x 38 cm
Power Source	Corded Electric
Special Feature	HEPA, Power outlet for tools