Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- LDAILY /
- Moccha Modern Kitchen Island Utility Cart User Manual

LDAILY B08L982DRC

Moccha Modern Kitchen Island Utility Cart User Manual

Model: B08L982DRC Brand: LDAILY

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Moccha Modern Kitchen Island Utility Cart. Please read this manual thoroughly before assembly and use to ensure safe and proper functionality. This utility cart is designed to provide additional storage and a versatile workspace in your kitchen or dining area.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble the cart on a soft, clean surface to prevent scratches or damage to components.
- Do not overtighten screws during assembly to avoid stripping threads or damaging the wood.
- Do not exceed the maximum weight capacity of 66 lbs on the stainless steel countertop.
- Always engage the locks on the directional wheels when the cart is stationary to prevent accidental movement.
- Keep small parts and hardware away from children during assembly and storage.

PARTS LIST

Before assembly, verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Stainless Steel Countertop
- Drawer Assembly (including drawer box and slides)
- Cabinet Frame (Rubber Wood panels)
- Cabinet Doors (2)

- · Adjustable Shelf
- Towel Rack / Push Handle
- Caster Wheels (4, including 2 with locking mechanisms)
- Hardware Pack (screws, cam locks, dowels, hinges, handles)

SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. It is recommended to have two people for certain steps to ensure stability and ease of construction.

- 1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface. Refer to the parts list and diagrams to identify each piece.
- 2. **Attach Caster Wheels:** Secure the four caster wheels to the bottom base of the cart frame using the provided screws. Ensure the two wheels with locking mechanisms are positioned at the front for easy access.
- 3. **Assemble Cabinet Frame:** Connect the side panels, back panel, and bottom panel of the cabinet using the cam locks and dowels. Ensure all connections are tight and the frame is square.
- 4. **Install Adjustable Shelf:** Insert the shelf pins into the desired height holes inside the cabinet. Place the adjustable shelf onto the pins.
- 5. **Assemble and Install Drawer:** Follow the specific instructions for assembling the drawer box and attaching the drawer slides to both the drawer and the main frame. Once assembled, slide the drawer into the designated slot. Attach the drawer handle.
- Attach Cabinet Doors: Mount the cabinet doors to the front of the cabinet frame using the provided hinges. Adjust hinges as necessary to ensure proper alignment and smooth opening/closing. Attach door handles.
- 7. **Place Stainless Steel Countertop:** Carefully place the stainless steel countertop onto the top of the assembled frame. Secure it using the designated fasteners from underneath.
- 8. **Attach Towel Rack/Handle:** Secure the towel rack/push handle to the side of the cart using the provided hardware.
- 9. **Final Check:** Verify that all screws are tightened and all components are securely in place. Test the drawer, cabinet doors, and wheel locks for proper function.



Figure 1: Exploded view showing main components for assembly.



Figure 2: Internal dimensions of the drawer and cabinet, illustrating storage capacity.

OPERATING INSTRUCTIONS

- Moving the Cart: To move the cart, unlock the directional wheels if they are engaged. Use the towel rack as a push handle to guide the cart to your desired location.
- Securing the Cart: Once the cart is in position, engage the locks on the two directional wheels to prevent unintended movement and ensure stability.
- **Using Storage:** The top drawer is suitable for utensils, smaller kitchen tools, or linens. The two-tier cabinet provides ample space for larger items like pots, pans, dishes, or pantry staples. The adjustable shelf allows customization of storage height to fit various items.
- **Countertop Use:** The stainless steel countertop is ideal for food preparation, serving, or holding small appliances. Ensure heavy items are placed centrally and within the specified weight limit.



Figure 3: The cart demonstrating its storage capabilities with the drawer and cabinet doors open.



Figure 4: Close-up view of the convenient towel rack and drawer handle.

MAINTENANCE

- Cleaning the Countertop: Wipe the stainless steel countertop with a dry cloth after each use. For stubborn stains, use a mild detergent and a soft cloth, then dry thoroughly to prevent water spots. Avoid abrasive cleaners or scouring pads, which can scratch the surface.
- Cleaning Wood Surfaces: Wipe wood surfaces with a soft, damp cloth. Dry immediately to prevent water damage. Avoid harsh chemicals, excessive moisture, or prolonged exposure to direct sunlight, which can damage the wood finish.
- Caster Wheels: Periodically check the caster wheels for debris (e.g., hair, lint) and clean as needed to ensure smooth movement and proper locking function.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain the cart's stability and structural integrity.

TROUBLESHOOTING

Problem	Possible Cause	Solution	
---------	----------------	----------	--

Problem	Possible Cause	Solution	
Cart is wobbly or unstable.	Loose fasteners; uneven floor surface.	Check and tighten all assembly screws. Ensure the cart is placed on a level surface.	
Drawer sticks or does not slide smoothly.	Misaligned drawer slides; debris in tracks; overloaded drawer.	Check drawer slide alignment and ensure they are securely attached. Clean any debris from the tracks. Reduce drawer contents if overloaded.	
Cabinet doors do not close properly.	Misaligned hinges; obstruction inside cabinet.	Adjust hinges as needed to align the doors. Check for items obstructing the door closure.	
Wheels do not roll smoothly or lock.	Debris caught in wheels; lock mechanism jammed.	Clean any hair or debris from around the wheel axles. Ensure the lock mechanism is clear and functioning correctly.	
Scratches on stainless steel countertop.	Abrasive cleaning materials; sharp objects.	Use only soft cloths and non-abrasive cleaners. Avoid dragging sharp objects across the surface. Minor scratches may be buffed with specialized stainless steel polish.	
Wood finish appears dull or damaged.	Exposure to moisture; harsh chemicals; lack of care.	Wipe spills immediately. Avoid direct sunlight or extreme temperature changes. Use wood-specific furniture polish if desired to restore luster.	

SPECIFICATIONS

• Model: B08L982DRC

• Brand: LDAILY

• Manufacturer: Moccha

- Product Dimensions (D x W x H): 28.5"D x 19"W x 35"H

• Countertop Dimensions: 26" x 20"

• Net Weight: 27 lbs

• Load Capacity of Countertop: 66 lbs

• Materials: Rubber Wood (frame), Stainless Steel (countertop, handles)

• Color: Brown

• Wheels: 4 Caster Wheels (2 omnidirectional, 2 directional with locks)



Figure 5: Detailed measurements of the kitchen island cart, including drawer and cabinet interior.

WARRANTY AND SUPPORT

For information regarding warranty coverage, product returns, or technical support, please contact the manufacturer or seller directly through your purchase platform. Keep your purchase receipt or order details as proof of purchase for any warranty claims.

Brand: LDAILY

Manufacturer: Moccha
ASIN: B08L982DRC

Rockford Public Schools Purchase Order Report (July 6 - August 9, 2024)

Detailed purchase order report from Rockford Public Schools covering July 6 to August 9, 2024, listing vendors, items, and costs.